

DocuPrint P255 d/P255 dw



User Guide

Contents

Preface	7
Trademarks and Document Disclaimer	8
About License.....	9
Types of Manuals	10
Using This Guide.....	11
Organization	11
Conventions.....	12
Safety Notes.....	13
Electrical Safety.....	14
Machine Installation.....	16
Operational Safety.....	18
Consumable	20
Warning and Caution Labels	21
Environment	22
Regulation	23
Radio Frequency Emissions (Class B).....	23
Product Safety Certification (UL, CB).....	23
Illegal Copies and Printouts.....	24
Product Features.....	25
1 Specifications.....	27
2 Basic Operation	31
Main Components	32
Front View.....	32
Rear View	33
Operator Panel	34
Turning On the Printer	35
Printing the Panel Settings Page.....	36
The Operator Panel	36
The Printer Setting Utility (Windows Only).....	36
Power Saver Mode.....	37
Exiting the Power Saver Mode	37
3 Printer Management Software	39
Print Drivers.....	40
CentreWare Internet Services	41
Creating an Administrative Password.....	41
Printer Setting Utility (Windows Only).....	42
SimpleMonitor (Windows Only)	43
Launcher (Windows Only).....	44

	User Setup Disk Creating Tool (Windows Only).....	45
4	Printer Connection and Software Installation.....	47
	Overview of Network Setup and Configuration.....	48
	Connecting Your Printer	49
	Connecting Printer to a Computer or a Network.....	50
	Setting the IP Address.....	52
	TCP/IP and IP Addresses.....	52
	Automatically Setting the Printer's IP Address	52
	Dynamic Methods of Setting the Printer's IP Address	53
	Assigning an IP Address (for IPv4 Mode).....	54
	Verifying the IP Settings	56
	Printing and Checking the System Settings Page	56
	Installing Print Drivers on Computers Running Windows.....	58
	Identifying Print Driver Pre-install Status (for Network Connection Setup).....	59
	Inserting the Software Pack CD-ROM	60
	USB Connection Setup.....	60
	Network Connection Setup	61
	Configuring Wireless Network Settings (DocuPrint P255 dw only).....	62
	Setting Up the Printer for Shared Printing	87
	Using the XML Paper Specification Print Driver	96
	Installing Print Drivers on Computers Running Mac OS X.....	97
	Mac OS X Wireless Settings on the Operator Panel (DocuPrint P255 dw only).....	98
	Installing Print Drivers on Computers Running Linux (CUPS).....	103
	Installing Print Drivers.....	104
	Specifying the Queue	105
	Specifying the Default Queue	108
	Specifying Printing Options.....	109
	Setting the Password for Authority as the Printer Administrator... ..	111
	Uninstalling Print Drivers	112
5	Printing Basics	115
	About Print Media.....	116
	Print Media Usage Guidelines	116
	Print Media That Can Damage Your Printer	117
	Print Media Storage Guidelines	117
	Supported Print Media.....	118
	Usable Print Media	119
	Standard Paper and Tested Paper	121
	Loading Print Media.....	125
	Capacity.....	125
	Print Media Dimensions.....	125

	Loading Print Media in the Paper Tray	126
	Loading Print Media in the Priority Sheet Inserter (PSI)	134
	Using the Output Tray Extension	139
	Setting Paper Sizes and Types	140
	Setting Paper Sizes	140
	Setting Paper Types	140
	Printing	141
	Printing from the Computer	141
	Canceling a Print Job	142
	Duplex Printing	143
	Selecting Printing Options	148
	Printing Custom Size Paper	153
	Checking Status of a Print Job	155
	Printing a Report Page	156
	Printer Settings	157
	Printing with the Web Services on Devices	159
	Adding Roles of Print Services	159
	Printer Setup	160
6	Using the Operator Panel Menus	161
	Understanding the Operator Panel Menus	162
	Report/List	163
	Meter Readings	164
	Admin Menu	164
	Tray Settings	182
	Panel Lock Feature	185
	Enabling the Panel Lock Feature	185
	Disabling the Panel Lock Feature	186
	Changing the Power Saver Mode Settings	187
	Resetting to Factory Defaults	188
7	Troubleshooting	189
	Clearing Jams	190
	Avoiding Jams	191
	Identifying the Location of Paper Jams	192
	Clearing Paper Jams From the Front of the Printer	193
	Clearing Paper Jams From the Rear of the Printer	198
	Clearing Paper Jams From the Center Output Tray	200
	Jam Problems	202
	Basic Printer Problems	203
	Display Problems	204
	Printing Problems	205
	Print Quality Problems	207
	The Output Is Too Light	208
	Toner Smears or Print Comes Off/Stain on Back Side	209

	Random Spots/Blurred Images.....	210
	The Entire Output Is Blank.....	210
	Streaks Appear on the Output	211
	Mottle	211
	Ghosting	212
	Fog.....	213
	Bead-Carry-Out (BCO)	213
	Auger Mark	214
	Wrinkled/Stained Paper	215
	The Top Margin Is Incorrect.....	216
	Protrudent/Bumpy Paper	216
	Other Problems	217
	Understanding Printer Messages	218
	Contacting Service	221
	Getting Help.....	222
	LCD Panel Messages	222
	SimpleMonitor Alerts.....	222
	Obtaining the Product Information	223
	Enabling Non-Genuine Mode	224
	Using the Operator Panel	224
	Using the Printer Setting Utility (Windows Only).....	225
8	Maintenance	227
	Replacing the Toner Cartridge	228
	When to Replace the Toner Cartridge	229
	Removing the Toner Cartridge	230
	Installing a Toner Cartridge	232
	Ordering Supplies.....	234
	Consumables.....	234
	When to Order a Toner Cartridge	234
	Recycling Supplies	235
	Storing Consumables	236
	Managing the Printer	237
	Checking or Managing the Printer	
	with the CentreWare Internet Services.....	237
	Checking Printer Status with the SimpleMonitor	
	(Windows Only).....	238
	Checking Printer Status Through E-mail	239
	Conserving Supplies.....	240
	Checking Page Counts.....	241
	Moving the Printer	242
	Contacting Fuji Xerox	245
	Technical Support.....	246
	Online Services	247

Preface

Thank you for purchasing the DocuPrint P255 d/P255 dw.

This guide is intended for users who use the printer for the first time, and provides all the necessary operating information about the printer.

Please read this guide to achieve the best performance from your printer.

This guide assumes you are familiar with computers and the basics of network operation and configuration.

After reading this guide, keep it safe and handy for future reference.

DocuPrint P255 d/P255 dw User Guide Help

Copyright© 2012 by Fuji Xerox Co., Ltd.

Fuji Xerox Co., Ltd.

July 2012 (Edition 2)

No. ME5779E2-2

Trademarks and Document Disclaimer

Apple®, Bonjour®, ColorSync®, Macintosh®, and Mac OS® are trademarks of Apple Inc. in the United States and/or other countries.

PCL® is a trademark of Hewlett-Packard Corporation in the United States and/or other countries.

Microsoft®, Windows Vista®, Windows®, and Windows Server® are trademarks of Microsoft Corporation in the United States and/or other countries.


Linux is a registered trademark of Linus Torvalds.

Novell is a registered trademark and SUSE is a trademark of Novell, Inc. in the United States and other countries.

Red Hat and Red Hat Enterprise Linux are registered trademarks of Red Hat, Inc. in the U.S. and other countries.

RSA,BSAFE are either registered trademarks or trademarks of EMC Corporation in the United States and/or other countries.

All product/brand names are trademarks or registered trademarks of the respective holders.

In this manual, safety instructions are preceded by the symbol . Always read and follow the instructions before performing the required procedures.

Fuji Xerox is not responsible for any breakdown of machines due to infection of computer virus or computer hacking.

IMPORTANT:

1. This manual is copyrighted with all rights reserved. Under the copyright laws, this manual may not be copied or modified in whole or part, without the written consent of the publisher.
2. Parts of this manual are subject to change without prior notice.
3. We welcome any comments on ambiguities, errors, omissions, or missing pages.
4. Never attempt any procedure on the machine that is not specifically described in this manual. Unauthorized operation can cause faults or accidents. Fuji Xerox is not liable for any problems resulting from unauthorized operation of the equipment.
5. Decompiling this manual is prohibited.

An export of this product is strictly controlled in accordance with Laws concerning Foreign Exchange and Foreign Trade of Japan and/or the export control regulations of the United States.

XEROX, the sphere of connectivity design, and DocuPrint are trademarks or registered trademarks of Xerox Corporation in the U.S. or Fuji Xerox Co., Ltd.

DocuWorks is a trademark of Fuji Xerox Co., Ltd.

All Xerox and Fuji Xerox product names are either registered trademarks or trademarks of Xerox Corporation or Fuji Xerox Co., Ltd.

About License

RSA BSAFE

Your printer includes RSA BSAFER Cryptographic software from EMC Corporation.



DES

This product includes software developed by Eric Young.

(eay@mincom.oz.au)

AES

Copyright© 2003, Dr BrianGladman, Worcester, UK. All rights reserved. This product uses published AES software provided by Dr Brian Gladman under BSD licensing terms.

TIFF(libtiff)

LibTIFF Copyright© 1988-1997 SamLeffler

Copyright© 1991-1997 Silicon Graphics, Inc.

JPEG

Our printer software uses some of the codes defined by the Independent JPEG Group.

Types of Manuals

<i>Safety Guide</i>	Describes the information you need to know before using the printer and to operate the printer safely.
<i>Setup Guide</i>	Provides step-by-step instructions on how to set up your printer. Also describes how to setup wireless network. (The wireless LAN feature is available only on the DocuPrint P255 dw model.)
<i>User Guide</i> (HTML files) (this guide)	Describes how to get ready to print and set various features. It also covers the operator panel menus, troubleshooting tips, and maintenance information. This guide is on the <i>Software Pack CD-ROM</i> .
<i>PostScript Level3 Compatible User Guide</i>	Describes how to set up your printer as a PostScript Level3 Compatible printer and the features that can be configured on your print driver. This guide is on the <i>Software Pack CD-ROM</i> .

Using This Guide

This section includes:

- "Organization" on page 11
- "Conventions" on page 12

■ Organization

This guide is organized into the following chapters. The summary of each chapter is as follows:

1 Specifications	Describes the printer specifications.
2 Basic Operation	Describes the main components of the printer, power saver modes, and how to turn on the printer.
3 Printer Management Software	Describes the software available for the printer.
4 Printer Connection and Software Installation	Describes the basic information about how to connect the printer to your computer and how to install the print driver.
5 Printing Basics	Describes the supported paper, how to load paper, and how to print data using various print features.
6 Using the Operator Panel Menus	Describes the setting items available on the operator panel and their setup procedures.
7 Troubleshooting	Describes the troubleshooting tips for printer problems such as paper jams.
8 Maintenance	Describes how to clean the printer, how to replace the toner cartridge, and how to see the printer status.
9 Contacting Fuji Xerox	Describes support information.

■ Conventions

- 1 In this guide, personal computers and workstations are collectively called “computers”.
- 2 The following terms are used throughout this guide:

IMPORTANT:





- Important information that must be read and followed.



NOTE:

- Additional information that merits emphasis.

See also:

- References within this guide.

- 3 Orientation of documents or paper is described in this guide as follows:
 , Long Edge Feed (LEF): Loading the document or paper in the landscape orientation.
 , Short Edge Feed (SEF): Loading the document or paper in the portrait orientation.




- 4 The screen shots and illustrations in this guide are those of the DocuPrint P255 dw unless otherwise specified. Some of the items in the screen shots and illustrations may not be displayed or available depending on your printer model.
- 5 Some features are not available on some models.

Safety Notes
























Before using this product, read “Safety Notes” carefully for safety use.

This product and recommended supplies have been tested and found to comply with strict safety requirements including safety agency approvals and compliance with environmental standards. Follow the following instructions for safety use.

 **WARNING:**

- Any unauthorized alteration including an addition of new functions or connection to external devices may not be covered by the product warranty. Contact your local Fuji Xerox representative for more information.

Follow all warning instructions marked on this product. The warning marks stand for the followings:

 DANGER	Used for item that if not followed strictly, can lead death or severe or fatal injuries and the possibility to do it is comparatively high.					
 WARNING	Used for items that if not followed strictly, can lead to severe or fatal injuries.					
 CAUTION	Used for items that if not followed strictly, can cause injuries to user or damages to machine.					
<p>: A symbol for items to pay attention to when handling machine. Follow instructions carefully to use machine safely.</p>						
 Caution	 Flammable	 Explodable	 Electric shock	 Heated surface	 Moving object	 Pinched fingers
<p>: A symbol for prohibited items. Follow instructions carefully to avoid any dangerous acts.</p>						
 Prohibited	 No fire	 Do not touch	 Do not use in bathroom	 Do not tear down	 Keep away from wet	 Never touch with wet hand
<p>: A symbol for items that must be performed. Follow instructions carefully to carry out these essential tasks.</p>						
 Instructions	 Unplug	 Ground/Earth				

■ Electrical Safety

WARNING

This product shall be operated by the power source as indicated on the product's data plate. Consult your local power company to check if your power source meets the requirements.



WARNING:

- **Connect this product to a protective earth circuit.**

This product is supplied with a plug that has a protective earth pin. The plug fits only into an earthed electrical outlet. This is a safety feature. If the plug doesn't fit to the outlet, contact an electrician to replace the outlet to avoid risk of electric shock. Never use an earthed adapter plug to connect the product to the electrical outlet that has no earth connection terminal.

Improper connection of a grounding conductor may cause electric shock.



Plug the power cord directly into a grounded electrical outlet. To prevent overheat and a fire accident, do not use an extension cord, a multi-plug adaptor or a multiple connector. Consult your local Fuji Xerox representative to check if an outlet is grounded.



Connect this product to a branch circuit or an outlet that has larger capacity than the rated ampere and voltage of this product. See the data plate on the rear panel of this product for its rated ampere and voltage.



Never touch the power cord with wet hands. It may cause electric shock.



Do not put an object on the power cord.



Always keep the plug connection free of dust. The dusty and damp environment may bring about minute electric current in a connector. It may generate heat and eventually cause a fire accident.



To avoid the risk of electric shock and a fire accident, only use the power cord supplied with this product or the ones designated by Fuji Xerox.

The power cord is exclusive use for this product. Do not use it for any other product.

Do not damage or alter the power cord. Damage and alteration may generate heat and eventually cause electric shock or a fire accident.

If the power cord is damaged or insulated wires are exposed, contact your local Fuji Xerox representative for its replacement. Do not use a damaged or uninsulated cord to avoid the risk of electric shock and a fire accident.

CAUTION



When cleaning this product, always switch off and unplug it. Access to a live machine interior may cause electric shock.



Do not unplug or re-plug this product with the switch on. Plugging and unplugging a live connector may deform the plug and generate heat, and eventually cause a fire accident.



Hold the plug not the cord when unplugging this product, or it may damage the cord and cause electric shock or a fire accident.



Always switch off and unplug the machine when it is not used over weekends or long holidays. It may cause deterioration of insulations and eventually electric shock or a fire accident.



Once a month, switch off this product and check if

- the power cord is plugged firmly into an electrical outlet;
- the plug is not excessively heated, rusted or bent;
- the plug and electrical outlet are free of dust; and
- the power cord is not cracked or worn down.

Once you notice any unusual condition, switch off and unplug this product first and contact your local Fuji Xerox representative.

■ Machine Installation

⚠ WARNING



Do not locate this product where people might step on or trip over the power cord.

Friction or excessive pressure may generate heat and eventually cause electric shock or a fire accident.

⚠ CAUTION



Never locate this product in the following places:

- Near radiators or any other heat sources
- Near volatile flammable materials such as curtains
- In the hot, humid, dusty or poorly ventilated environment
- In the place receiving direct sunlight
- Near cookers or humidifiers




Locate this product on a level and sturdy surface that can withstand a weight of 6.8 Kg. Otherwise, if tilted, the product may fall over and cause injuries.




Locate this product in a well-ventilated area. Do not obstruct ventilation openings of the product.

Keep the minimum clearance as follows for ventilation and an access to the power plug. Unplug the product if an abnormal condition is noted.





Do not incline the product at more than 1 degree angle. Otherwise, it may fall over and cause injuries.



To bundle wires and cables, always use the cable ties and spiral tubes that Fuji Xerox supplies. Otherwise, it may cause some defects.

Others



To keep this product in a good performance and condition, always use it in the following environment:

- Temperature: 10 – 32 °C
- Humidity: 10 – 85%

When the product is left in a chilly room and the room is rapidly warmed up by heater, dew condensation may form inside the product and cause a partial deletion on printing.

■ Operational Safety

WARNING



The operator's product maintenance procedures are described in the customer documentation supplied with this product. Do not carry out any other maintenance procedures not described in the documentation.



This product features safety design not to allow operators access to hazard areas. The hazard areas are isolated from operators by covers or protectors which require a tool to remove. To prevent electric shock and injuries, never remove those covers and protectors.



To avoid the risk of electric shock and a fire accident, switch off and unplug the product promptly in the following conditions, then contact your local Fuji Xerox representative.

- The product emits smoke or its surface is unusually hot.
- The product emits unusual noise or odor.
- The power cord is cracked or worn down.
- A circuit breaker, fuse or any other safety device becomes activated.
- Any liquid is spilled into the product.
- The product is soaked in water.
- Any part of the product is damaged.



Do not insert any object into slots or openings of this product.
Do not put any of the followings on the product:

- Liquid container such as flower vases or coffee cups
- Metal parts such as staples or clips
- Heavy objects

If liquid is spilled over or metal parts are slipped into the product, it may cause electric shock or a fire accident.



Do not use conductive paper such as origami paper, carbonic paper or conductively-coated paper. When paper jam occurs, it may cause short-circuit and eventually a fire accident.



When cleaning this product, use the designated cleaning materials exclusive to it. Other cleaning materials may result in poor performance of the product. Never use aerosol cleaners to avoid catching fire and explosion.



If you cannot remove the paper jam by doing the procedures in the manual, do not try to forcibly remove the jam. Doing so may cause injuries. Contact your local Fuji Xerox representative.



Never play the CD-ROM supplied with the product on an audio player. Always use a CD-ROM player. Otherwise, large sound may damage audio players or your ears.

CAUTION



Always follow all warning instructions marked on or supplied with this product.

To avoid the risk of burn injuries and electric shock, never touch the area with the "High Temperature" or "High Voltage" marks on.



Keep electrical and mechanical safety interlocks active. Keep the safety interlocks away from magnetic materials. Magnetic materials may accidentally activate the product and cause injuries or electric shock.



Do not attempt to remove a paper deeply jammed inside the product, particularly a paper wrapped around the fusing unit or the heat roller. Otherwise, it may cause injuries or burns. Switch off the product immediately and contact your local Fuji Xerox representative.



Ventilate well during extended operation or mass printing. It may affect the office air environment due to odor such as ozone in a poorly ventilated room.

Provide proper ventilation to ensure the comfortable and safe environment.

■ Consumable

WARNING



Store all consumables in accordance with the instructions given on its package or container.



Use a broom or a wet cloth to wipe off spilled toner. Never use a vacuum cleaner for the spills. It may catch fire by electric sparks inside the vacuum cleaner and cause explosion. If you spill a large volume of toner, contact your local Fuji Xerox representative.



Never throw a toner cartridge into an open flame. Remaining toner in the cartridge may catch fire and cause burn injuries or explosion.

If you have a used toner cartridge no longer needed, contact your local Fuji Xerox representative for its disposal.

CAUTION



Keep drum cartridges (or drum if not a cartridge type) and toner cartridges out of the reach of children. If a child accidentally swallows toner, spit it out, rinse mouth with water, drink water and consult a physician immediately.



When replacing drum cartridges (or drum if not a cartridge type) and toner cartridges, be careful not to spill the toner. In case of any toner spills, avoid contact with clothes, skin, eyes and mouth as well as inhalation.



If toner spills onto your skin or clothing, wash it off with soap and water.

If you get toner particles in your eyes, wash it out with plenty of water for at least 15 minutes until irritation is gone. Consult a physician if necessary.

If you inhale toner particles, move to a fresh air location and rinse your mouth with water.

If you swallow toner, spit it out, rinse your mouth with water, drink plenty of water and consult a physician immediately.




■ Warning and Caution Labels

Always follow all warning instructions marked on or supplied with this product.

To avoid the risk of burn injuries and electric shock, never touch the area with the "High Temperature" or "High Voltage" marks on.

NOTE:

- The following shows the toner cartridge label for DocuPrint P255 dw.



Environment

- For environmental protection and efficient use of resources, Fuji Xerox reuses returned toner cartridges and drums (photoreceptors) to make recycle parts, recycle materials or energy recovery.
- Proper disposal is required for toner cartridges no longer needed. Do not open toner cartridges. Return them to your local Fuji Xerox representative.

Regulation

■ Radio Frequency Emissions (Class B)



This product has been tested and found to comply with the limits for a Class B digital device, pursuant to the International Standard for Electromagnetic Interference (CISPR Publ. 22) and Radiocommunications Act 1992 in Australia/New Zealand. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning this product off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between this product and the receiver.
- Connect this product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes and modifications to this product not specifically approved by Fuji Xerox may void the user's authority to operate this product.

■ Product Safety Certification (UL, CB)

This product is certified by the following agency using the safety standards listed.

Standard

IEC60950-1:ed. 2

Illegal Copies and Printouts

Copying or printing certain documents may be illegal in your country. Penalties of fines or imprisonment may be imposed on those found guilty. The following are examples of items that may be illegal to copy or print in your country.


- Currency
- Banknotes and checks
- Bank and government bonds and securities
- Passports and identification cards
- Copyright material or trademarks without the consent of the owner
- Postage stamps and other negotiable instruments

This list is not inclusive and no liability is assumed for either its completeness or accuracy. In case of doubt, contact your legal counsel.

Product Features

This section describes the product features and indicates their links.


Duplex Print



When you have multiple pages to print, you can use the duplex feature of the computer to print on either side of paper to save paper consumption.

For more information, see ["Duplex Printing" on page 143](#).


Priority Sheet Inserter (PSI)



Print media loaded in the PSI is given precedence over the media in the paper tray. Using the PSI, you can print on print media of another type or size preferentially over the regular media in the paper tray.

For more information, see ["Loading Print Media in the Priority Sheet Inserter \(PSI\)" on page 134](#).


Multiple Up Print



With the Multiple Up print feature of the printer, you can print multiple pages on a single sheet of paper to save paper consumption.

For more information, see the print driver's help.

Wireless Print (DocuPrint P255 dw only)






With the wireless LAN feature of the printer, you can place your printer at any location and print from a computer without cabling.

For more information, see ["Configuring Wireless Network Settings \(DocuPrint P255 dw only\)" on page 62](#).

Specifications

This chapter lists the main specifications of the printer. Note that the specifications of the product may change without prior notice.

Items	Description
Product Code	DocuPrint P255 dw 110V: TL300673 DocuPrint P255 dw 220V: TL300674 DocuPrint P255 d 220V: TL300675 DocuPrint P255 dw 220V: TL300687
Type	Desktop
Printing Method	LED Xerography IMPORTANT: <ul style="list-style-type: none"> LED + LED electrophotographic system
Fusing System	Thermal fusing system using a belt
Warm-up Time	Less than 26 seconds (after powering on at 22 °C temperature)
Continuous Print Speed* ¹	A4  : When plain paper is fed from the paper tray 1 Sided* ² : 30 sheets/min IMPORTANT: * ¹ Print speed may decrease due to factors such as paper type, paper size, and printing conditions. * ² When continuously printing a single document of A4  .
First Print	7 seconds or less (PCL, A4  /Fed from the paper tray) IMPORTANT: <ul style="list-style-type: none"> The period of time required to finish printing the first page of a print job after the printer receives the start command while it is ready to print. The first print output time does not apply to a job received right after the printer exits Low Power or Sleep mode or it is turned on.
Resolution	Standard: 600 × 600 dpi High Resolution: 1200 × 1200 dpi* * When printing in high resolution mode, printing speed may be reduced due to image quality adjustment. Printing speed may also be reduced depending on documents.
Tone	256 tones

Items	Description
Paper Size	<p>Paper tray: A4, B5, A5, Letter (8.5 × 11"), Executive (7.25 × 10.5"), Folio (8.5 × 13"), Legal (8.5 × 14"), Statement, Com-10, Monarch, DL, C5, Yougata 2/3, Yougata 4/6, Nagagata 3/4, Younaga 3, Kakugata 3, Postcard (100 × 148 mm), W-Postcard (148 × 200 mm), Custom Paper (Width: 76.2 - 215.9 mm, Length: 127 - 355.6 mm)</p> <p>Priority Sheet Inserter (PSI): A4, B5, A5, Letter (8.5 × 11"), Executive (7.25 × 10.5"), Folio (8.5 × 13"), Legal (8.5 × 14"), Statement, Com-10, DL, C5, Yougata 4, Nagagata 3, Younaga 3, Kakugata 3, Custom Paper (Width: 76.2 - 215.9 mm, Length: 210 - 355.6 mm)</p> <p>Image loss: 4.1 mm from the top, bottom, left, and right edges</p>
Paper Type	<p>Paper tray: Plain (60 - 105 gsm), Lightweight Cardstock (106 - 163 gsm), Labels, Envelope, Recycled, Postcard JPN</p> <p>Priority Sheet Inserter (PSI): Plain (60 - 105 gsm), Lightweight Cardstock (106 - 163 gsm), Labels, Envelope, Recycled, Postcard JPN</p> <p>IMPORTANT:</p> <ul style="list-style-type: none"> • Fuji Xerox P paper (64 gsm) • Use only the recommended paper. Using paper other than that recommended for the printer can cause printing problems. For more information, see "Print Media That Can Damage Your Printer" on page 117. • Note that poor printing quality due to paper-related printing problems can occur when using the printer in an environment that is dry, cold, or very humid. • Printing over the printed side or on the reverse side of paper that already has been printed on can result in poor print quality. • When printing on envelopes, use envelopes that do not have adhesive applied. • The type of paper being used and environmental conditions can affect printing quality. Because of this, it is recommended that you test print and confirm proper print quality before using the printer.
Paper Weight	60 - 163 gsm
Paper Capacity	<p>Standard: Paper tray: 250 sheets Priority Sheet Inserter (PSI): 10 sheets</p> <p>IMPORTANT:</p> <ul style="list-style-type: none"> • Fuji Xerox P paper (64 gsm)
Output Tray Capacity	<p>Standard: approximately 125 sheets (face down)</p> <p>IMPORTANT:</p> <ul style="list-style-type: none"> • Fuji Xerox P paper (64 gsm)
2-sided Printing Feature	Standard
CPU	4305/300 MHz

Items	Description
Memory Capacity	Standard: 128 MB (Onboard) IMPORTANT: <ul style="list-style-type: none"> The above memory capacity does not guarantee print quality depending on the type and content of print data.
Hard Disk	—
Page Description Language	Standard: PCL 5e, PCL 6, PostScript Level3 Compatible, PDF, TIFF, JPEG
Supported OS ^{*1}	Windows [®] XP, Windows [®] XP x64 Edition, Windows Vista [®] , Windows Vista [®] x64 Edition, Windows Server [®] 2003, Windows Server [®] 2003 x64 Edition, Windows Server [®] 2008, Windows Server [®] 2008 x64 Edition, Windows Server [®] 2008 R2 x64 Edition, Windows [®] 7, Windows [®] 7 x64 Edition, Mac OS ^{®*2} , Linux OS ^{®*3} IMPORTANT: ^{*1} For the latest information about the supported operating systems, contact our Customer Support Center or your dealer. ^{*2} Mac OS [®] X 10.4.11/10.5.8 - 10.6, 10.7 are supported. ^{*3} Red Hat Enterprise Linux 5/6 Desktop (x86), SUSE Linux Enterprise Desktop 10/11 (x86), and Ubuntu 8/10 (x86) are supported.
Interface	Standard: USB 1.1/2.0 (Hi-Speed), Ethernet (10Base-T, 100Base-TX), IEEE802.11b/g (DocuPrint P255 dw only)
Power	AC 110 - 127 V ± 10%; 9 A; both 50/60 Hz AC 220 - 240 V ± 10%; 5 A; both 50/60 Hz IMPORTANT: <ul style="list-style-type: none"> Maximum machine measured current
Operating Noise	During operation: 7.37 B During stand-by: 4.3 B IMPORTANT: <ul style="list-style-type: none"> Measurements based on ISO7779 Unit B: acoustic power level (LwAd)
Power Consumption	In Sleep mode: 3.8 W or less Average: During standby: 50 W, During continuous printing: 450 W IMPORTANT: <ul style="list-style-type: none"> Low Power mode: 8 W average
Dimensions	385 (W) × 355.6 (D) [*] × 225 (H) mm IMPORTANT: [*] Measured when the paper tray is inserted.

Items	Description
Weight	6.8 kg (including consumables)
Usage Environment	<p>Temperature: 10 - 32 °C; Humidity: 10 - 85% (except malfunctions due to dew condensation)</p> <p>Non-Use: Temperature: -20 - 40 °C; Humidity: 5 - 85% (except malfunctions due to dew condensation)</p> <p>IMPORTANT:</p> <ul style="list-style-type: none"> • Until the conditions (temperature and humidity) inside the printer become acclimated to the installation environment, certain qualities of the paper can cause poor printing.

Basic Operation

This chapter includes:

- ["Main Components" on page 32](#)
- ["Turning On the Printer" on page 35](#)
- ["Printing the Panel Settings Page" on page 36](#)
- ["Power Saver Mode" on page 37](#)


Main Components

This section provides an overview of your printer.

This section includes:


- ["Front View" on page 32](#)
- ["Rear View" on page 33](#)
- ["Operator Panel" on page 34](#)

■ Front View



1	Front Cover	2	Output Tray Extension
3	Priority Sheet Inserter (PSI)	4	Center Output Tray
5	Operator Panel	6	Power Switch
7	Toner Cartridge	8	Paper Tray Cover
9	Paper Tray	10	Paper Width Guides
11	Toner Access Cover		


■ Rear View












1	USB Port	2	Rear Cover Handle
3	Levers	4	Ethernet Port
5	Power Connector	6	Rear Cover
7	Paper Chute	8	Transfer Roller
9	Registration Roller	10	OPC Drum

■ Operator Panel

The operator panel has a 2-line liquid crystal display (LCD), buttons, and LEDs.




- 1**  **(Energy Saver) Button/LED**
 - Lights up in the Sleep mode. Press this button to exit the Sleep mode.
- 2**  **Buttons**
 - Scrolls through menus or items in the Menu mode. To enter numbers or passwords, press these buttons.
- 3**  **Buttons**
 - Selects submenus or setting values in the Menu mode.
- 4**  **(Cancel Job) Button**
 - Cancels the current print job.
- 5**  **! (Error) LED**
 - Lights up when the printer has an error.
- 6**  **(Ready) LED**
 - Lights up when the printer is ready.
- 7**  **(Back) Button**
 - Switches to the print mode from the top menu of the Menu mode.
 - Returns to the upper hierarchy of the menu from the submenu of the Menu mode.
- 8**  **Button**
 - Displays the selected menu or item and determines the selected value in the Menu mode.
- 9** **LCD Panel**
 - Displays various settings, instructions, and error messages.
- 10**  **(Menu) Button**
 - Moves to the top menu.

Turning On the Printer


IMPORTANT:

- Do not use extension cords or power strips.
- Do not connect the printer to an uninterruptible power supply (UPS) system.

- 1 Connect one end of the power cord to the power connector on the rear of the printer (see "Rear View" on page 33).



- 2 Connect the other end to a power source.
- 3 Turn on the printer.



NOTE:

- When you turn on the printer for the first time, follow the on-screen instructions on the LCD panel to configure the initial settings of your printer.

Printing the Panel Settings Page

The Panel Settings page shows current settings on the operator panel menus.




This section includes:

- "The Operator Panel" on page 36
- "The Printer Setting Utility (Windows Only)" on page 36

■ The Operator Panel

NOTE:

- The reports and lists are all printed in English.

- 1 Press the  (**Menu**) button.
- 2 Select `Report/List`, and then press the  button.
- 3 Select `Panel Settings`, and then press the  button.
The Panel Settings page is printed.

■ The Printer Setting Utility (Windows Only)

The following procedure uses Microsoft Windows 7 as an example.

NOTE:

- The reports and lists are all printed in English.

- 1 Click **Start** → **All Programs** → **Fuji Xerox** → **Fuji Xerox Printer Software for Asia-Pacific** → your printer → **Printer Setting Utility**.


NOTE:

- The window to select a printer appears in this step when multiple print drivers are installed on your computer. In this case, click the name of the desired printer listed in **Printer Name**.

The Printer Setting Utility starts.

- 2 Click the **Printer Settings Report** tab.
- 3 Select **Reports** from the list at the left side of the page.
The **Reports** page is displayed.
- 4 Click the **Panel Settings** button.
The Panel Settings page is printed.

Power Saver Mode

The printer has a power saving feature that reduces power consumption during periods of inactivity and operates in two modes: Low Power and Sleep. In Low Power mode, only the LCD panel goes blank. In Sleep mode, all LEDs, except for the  (**Energy Saver**) LED, on the operator panel go out and the LCD panel goes blank. When the printer is in Sleep mode, it consumes less power than in Low Power mode.

By default, the printer enters Low Power mode in one minute of inactivity after completion of the last print job, and then enters Sleep mode in another six minutes of inactivity. You can change these default settings in the following ranges:


Low Power mode: 1 to 30 minutes

Sleep mode: 6 to 11 minutes



See also:

- ["Changing the Power Saver Mode Settings" on page 187](#)

■ Exiting the Power Saver Mode

The printer automatically exits the power saver mode when it receives a print job from a computer. Alternatively, you can manually bring it back to the ready-to-print state by pressing the  (**Energy Saver**) button. Whether the printer is in Low Power or Sleep mode, it will take about 25 seconds for the printer to resume the ready-to-print state.

NOTE:

- In Low Power mode, opening and closing the rear cover will bring the printer back to the ready-to-print state.
- When the printer is in Sleep mode, all buttons on the operator panel except for the  (**Energy Saver**) button do not function. To use the buttons on the operator panel, press the  (**Energy Saver**) button to exit the power saver mode.

See also:

- ["Changing the Power Saver Mode Settings" on page 187](#)

Printer Management Software

Use the *Software Pack CD-ROM* supplied with your printer to install a combination of software programs, depending on your operating system.

This chapter includes:

- ["Print Drivers" on page 40](#)
- ["CentreWare Internet Services" on page 41](#)
- ["Printer Setting Utility \(Windows Only\)" on page 42](#)
- ["SimpleMonitor \(Windows Only\)" on page 43](#)
- ["Launcher \(Windows Only\)" on page 44](#)
- ["User Setup Disk Creating Tool \(Windows Only\)" on page 45](#)

Print Drivers

To access all of your printer's features, install print drivers from the *Software Pack CD-ROM*. A printer driver enables communications between your computer and printer and provides access to your printer features.

See also:

- ["Installing Print Drivers on Computers Running Windows" on page 58](#)
- ["Installing Print Drivers on Computers Running Mac OS X" on page 97](#)

CentreWare Internet Services

This section provides information on the CentreWare Internet Services.

The CentreWare Internet Services is a hyper text transfer protocol (HTTP)-based web page service that is accessed through your web browser.

Using the CentreWare Internet Services, you can confirm the printer status, and change the printer configuration options easily. Anyone on your network can access the printer using the CentreWare Internet Services. In administrative mode, you can change the configuration of the printer and manage your printer settings without leaving your computer.

NOTE:

- Users who are not given passwords by the administrator can still view the configuration settings in user mode. They will not be able to save or apply any changes to the current configuration and settings.
- For details on the menu items of the CentreWare Internet Services, refer to the Help on the CentreWare Internet Services.

■ Creating an Administrative Password

- 1 Launch your web browser.
- 2 Enter the IP address of the printer in the address bar, and then press the **Enter** key.
- 3 Click the **Properties** tab.
- 4 In the left navigation panel, scroll down to **Security** and select **Administrator Settings**.
- 5 Select **Enabled** for **Administrator Mode**.
- 6 In the **Administrator Login ID** field, enter a name for the administrator.

NOTE:

- The default ID and password are “11111” and “x-admin” respectively.
- 7 In the **Administrator Password** and **Re-enter Password** fields, enter a password for the administrator.
 - 8 In the **Maximum Login Attempts** field, enter the number of login attempts allowed.
 - 9 Click **Apply**.
- Your new password has been set and anyone with the administrator name and password can log in and change the printer configuration and settings.

Printer Setting Utility (Windows Only)

The Printer Setting Utility allows you to view or specify the system settings. You can also diagnose the system settings with the Printer Setting Utility.

The Printer Setting Utility consists of the **Printer Settings Report**, **Printer Maintenance**, and **Diagnosis** tabs.

The Printer Setting Utility is installed along with print drivers.

NOTE:

- The **Password** dialog box appears the first time you attempt to change settings on Printer Setting Utility when the Panel Lock feature is enabled on the printer. In this case, enter the password you specified, and click **OK** to apply the settings.

SimpleMonitor (Windows Only)

You can check the printer status with the SimpleMonitor. Double-click the SimpleMonitor printer icon on the taskbar at the bottom right of the screen. The **Printer Selection** window appears, which displays the printer name, printer connection port, printer status, and model name. Check the column **Status** to know the current status of your printer.

Settings button: Displays the **Settings** window and allows you to modify the SimpleMonitor settings.

Click the name of the desired printer listed on the **Printer Selection** window. The **Printer Status** window appears.

The **Printer Status** window alerts you when there is a warning or when an error occurs, for example, when a paper jam occurs or toner is running low.

By default, the **Printer Status** window appears automatically when an error occurs. You can specify the conditions for starting the **Printer Status** window in **Printer Status Window Properties**.

To change the pop-up settings for the **Printer Status** window:

- 1 Right-click the SimpleMonitor printer icon on the taskbar at the bottom right of the screen.
- 2 Select **Printer Status Window Properties**.
The **Printer Status Window Properties** window appears.
- 3 Select the type of the pop-up and then click **OK**.

You can also check the toner level of your printer and the job information on the **Printer Status** window.

The SimpleMonitor is installed along with print drivers.

Launcher (Windows Only)

Using the **Launcher-Btype** window, you can open the **Status Window**, **Printer Setting Utility**, and **Troubleshooting**.


To use the Launcher, select to install the Launcher when you install print drivers.

The following procedure uses Windows 7 as an example.

To start the Launcher:

- 1 Click **Start** → **All Programs** → **Fuji Xerox** → **Fuji Xerox Printer Software for Asia-Pacific** → your printer → **Launcher**.

The **Launcher-Btype** window appears.



- 2 The **Launcher-Btype** window provides three buttons: **Status Window**, **Printer Setting Utility**, and **Troubleshooting**.

To exit, click the **X** button at the top-right of the window.

For more information, click the **Help** button/icon of each application.

Status Window	Opens the Printer Status window. See also: <ul style="list-style-type: none">• "SimpleMonitor (Windows Only)" on page 43
Printer Setting Utility	Starts the Printer Setting Utility. See also: <ul style="list-style-type: none">• "Printer Setting Utility (Windows Only)" on page 42
Troubleshooting	Opens the Troubleshooting guide, which allows you to resolve issues by yourself.

User Setup Disk Creating Tool (Windows Only)

You can use the User Setup Disk Creating Tool program in the **MakeDisk** folder within the **Utilities** folder and drivers in the respective folders of the *Software Pack CD-ROM* to create a driver installation package. A driver installation package can contain a group of print driver settings and other data for things such as:

- Print orientation and Multiple Up print (document settings)
- Watermarks

If you want to install the print driver with the same settings on multiple computers running on the same operating system, create a setup disk in a floppy disk or in a server on the network. Using the setup disk that you have created will reduce the amount of work required when installing the print driver.

- Install print drivers for your printer on the computer on which the setup disk is to be created.
- The setup disk can only be used on the operating system on which the disk was created or computers running the same operating system. Create a separate setup disk for each of the operating systems.

To create a setup disk, follow the procedure below. The procedure uses Windows 7 as an example.


- 1 Right-click the icon for your printer in the **Devices and Printers** folder and select **Printing preferences** to open the print driver window.
- 2 Specify the settings that you want to include in a driver installation package (for example, the **Multiple Up** setting on the **Layout** tab).
- 3 Insert the *Software Pack CD-ROM* into the CD/DVD drive and open the disc.

NOTE:


- If the **AutoPlay** window appears, click **Open folder to view files**.

- 4 Double-click **Utilities** → **MakeDisk** → your desired language.
- 5 Double-click **makedisk.exe**.

The **Creating Setup Disk** window appears.



- 6 Select your printer and click **Create Disk**.
The **Setup Disk Settings** window appears.




- 7 Enter a description of your printer settings in the **Comment** field and select an output port from the **Port** list box.

NOTE:

- Alternatively, you can click **Add Port** to create your desired port.
- Select the **Set as default printer** check box as needed.

- 8 Click **Create Setup Disk**.
The **Specifying Setup Disk Directory** window appears.



- 9 Enter the path to the destination folder directly into the **Destination folder** box or click **Browse** to select the folder.
- 10 Click **OK**.

Printer Connection and Software Installation

This chapter includes:

- ["Overview of Network Setup and Configuration" on page 48](#)
- ["Connecting Your Printer" on page 49](#)
- ["Setting the IP Address" on page 52](#)
- ["Installing Print Drivers on Computers Running Windows" on page 58](#)
- ["Installing Print Drivers on Computers Running Mac OS X" on page 97](#)
- ["Installing Print Drivers on Computers Running Linux \(CUPS\)" on page 103](#)

Overview of Network Setup and Configuration

To set up and configure the network:

- 1 Connect the printer to the network using the recommended hardware and cables.
- 2 Turn on the printer and the computer.
- 3 Print the System Settings page and keep it for referencing network settings.
- 4 Install the driver software on the computer from the *Software Pack CD-ROM*. For information on driver installation, see the section in this chapter for the specific operating system you are using.
- 5 Configure the printer's TCP/IP address, which is required to identify the printer on the network.
 - Microsoft Windows operating systems: Run the installer on the *Software Pack CD-ROM* to automatically set the printer's Internet Protocol (IP) address if you connect the printer to an established TCP/IP network. You can also manually set the printer's IP address on the operator panel.
 - Mac OS X and Linux systems: Manually set the printer's TCP/IP address on the operator panel. To use a wireless connection (DocuPrint P255 dw only), also configure wireless network settings on the operator panel.
- 6 Print the System Settings page to verify the new settings.

NOTE:

- The reports and lists are all printed in English.
- If the *Software Pack CD-ROM* is not available, you can download the latest driver from our web site: <http://www.fujixeroxprinters.com/>


See also:

- "Printing the System Settings Page" on page 156

Connecting Your Printer

The interface cables of your printer must meet the following requirements:

Connection Type	Connection Specifications
Ethernet	10 Base-T/100 Base-TX compatible
USB	USB 2.0 compatible
Wireless (DocuPrint P255 dw only)	IEEE 802.11b/802.11g



1 USB Port



2 Ethernet Port



■ Connecting Printer to a Computer or a Network

Connect your printer via a USB, Ethernet, or wireless (DocuPrint P255 dw only) connection. Hardware and cabling requirements vary for the different connection methods. Ethernet cables and hardware are not supplied with your printer and must be purchased separately.

The available features for each connection type are shown in the following table.


Connection Type	Available Features
USB	When connected via USB you can: <ul style="list-style-type: none">• Instruct print jobs from a computer.• Use the SimpleMonitor to check the printer status.
Ethernet	When connected via Ethernet you can: <ul style="list-style-type: none">• Instruct print jobs from a computer on the network.• Use the SimpleMonitor to check the printer status.
Wireless (DocuPrint P255 dw only)	When connected via wireless you can: <ul style="list-style-type: none">• Instruct print jobs from a computer on the network.• Use the SimpleMonitor to check the printer status.

USB Connection

If your printer is connected to a network instead of your computer, skip this section and go to "[Network Connection](#)" on page 51.

To connect the printer to a computer:

- 1 Connect the smaller end of the supplied USB cable to the USB port on the rear of the printer, and the other end to a USB port on the computer.




NOTE:

- Do not connect the printer USB cable to the USB connector available on the keyboard.

Network Connection

To connect the printer to an Ethernet network:

- 1 Ensure that the printer, computer and any other connected devices have been turned off and all cables have been disconnected.
- 2 Connect one end of an Ethernet cable to the Ethernet port on the rear of the printer, and the other end to a LAN drop or hub.



NOTE:

- Do not connect the Ethernet cable when you intend to use the wireless network feature of the DocuPrint P255 dw model.

See also:

- ["Configuring Wireless Network Settings \(DocuPrint P255 dw only\)" on page 62](#)

Setting the IP Address

This section includes:

- ["TCP/IP and IP Addresses" on page 52](#)
- ["Automatically Setting the Printer's IP Address" on page 52](#)
- ["Dynamic Methods of Setting the Printer's IP Address" on page 53](#)
- ["Assigning an IP Address \(for IPv4 Mode\)" on page 54](#)
- ["Verifying the IP Settings" on page 56](#)
- ["Printing and Checking the System Settings Page" on page 56](#)

■ TCP/IP and IP Addresses

If your computer is on a large network, contact your network administrator for the appropriate TCP/IP addresses and additional system settings information.

If you are creating your own small Local Area Network or connecting the printer directly to your computer using Ethernet, follow the procedure for automatically setting the printer's IP address.

Computers and printers primarily use TCP/IP protocols to communicate over an Ethernet network. With TCP/IP protocols, each printer and computer must have a unique IP address. It is important that the addresses are similar, but not the same; only the last digit needs to be different. For example, your printer can have the address 192.168.1.2 while your computer has the address 192.168.1.3. Another device can have the address 192.168.1.4.

Many networks have a Dynamic Host Configuration Protocol (DHCP) server. A DHCP server automatically programs an IP address into every computer and printer on the network that is configured to use DHCP. A DHCP server is built into most cable and Digital Subscriber Line (DSL) routers. If you use a cable or DSL router, see your router's documentation for information on IP addressing.

■ Automatically Setting the Printer's IP Address

If the printer is connected to a small established TCP/IP network without a DHCP server, use the installer on the *Software Pack CD-ROM* to detect or assign an IP address to your printer. For further instructions, insert the *Software Pack CD-ROM* into your computer's CD/DVD drive. After the Installer starts, follow the prompts for installation.

NOTE:

- For the automatic installer to function, the printer must be connected to an established TCP/IP network.




■ Dynamic Methods of Setting the Printer's IP Address

There are two protocols available for dynamically setting the printer's IP address:

- DHCP
- DHCP/Auto IP (enabled by default)








You can turn on/off either protocol using the operator panel, or use the CentreWare Internet Services to turn on/off the DHCP protocol.

NOTE:

- You can print a report that includes the printer's IP address. On the operator panel, press the  (**Menu**) button, select `Report/List`, press the  button, select `System Settings`, and then press the  button. The IP address is listed on the System Settings page.

Using the Operator Panel

To turn on/off either the DHCP or the AutoIP protocol:

- 1 On the operator panel, press the  (**Menu**) button.
- 2 Select `Admin Menu`, and then press the  button.
- 3 Select `Network`, and then press the  button.
- 4 Select `TCP/IP`, and then press the  button.
- 5 Select `IPv4`, and then press the  button.
- 6 Select `Get IP Address`, and then press the  button.
- 7 Select `DHCP/AutoIP` or `DHCP`, and then press the  button.

Using the CentreWare Internet Services

To turn on/off the DHCP protocol:

- 1 Launch your web browser.
- 2 Enter the IP address of the printer in the address bar, and then press the **Enter** key. The CentreWare Internet Services appear on your browser.
- 3 Select **Properties**.
- 4 Select **TCP/IP** from the **Protocol Settings** folder on the left navigation panel.
- 5 In the **IP Address Mode** field, select the **DHCP/AutoIP** option.
- 6 Click the **Apply** button.






















■ Assigning an IP Address (for IPv4 Mode)


NOTE:

- When you assign an IP address manually in **IPv6** mode, use the CentreWare Internet Services. To display the CentreWare Internet Services, use the link local address. To check a link local address, see ["Printing and Checking the System Settings Page" on page 56](#).
- Assigning an IP address is considered as an advanced function and is normally done by a system administrator.
- Depending on the address class, the range of the IP address assigned may be different. On Class A, for example, an IP address in the range from 0.0.0.0 to 127.255.255.255 will be assigned. For assignment of IP addresses, contact your system administrator.

You can assign the IP address by using the operator panel or the Printer Setting Utility.

Using the Operator Panel

- 1 Turn on the printer.
Ensure that the LCD panel shows `Ready to Print`.
- 2 On the operator panel, press the  (**Menu**) button.
- 3 Select `Admin Menu`, and then press the  button.
- 4 Select `Network`, and then press the  button.
- 5 Select `TCP/IP`, and then press the  button.
- 6 Select `IPv4`, and then press the  button.
- 7 Select `Get IP Address`, and then press the  button.
- 8 Select `Panel`, and then press the  button.
- 9 Press the  (**Back**) button, and then ensure that `Get IP Address` is selected.
- 10 Select `IP Address`, and then press the  button.
- 11 Enter the value of the IP address using the  or  button.
- 12 Press the  button.
- 13 Repeat steps **11** and **12** to enter all of the digits in the IP address, and then press the  button.
- 14 Press the  (**Back**) button, and then ensure that `IP Address` is selected.
- 15 Select `Subnet Mask`, and then press the  button.
- 16 Enter the value of the subnet mask using the  or  button.
- 17 Press the  button.
- 18 Repeat steps **16** and **17** to set subnet mask, and then press the  button.
- 19 Press the  (**Back**) button, and then ensure that `Subnet Mask` is selected.
- 20 Select `Gateway Address`, and then press the  button.

- 21 Enter the value of the gateway address using the ▲ or ▼ button.
- 22 Press the ► button.
- 23 Repeat steps 21 and 22 to set gateway address, and then press the  button.
- 24 Turn off and turn on the printer.

See also:

- "Operator Panel" on page 34

Using the Printer Setting Utility (Windows Only)

The following procedure uses Windows 7 as an example.

NOTE:

- When you use IPv6 mode for network printing, you cannot use the Printer Setting Utility to assign an IP address.

- 1 Click **Start** → **All Programs** → **Fuji Xerox** → **Fuji Xerox Printer Software for Asia-Pacific** → your printer → **Printer Setting Utility**.

NOTE:

- The window to select a printer appears in this step when multiple print drivers are installed on your computer. In this case, click the name of the desired printer listed in **Printer Name**.

The Printer Setting Utility starts.

- 2 Click the **Printer Maintenance** tab.
- 3 Select **TCP/IP Settings** from the list at the left side of the page.
The **TCP/IP Settings** page is displayed.
- 4 Select **Panel** from **IP Address Mode**, and then enter the values in **IP Address**, **Subnet Mask**, and **Gateway Address**.
- 5 Click the **Restart printer to apply new settings** button to take effect.

The IP address is assigned to your printer. To verify the setting, display the web browser on any computer connected to the network and enter the IP address into the address bar on the browser. If the IP address is set up correctly, the CentreWare Internet Services appears on your browser.

You can also assign the IP address to the printer when installing the print drivers with installer. When you use the network installation feature, and the `Get IP Address` is set to `DHCP` or `DHCP/AutoIP` on the operator panel menus, you can set the IP address from `0.0.0.0` to the desired IP address on the printer selection window.

■ Verifying the IP Settings

The following procedure uses Windows 7 as an example.

NOTE:

- The reports and lists are all printed in English.

- 1 Print the System Settings page.
- 2 Look under the **IPv4** heading on the System Settings page to ensure that the IP address, subnet mask, and gateway address are appropriate.

To verify if the printer is active on the network, run the ping command in your computer:

- 1 Click **Start**, and select **Search programs and files**.
- 2 Enter **cmd**, and then press the **Enter** key.
A black window appears.
- 3 Enter **ping xx.xx.xx.xx** (where **xx.xx.xx.xx** is the IP address of your printer), and then press the **Enter** key.
- 4 Reply from the IP address denotes printer is active on the network.

See also:

- ["Printing and Checking the System Settings Page" on page 56](#)

■ Printing and Checking the System Settings Page

Print the System Settings page and check your printer's IP address.




This section includes:

- ["Using the Operator Panel" on page 56](#)
- ["Using the Printer Setting Utility \(Windows Only\)" on page 57](#)

Using the Operator Panel

NOTE:

- The reports and lists are all printed in English.

- 1 Press the  (**Menu**) button.
- 2 Select **Report/List**, and then press the  button.
- 3 Select **System Settings**, and then press the  button.
The System Settings page is printed.
- 4 Confirm the IP address next to **IP Address** under **Wired Network** (DocuPrint P255 d) or **Wired Network/Wireless Network** (DocuPrint P255 dw) on the System Settings page. If the IP address is **0.0.0.0**, wait for a few minutes to resolve the IP address automatically, and then print the System Settings page again.

If the IP address is not resolved automatically, see ["Assigning an IP Address \(for IPv4 Mode\)" on page 54](#).

Using the Printer Setting Utility (Windows Only)

The following procedure uses Windows 7 as an example.

NOTE:

- The reports and lists are all printed in English.

- 1 Click **Start** → **All Programs** → **Fuji Xerox** → **Fuji Xerox Printer Software for Asia-Pacific** → your printer → **Printer Setting Utility**.

NOTE:

- The window to select a printer appears in this step when multiple print drivers are installed on your computer. In this case, click the name of the desired printer listed in **Printer Name**.

The Printer Setting Utility starts.

- 2 Click the **Printer Settings Report** tab.
- 3 Select **Reports** from the list at the left side of the page.
The **Reports** page appears.
- 4 Click the **System Settings** button.

The System Settings page is printed.

If the IP address is **0.0.0.0** (the factory default) or **169.254.xx.xx**, an IP address has not been assigned.

See also:

- ["Assigning an IP Address \(for IPv4 Mode\)" on page 54](#)

Installing Print Drivers on Computers Running Windows

You can use three types of print drivers on your printer: PCL, PostScript Level3 Compatible, and XML Paper Specification print drivers. This section provides information on the PCL print driver.

For information on the other drivers, see the following:

PostScript Level3 Compatible print driver: *PostScript Level3 Compatible User Guide*

XML Paper Specification print driver: ["Using the XML Paper Specification Print Driver" on page 96](#)

This section includes:

- ["Identifying Print Driver Pre-install Status \(for Network Connection Setup\)" on page 59](#)
- ["Inserting the Software Pack CD-ROM" on page 60](#)
- ["USB Connection Setup" on page 60](#)
- ["Network Connection Setup" on page 61](#)
- ["Configuring Wireless Network Settings \(DocuPrint P255 dw only\)" on page 62](#)
- ["Setting Up the Printer for Shared Printing" on page 87](#)
- ["Using the XML Paper Specification Print Driver" on page 96](#)

■ Identifying Print Driver Pre-install Status (for Network Connection Setup)

Before installing print drivers on your computer, print the System Settings page to check the IP address of your printer.




This section includes:

- ["Using the Operator Panel" on page 59](#)
- ["Using the Printer Setting Utility" on page 59](#)
- ["Disabling the Firewall Before Installing Printer Drivers" on page 60](#)

Using the Operator Panel

NOTE:

- The reports and lists are all printed in English.

- 1 Press the  (**Menu**) button.
- 2 Select `Report/List`, and then press the  button.
- 3 Select `System Settings`, and then press the  button.
The System Settings page is printed.
- 4 Find the IP address under **Wired Network** (DocuPrint P255 d) or **Wired Network/Wireless Network** (DocuPrint P255 dw) on the System Settings page.
If the IP address is **0.0.0.0**, wait for a few minutes to resolve the IP address automatically, and then print the System Settings page again.
If the IP address is not resolved automatically, see ["Assigning an IP Address \(for IPv4 Mode\)" on page 54](#).

Using the Printer Setting Utility

The following procedure uses Windows 7 as an example.

NOTE:

- The reports and lists are all printed in English.

- 1 Click **Start** → **All Programs** → **Fuji Xerox** → **Fuji Xerox Printer Software for Asia-Pacific** → your printer → **Printer Setting Utility**.

NOTE:

- The window to select a printer appears in this step when multiple print drivers are installed on your computer. In this case, click the name of the desired printer listed in **Printer Name**.

The Printer Setting Utility starts.

- 2 Click the **Printer Settings Report** tab.
- 3 Select **TCP/IP Settings** from the list on the left side of the page.
The **TCP/IP Settings** page is displayed.

If the IP address shows **0.0.0.0** (the factory default) or **169.254.xx.xx**, an IP address has not been assigned. To assign one for your printer, see ["Assigning an IP Address \(for IPv4 Mode\)" on page 54](#).

Disabling the Firewall Before Installing Printer Drivers

If you are running one of the following operating systems, you must disable the firewall before installing print drivers:

- Windows 7
- Windows Vista
- Windows Server 2008 R2
- Windows Server 2008
- Windows XP

The following procedure uses Windows 7 as an example.

- 1 Click **Start** → **Help and Support**.

NOTE:

- For Windows Vista, Windows Server 2008, Windows Server 2008 R2 and Windows 7 operating systems, if you use **Online Help**, switch to **Offline Help** on **Windows Help and Support** window.

- 2 In the **Search Help** box, enter **firewall** and then press the **Enter** key.
In the list, click **Turn Windows Firewall on or off** and then follow the instructions on the screen.
Enable the firewall after the installation of the printer software is complete.

■ Inserting the Software Pack CD-ROM

- 1 Insert the *Software Pack CD-ROM* into your computer's CD/DVD drive. When the **AutoPlay** window appears, click **Run setup.exe** to start the **Easy Install Navi**.

NOTE:

- If the CD does not automatically start or the **AutoPlay** window does not appear, click **Start** (**start** for Windows XP) → **Computer** → **D:\setup.exe** (where D is the drive letter of your CD), and then click **OK**.

■ USB Connection Setup

The following procedure uses Windows 7 as an example.

- 1 Connect your computer and printer with a USB cable.
- 2 Turn on the printer.
- 3 Click **Installing Drivers and Software**.
- 4 Select **Personal Installation**, and then click **Next**.
- 5 If you agree to the terms of the **License Agreement**, click **I accept the terms of the license agreement** to continue the installation process, and then click **Next**.
- 6 Select whether to restart your computer and click **Finish** to exit the wizard.

• USB Printing

A personal printer is a printer connected to your computer or a print server using a USB. If your printer is connected to a network and not to your computer, see "[Network Connection Setup](#)" on page 61.

■ Network Connection Setup

NOTE:

- To use your printer in a Linux environment, you need to install print drivers for the Linux operating systems. For details on how to install and use the drivers, see also "[Installing Print Drivers on Computers Running Linux \(CUPS\)](#)" on page 103.
- When using a CD drive in a Linux environment, you need to mount the drive to your system environment. The command strings are mount/media/CD-ROM.

The following procedure uses Windows 7 as an example.

- 1 Click **Installing Drivers and Software**.
- 2 Select **Network Installation**, and then click **Next**.
- 3 If you agree to the terms of the **License Agreement**, click **I accept the terms of the license agreement** to continue the installation process, and then click **Next**.
- 4 Select the printer you want to install from the printer list, and then click **Next**. If the target printer is not displayed on the list, click **Refresh** to refresh the list or click **Add Printer** to add a printer to the list manually. You may specify the IP address and port name at this point.
If you have installed this printer on the server computer, select **I am setting up this printer on a server** check box.

NOTE:

- If the installer displays **0.0.0.0** when you intend to use the **AutoIP** feature, you must enter a valid IP address to continue.
- 5 Specify the printer settings, and then click **Next**.
 - a Enter the printer name.
 - b If you want other users on the network to access this printer, select **Share this printer with other computers on the network**, and then enter a share name that users can identify.
 - c If you want to set a printer as the default for printing, select the **Set this printer as default for printing** check box.
 - 6 Select the software and documentation you want to install, and then click **Install**. You can specify folders in which to install the software and documentation. To change the folders, click **Browse**.
 - 7 Click **Finish** to exit the wizard.

■ Configuring Wireless Network Settings (DocuPrint P255 dw only)

You can configure wireless network settings with the **Easy Install Navi**.

IMPORTANT:

- Be sure to obtain the SSID and security information from a system administrator in advance when you use a communications standard other than WPS to configure wireless network settings.
- Ensure that the Ethernet cable has been disconnected from the printer before you configure the wireless network settings.

The wireless network specifications are described below:

Item	Specification
Connectivity	Wireless
Connectivity Standard	IEEE 802.11b/g compliant
Bandwidth	2.4 GHz
Data Transfer Rate	IEEE 802.11b mode: 11, 5.5, 2, 1 Mbps IEEE 802.11g mode: 54, 48, 36, 24, 18, 12, 9, 6 Mbps
Security	64 (40-bit key)/ 128 (104-bit key) WEP, WPA-PSK (TKIP, AES), WPA2-PSK (AES)(IEEE802.1x attestation function of WPA 1x non-corresponds)
Certifications	Wi-Fi, WPA2.0 (Personal)
Wi-Fi Protected Setup (WPS)	Push Button Configuration (PBC), Personal Identification Number (PIN)

You can select a method to configure wireless network settings from the following:

Wizard Setup Through USB Connection	
Advanced Setup Through	Ethernet connection
	Operator Panel
	CentreWare Internet Services
	WPS-PIN ^{*1}
	WPS-PBC ^{*2}

^{*1} WPS-PIN (Wi-Fi[®] Protected Setup-Personal Identification Number) is a method to authenticate and register devices required for wireless configuration, by entering PIN code in the printer and computer. This setting, performed through access point, is available only when the access points of your wireless router supports WPS.

^{*2} WPS-PBC (Wi-Fi Protected Setup-Push Button Configuration) is a method to authenticate and register devices required for wireless configuration, by pressing the button provided on the access point via wireless routers, and then performing WPS-PBC setting on the operator panel. This setting is available only when the access point supports WPS.

This section includes:

- ["Using Wizard Setup to Configure Wireless Network Settings" on page 63](#)
- ["Using Advanced Setup to Configure Wireless Network Settings" on page 68](#)
- ["Setting Up a New Wireless Network Environment for Your Computer \(When You Need to Set Up Your Wireless Connectivity With Your Computer\)" on page 78](#)

Using Wizard Setup to Configure Wireless Network Settings


The following procedure uses Windows 7 as an example.

- 1 Insert the *Software Pack CD-ROM* into your computer's CD/DVD drive. When the **AutoPlay** window appears, click **Run setup.exe** to start the **Easy Install Navi**.



- 2 Click **Start Setup**.
- 3 Click **Connect Your Printer**.
The connection type selection screen appears.
- 4 Select **Wireless Connection**, and then click **Next**.
The setting method selection screen appears.

- 5 Ensure that **Wizard** is selected, and then click **Next**.




- 6 Follow the on-screen instructions to connect the USB cable and perform other setup until the **Printer Setup Utility** screen appears.

- 7 Select either of the following:

- Click the **Select from the found Access Points** radio button and select the SSID.
- Click the **Input the SSID directly** radio button and enter the SSID in the **SSID** box.

- 8 Click **Next**.



- 9 Select **Type of wireless network**.

- 10 Configure the security setting, and then click **Next**.

The **IP Address Settings** screen appears.


11 Select **IP Mode** depending on your network scheme.

When **IPv4** is selected, configure the following:

- a** Select **Type**.
- b** If you have selected **Use Manual Address** from **Type**, enter the following items:
 - **IP Address** of your printer
 - **Subnet Mask**
 - **Gateway Address**


When **Dual Stack** is selected, configure the following:

- a** Configure **IPv4 Settings**.
- b** If you have selected the **Use Manual Address** check box under **IPv6 Settings**, enter the following items:
 - **IP Address** of your printer
 - **Gateway Address**




12 Click **Next**.

The **Confirm the settings** screen appears.




13 Ensure that the wireless network settings are displayed, and then click **Apply**.

A confirmation window appears.



14 Click **Yes**.

15 Wait a few minutes until the printer restarts to establish a wireless network connection and the **Configuration Complete** screen appears.



16 Click **Print Printer Setting**.

17 Confirm that "Link Quality" is shown as "Good", "Acceptable", or "Low" on the report.

NOTE:


- When "Link Quality" is shown as "No Reception", check if the wireless network settings are correctly configured. To reconfigure the wireless network settings, click **Next** on the **Configuration Complete** screen and then click **Return**.

18 Click **Next**.

19 Follow the on-screen instructions until the **Check Setup** screen appears.

20 Confirm there are no errors displayed on the LCD panel, and then click **Start Installation**.

If you see any errors, click **Trouble Shooting Guide** and follow the instruction.



21 If you agree to the terms of the **License Agreement**, click **I accept the terms of the license agreement** to continue the installation process, and then click **Next**.

22 Check if the printer to be installed is listed in the **Select Printer** screen, and then click **Next**.

NOTE:

- If the printer to be installed is not listed in the **Select Printer** screen, try the following steps:
 - Click **Refresh** to update the information.
 - Click **Add Printer**, and then enter the details of the printer manually.

23 Select the required items on the **Enter Printer Settings** screen, and then click **Next**.

24 Select the software to be installed, and then click **Install**.

25 Click **Finish** to exit this tool.

The wireless configuration is complete.

Using Advanced Setup to Configure Wireless Network Settings

To use the Advanced setup, display the **Configure Wireless Settings** screen.

The following procedure uses Windows 7 as an example.

• Displaying the Configure Wireless Settings Screen

- 1 Insert the *Software Pack CD-ROM* into your computer's CD/DVD drive. When the **AutoPlay** window appears, click **Run setup.exe** to start the **Easy Install Navi**.



- 2 Click **Start Setup**.
- 3 Click **Connect Your Printer**.
- 4 Select **Wireless Connection**, and then click **Next**.
The setting method selection screen appears.

5 Select **Advanced**.



- **Select a connection method from the following**

- "Ethernet Cable" on page 70
- "WPS-PIN" on page 74
- "WPS-PBC" on page 75
- "Operator Panel" on page 76
- "CentreWare Internet Services" on page 77


- **Ethernet Cable**

- 1 Select **Ethernet Cable**, and then click **Next**.
- 2 Follow the on-screen instructions, and then click **Next**.
The **Printer Setup Utility** screen appears.
- 3 Select the printer to be configured in the **Select Printer** screen, and then click **Next**.

NOTE:

- If the printer to be configured is not listed in the **Select Printer** screen, try the following steps:
 - Click **Refresh** to update the information.
 - Click **Enter IP Address**, and then enter the IP address of your printer.

- 4 Enter the SSID.



- 5 Select **Type of wireless network**.
- 6 Configure the security setting, and then click **Next**.
The **IP Address Settings** screen appears.


7 Select **IP Mode** depending on your network scheme.

When **IPv4** is selected, configure the following:

- a Select **Type**.
- b If you have selected **Use Manual Address** from **Type**, enter the following items:
 - **IP Address** of your printer
 - **Subnet Mask**
 - **Gateway Address**


When **Dual Stack** is selected, configure the following:

- a Configure **IPv4 Settings**.
- b If you have selected the **Use Manual Address** check box under **IPv6 Settings**, enter the following items:
 - **IP Address** of your printer
 - **Gateway Address**




8 Click **Next**.

The **Confirm the settings** screen appears.




9 Ensure that the wireless network settings are displayed, and then click **Apply**.

A confirmation window appears.



10 Click **Yes**.

11 Wait a few minutes until the printer restarts to establish a wireless network connection and the **Configuration Complete** screen appears.



12 Click **Next**.

13 Follow the on-screen instructions until the **Check Setup** screen appears.

14 Print the System Settings page using the operator panel.

See "Printing the System Settings Page" on page 156.


15 Confirm that "Link Quality" is shown as "Good", "Acceptable", or "Low" on the report.

NOTE:

- When "Link Quality" is shown as "No Reception", check if the wireless network settings are correctly configured. To reconfigure the wireless network settings, click **Return**.

16 Confirm there are no errors displayed on the LCD panel, and then click **Start Installation**.

If you see any errors, click **Trouble Shooting Guide** and follow the instruction.



17 If you agree to the terms of the **License Agreement**, click **I accept the terms of the license agreement** to continue the installation process, and then click **Next**.

18 Check if the printer to be installed is listed in the **Select Printer** screen, and then click **Next**.

NOTE:

- If the printer to be installed is not listed in the **Select Printer** screen, try the following steps:
 - Click **Refresh** to update the information.
 - Click **Add Printer**, and then enter the details of the printer manually.

19 Configure the required items on the **Enter Printer Settings** screen, and then click **Next**.

20 Select the software to be installed, and then click **Install**.

21 Click **Finish** to exit this tool.


The wireless configuration is complete.

• WPS-PIN

NOTE:

- **WPS-PIN** (Wi-Fi Protected Setup-Personal Identification Number) is a method to authenticate and register devices required for wireless configuration, by entering PIN code to a printer and computer. This setting, performed through access point, is available only when the access points of your wireless router supports WPS.
- Before **WPS-PIN** starts, you will need to enter your PIN code at the web page of the wireless access point. See the access point manual for the details.

- 1 Select **WPS-PIN**, and then click **Next**.
- 2 Follow the on-screen instructions until the **Check Setup** screen appears.
- 3 Confirm there are no errors displayed on the LCD panel, and then click **Start Installation**.
If you see any errors, click **Trouble Shooting Guide** and follow the instruction.



- 4 If you agree to the terms of the **License Agreement**, click **I accept the terms of the license agreement** to continue the installation process, and then click **Next**.
- 5 Check if the printer to be installed is listed in the **Select Printer** screen, and then click **Next**.

NOTE:

- If the printer to be installed is not listed in the **Select Printer** screen, try the following steps:
 - Click **Refresh** to update the information.
 - Click **Add Printer**, and then enter the details of the printer manually.

- 6 Configure the required items on the **Enter Printer Settings** screen, and then click **Next**.
- 7 Select the software to be installed, and then click **Install**.
- 8 Click **Finish** to exit this tool.

The wireless configuration is complete.


When the **WPS-PIN** operation is successful and the printer is rebooted, wireless LAN connection is completed.

• WPS-PBC

NOTE:

- **WPS-PBC** (Wi-Fi Protected Setup-Push Button Configuration) is a method to authenticate and register devices required for wireless configuration, by pressing the button provided on the access point via wireless routers, and then performing **WPS-PBC** setting on the operator panel. This setting is available only when the access point supports WPS.

- 1 Select **WPS-PBC**, and then click **Next**.
- 2 Follow the on-screen instructions until the **Check Setup** screen appears.
- 3 Confirm there are no errors displayed on the LCD panel, and then click **Start Installation**.
If you see any errors, click **Trouble Shooting Guide** and follow the instruction.



- 4 If you agree to the terms of the **License Agreement**, click **I accept the terms of the license agreement** to continue the installation process, and then click **Next**.
- 5 Check if the printer to be installed is listed in the **Select Printer** screen, and then click **Next**.

NOTE:

- If the printer to be installed is not listed in the **Select Printer** screen, try the following steps:
- Click **Refresh** to update the information.
 - Click **Add Printer**, and then enter the details of the printer manually.

- 6 Configure the required items on the **Enter Printer Settings** screen, and then click **Next**.
- 7 Select the software to be installed, and then click **Install**.
- 8 Click **Finish** to exit this tool.
The wireless configuration is complete.


NOTE:

- For the **WPS-PBC** operation on the wireless LAN access point, refer to the manual supplied with the wireless LAN access point.

When the **WPS-PBC** operation is successful and the printer is rebooted, wireless LAN connection is completed.

• Operator Panel

- 1 Select **Operator Panel**, and then click **Next**.
- 2 Follow the on-screen instructions until the **Check Setup** screen appears.
- 3 Confirm there are no errors displayed on the LCD panel, and then click **Start Installation**.
If you see any errors, click **Trouble Shooting Guide** and follow the instruction.



- 4 If you agree to the terms of the **License Agreement**, click **I accept the terms of the license agreement** to continue the installation process, and then click **Next**.
- 5 Check if the printer to be installed is listed in the **Select Printer** screen, and then click **Next**.


NOTE:

- If the printer to be installed is not listed in the **Select Printer** screen, try the following steps:
 - Click **Refresh** to update the information.
 - Click **Add Printer**, and then enter the details of the printer manually.

- 6 Configure the required items on the **Enter Printer Settings** screen, and then click **Next**.
- 7 Select the software to be installed, and then click **Install**.
- 8 Click **Finish** to exit this tool.
The wireless configuration is complete.

• CentreWare Internet Services

- 1 Select **CentreWare Internet Services**, and then click **Next**.
- 2 Follow the on-screen instructions until the **Check Setup** screen appears.
- 3 Confirm there are no errors displayed on the LCD panel, and then click **Start Installation**.
If you see any errors, click **Trouble Shooting Guide** and follow the instruction.



- 4 If you agree to the terms of the **License Agreement**, click **I accept the terms of the license agreement** to continue the installation process, and then click **Next**.
- 5 Check if the printer to be installed is listed in the **Select Printer** screen, and then click **Next**.

NOTE:

- If the printer to be installed is not listed in the **Select Printer** screen, try the following steps:
 - Click **Refresh** to update the information.
 - Click **Add Printer**, and then enter the details of the printer manually.

- 6 Configure the required items on the **Enter Printer Settings** screen, and then click **Next**.
- 7 Select the software to be installed, and then click **Install**.
- 8 Click **Finish** to exit this tool.

The wireless configuration is complete.

When the CentreWare Internet Services operation is successful and the printer is rebooted, wireless LAN connection is completed.

Setting Up a New Wireless Network Environment for Your Computer (When You Need to Set Up Your Wireless Connectivity With Your Computer)

• For DHCP Networks:

1 Setting up your computer for wireless connectivity:

NOTE:

- You can also change the wireless network settings using the wireless application that may be installed on your computer.

For Windows XP and Windows Server 2003:

- a Select **Network Connections** from **Control Panel**.
- b Right-click **Wireless Network Connection** and select **Properties**.
- c Select the **Wireless Networks** tab.
- d Ensure that the check box for **Use Windows to configure my wireless network settings** is selected.


NOTE:

- Make note of the wireless network settings on the **Advanced** dialog box (step **f**) and the **Wireless network properties** dialog box (step **h**). You may require these settings later.
- e Click the **Advanced** button.
 - f Select **Computer-to-computer (ad hoc) networks only** and close the **Advanced** dialog box.
 - g Click the **Add** button to display **Wireless network properties**.

- h On the **Association** tab, enter the following information and click **OK**.
Network name (SSID): xxxxxxxx (xxxxxxx indicates a wireless device's SSID which you use)

Network Authentication: Open

Data encryption: Disabled



- i Click the **Move up** button to move the newly added SSID to the top of the list.
- j Click **OK** to close the **Wireless Network Connection Properties** dialog box.

For Windows Vista:

- a Display **Control Panel**.
- b Select **Network and Internet**.
- c Select **Network and Sharing Center**.
- d Select **Connect to a network**.
- e Select **xxxxxxx** (xxxxxxx indicates a wireless device's SSID which you use) from the network items listed in the available network list, and click **Connect**.
- f Click **Close** in the dialog box after confirming the connection is a success.







For Windows Server 2008:

- a Display **Control Panel**.
- b Select **Network and Internet**.
- c Select **Network and Sharing Center**.
- d Select **Connect to a network**.
- e Select **xxxxxxx** (xxxxxxx indicates a wireless device's SSID which you use) from the network items listed in the available network list, and click **Connect**.
- f Click **Close** in the dialog box after confirming the connection is a success.

For Windows Server 2008 R2 and Windows 7:


- a Display **Control Panel**.
- b Select **Network and Internet**.
- c Select **Network and Sharing Center**.
- d Select **Connect to a network**.
- e Select **xxxxxxx** (xxxxxxx indicates a wireless device's SSID which you use) from the network items listed in the available network list, and click **Connect**.

2 Check the IP address assigned by AutoIP on the printer.

- a On the operator panel, press the  (**Menu**) button.
- b Select **Admin Menu**, and then press the  button.
- c Select **Network**, and then press the  button.
- d Select **TCP/IP**, and then press the  button.
- e Select **IPv4**, and then press the  button.
- f Select **IP Address**, and then press the  button.
(Default IP address range: 169.254.xxx.yyy)

```
IP Address  
169.254.000.041*
```

3 Ensure that the IP Address on your computer is assigned by DHCP.



4 Launch your web browser.

- 5 Enter the IP address of the printer in the address bar, and then press the **Enter** key. The CentreWare Internet Services appears on your browser.



- 6 Configure wireless network settings for the printer on the CentreWare Internet Services.
- 7 Reboot the printer.
- 8 Restore the wireless network settings on your computer.

NOTE:

- If the operating system on your computer provides a wireless configuration software, use it to change the wireless network settings. See the instructions below.

For Windows XP and Windows Server 2003:

- a Select **Network Connections** from **Control Panel**.
- b Right-click **Wireless Network Connection** and select **Properties**.
- c Select the **Wireless Networks** tab.
- d Ensure that the check box for **Use Windows to configure my wireless network settings** is selected.
- e Click **Advanced**.
- f You can either set the printer to the ad-hoc mode or the infrastructure mode.
- For Ad hoc mode:
 - Select **Computer-to-computer (ad hoc) networks only** and close the dialog box.
- For Infrastructure mode:
 - Select **Access point (Infrastructure) networks only** and close the dialog box.
- g Click **Add** to display **Wireless network properties**.
- h Enter the setting that you will send to the printer and click **OK**.
- i Click **Move up** to move the setting to the top of the list.
- j Click **OK** to close the **Wireless Network Connection Properties** dialog box.

For Windows Vista:

- a Display **Control Panel**.
- b Select **Network and Internet**.
- c Select **Network and Sharing Center**.
- d Select **Connect to a network**.
- e Select the network, and then click **Connect**.
- f Click **Close** in the dialog box after confirming the connection is a success.

For Windows Server 2008:

- a Display **Control Panel**.
- b Select **Network and Internet**.
- c Select **Network and Sharing Center**.
- d Select **Connect to a network**.
- e Select the network, and then click **Connect**.
- f Click **Close** in the dialog box after confirming the connection is a success.

For Windows Server 2008 R2 and Windows 7:

- a Display **Control Panel**.
- b Select **Network and Internet**.
- c Select **Network and Sharing Center**.
- d Select **Connect to a network**.
- e Select the network, and then click **Connect**.

• For Fixed IP Networks:

- 1 Set up your computer for wireless connectivity:

NOTE:

- If the operating system on your computer provides a wireless configuration software, use it to change the wireless network settings. See the instructions below.

For Windows XP and Windows Server 2003:

- a Select **Network Connections** from **Control Panel**.
- b Right-click **Wireless Network Connection** and select **Properties**.
- c Select the **Wireless Networks** tab.
- d Ensure that the check box for **Use Windows to configure my wireless network settings** is selected.


NOTE:

- Be sure to write down the current wireless computer settings in step **f** and step **h** so that you can restore them later.
- e Click the **Advanced** button.
 - f Select **Computer-to-computer (ad hoc) networks only** and close the **Advanced** dialog box.
 - g Click the **Add** button to display **Wireless network properties**.

- h On the **Association** tab, enter the following information and click **OK**.
Network name (SSID): xxxxxxxx (xxxxxxx indicates a wireless device's SSID which you use)

Network Authentication: Open

Data encryption: Disabled



- i Click the **Move up** button to move the newly added SSID to the top of the list.
- j Click **OK** to close the **Wireless Network Connection Properties** dialog box.

For Windows Vista:

- a Display **Control Panel**.
- b Select **Network and Internet**.
- c Select **Network and Sharing Center**.
- d Select **Connect to a network**.
- e Select **xxxxxxx** (xxxxxxx indicates a wireless device's SSID which you use) from the network items listed in the available network list, and click **Connect**.
- f Click **Close** in the dialog box after confirming the connection is a success.


For Windows Server 2008:

- a Display **Control Panel**.
- b Select **Network and Internet**.
- c Select **Network and Sharing Center**.
- d Select **Connect to a network**.
- e Select **xxxxxxx** (xxxxxxx indicates a wireless device's SSID which you use) from the network items listed in the available network list, and click **Connect**.
- f Click **Close** in the dialog box after confirming the connection is a success.

For Windows Server 2008 R2 and Windows 7:


- a Display **Control Panel**.
- b Select **Network and Internet**.
- c Select **Network and Sharing Center**.
- d Select **Connect to a network**.
- e Select **xxxxxxx** (xxxxxxx indicates a wireless device's SSID which you use) from the network items listed in the available network list, and click **Connect**.

- 2 Check the IP address on your computer.



- 3 Set the IP address on the printer.
See "[Assigning an IP Address \(for IPv4 Mode\)](#)" on page 54.
- 4 Launch your web browser.

- 5 Enter the IP address of the printer in the address bar, and then press the **Enter** key. The CentreWare Internet Services appears on your browser.



- 6 Change the wireless network settings for the printer on the CentreWare Internet Services.
- 7 Reboot the printer.
- 8 Restore the wireless network settings on your computer.

NOTE:

- If the operating system on your computer provides a wireless configuration software, use it to change the wireless network settings. Or you can change the wireless network settings using the tool provided with the operating system. See the instructions below.

For Windows XP and Windows Server 2003:

- a Select **Network Connections** from **Control Panel**.
 - b Right-click **Wireless Network Connection** and select **Properties**.
 - c Select the **Wireless Networks** tab.
 - d Ensure that the check box for **Use Windows to configure my wireless network settings** is selected.
 - e Click **Advanced**.
 - f You can either set the printer to the ad-hoc mode or the infrastructure mode.
- For Ad hoc mode:
Select **Computer-to-computer (ad hoc) networks only** and close the dialog box.
 - For Infrastructure mode:
Select **Access point (Infrastructure) networks only** and close the dialog box.

- g Click **Add** to display **Wireless network properties**.
- h Enter the setting that you will send to the printer and click **OK**.
- i Click **Move up** to move the setting to the top of the list.
- j Click **OK** to close the **Wireless Network Connection Properties** dialog box.

For Windows Vista:

- a Display **Control Panel**.
- b Select **Network and Internet**.
- c Select **Network and Sharing Center**.
- d Select **Connect to a network**.
- e Select the network, and then click **Connect**.
- f Click **Close** in the dialog box after confirming the connection is a success.

For Windows Server 2008:

- a Display **Control Panel**.
- b Select **Network and Internet**.
- c Select **Network and Sharing Center**.
- d Select **Connect to a network**.
- e Select the network, and then click **Connect**.
- f Click **Close** in the dialog box after confirming the connection is a success.

For Windows Server 2008 R2 and Windows 7:

- a Display **Control Panel**.
- b Select **Network and Internet**.
- c Select **Network and Sharing Center**.
- d Select **Connect to a network**.
- e Select the network, and then click **Connect**.

■ Setting Up the Printer for Shared Printing

One way to make a new printer available for other computers on a network is to use the *Software Pack CD-ROM* supplied with your printer. Using the supplied CD is helpful in a way that it will install utilities including the SimpleMonitor as well. The following, however, describes the procedures for sharing a printer on a network without using the supplied CD.

To set up a printer to be shared on a network, you need to set up the printer for network sharing and install print drivers for the printer on every computer on the network.

NOTE:

- You need to purchase an additional Ethernet cable at your own cost to connect a printer to an Ethernet network.

Setting Up the Printer for Network Sharing

• For Windows XP, Windows XP 64-bit Edition, Windows Server 2003, and Windows Server 2003 x64 Edition

- 1 Click **Start** (**start** for Windows XP) → **Printers and Faxes**.
- 2 Right-click the icon for your printer and select **Properties**.
- 3 From the **Sharing** tab, select **Share this printer**, and then enter a name in the **Share name** text box.
- 4 Click **Additional Drivers** and select the operating systems of all network clients using your printer.
- 5 Click **OK**.
If the files are not present in your computer, and then you will be prompted to insert the server operating system CD.
- 6 Click **Apply**, and then click **OK**.

• For Windows Vista and Windows Vista 64-bit Edition

- 1 Click **Start** → **Control Panel** → **Hardware and Sound** → **Printers**.
- 2 Right-click the printer icon and select **Sharing**.
- 3 Click **Change sharing options** button.
- 4 The "**Windows needs your permission to continue**" appears.
- 5 Click **Continue** button.
- 6 Select the **Share this printer** check box, and then enter a name in the **Share name** text box.
- 7 Select **Additional Drivers** and select the operating systems of all network clients using your printer.
- 8 Click **OK**.
- 9 Click **Apply**, and then click **OK**.

• For Windows Server 2008 and Windows Server 2008 64-bit Edition

- 1 Click **Start** → **Control Panel** → **Hardware and Sound** → **Printers**.
- 2 Right-click the printer icon and select **Sharing**.
- 3 Select the **Share this printer** check box, and then enter a name in the **Share name** text box.
- 4 Click **Additional Drivers** and select the operating systems of all network clients using your printer.
- 5 Click **OK**.
- 6 Click **Apply**, and then click **OK**.

• For Windows 7, Windows 7 64-bit Edition, and Windows Server 2008 R2

- 1 Click **Start** → **Devices and Printers**.
- 2 Right-click the printer icon and select **Printer properties**.
- 3 On the **Sharing** tab, select the **Share this printer** check box, and then enter a name in the **Share name** text box.
- 4 Click **Additional Drivers** and select the operating systems of all network clients using your printer.
- 5 Click **OK**.
- 6 Click **Apply**, and then click **OK**.

To check that the printer is shared:

- Ensure that the printer object in the **Printers, Printers and Faxes** or **Devices and Printers** folder is shared. The share icon is shown under the printer icon.
- Browse **Network** or **My Network Places**. Find the host name of the server and look for the shared name you assigned to the printer.

Installing Print Drivers


Now that the printer is set for shared printing, you need to install print drivers for the shared printer using either of the two Windows features.

• Using the Point and Print Feature

The Point and Print feature is a Microsoft Windows technology that automatically downloads and installs a print driver necessary for using the shared printer on the network.

For Windows XP, Windows XP 64-bit Edition, Windows Server 2003, and Windows Server 2003 x64 Edition

- 1 On the Windows desktop of the client computer, double-click **My Network Places**.
- 2 Locate the host name of the server computer, and then double-click the host name.
- 3 Right-click the shared printer name, and then click **Connect**.



Wait until the driver is copied from the server to the client computer and a new printer object is added to the **Printers and Faxes** folder. It may take some time depending on the amount of network traffic.

Close **My Network Places**.

- 4 Print a test page to verify installation.
 - a Click **start (Start for Windows Server 2003/Windows Server 2003 x64 Edition) → Printers and Faxes**.
 - b Select the printer you have installed.
 - c Click **File → Properties**.
 - d On the **General** tab, click **Print Test Page**.When a test page is printed successfully, installation is complete.

For Windows Vista and Windows Vista 64-bit Edition


- 1 Click **Start** → **Network**.
- 2 Locate and double-click the host name of the server computer.
- 3 Right-click the shared printer name, and then click **Connect**.
- 4 Click **Install driver**.
- 5 Click **Continue** in the **User Account Control** dialog box.
Wait until the driver is copied from the server to the client computer and a new printer object is added to the **Printers** folder. It may take some time depending on the amount of network traffic.
- 6 Print a test page to verify installation.
 - a Click **Start** → **Control Panel** → **Hardware and Sound**.
 - b Select **Printers**.
 - c Right-click the printer you just created and select **Properties**.
 - d On the **General** tab, click **Print Test Page**.When a test page is printed successfully, installation is complete.

For Windows Server 2008 and Windows Server 2008 64-bit Edition

- 1 Click **Start** → **Network**.
- 2 Locate the host name of the server computer, and then double-click the host name.
- 3 Right-click the shared printer name, and then click **Connect**.
- 4 Click **Install driver**.
- 5 Wait until the driver is copied from the server to the client computer and a new printer object will be added to the **Printers** folder. It may take some time depending on the amount of network traffic.
- 6 Print a test page to verify installation.
 - a Click **Start** → **Control Panel**.
 - b Select **Hardware and Sound**.
 - c Select **Printers**.
 - d Right-click the printer you just created and select **Properties**.
 - e On the **General** tab, click **Print Test Page**.When a test page is printed successfully, installation is complete.

For Windows 7, Windows 7 64-bit Edition, and Windows Server 2008 R2

- 1 Click **Start** → **Computer** → **Network**.
- 2 Locate the host name of the server computer, and then double-click the host name.
- 3 Right-click the shared printer name, and then click **Connect**.




- 4 Click **Install driver**.
- 5 Wait until the driver is copied from the server to the client computer and a new printer object will be added to the **Devices and Printers** folder. It may take some time depending on the amount of network traffic.
- 6 Print a test page to verify installation.
 - a Click **Start** → **Devices and Printers**.
 - b Right-click the printer you just created and select **Printer properties**.
 - c On the **General** tab, click **Print Test Page**.
When a test page is printed successfully, installation is complete.

• Using the Peer-to-Peer Feature

With the peer-to-peer feature, you need to specify the shared printer to install a print driver.

For Windows XP, Windows XP 64-bit Edition, Windows Server 2003, and Windows Server 2003 x64 Edition

- 1 Click **start** (**Start** for Windows Server 2003/Windows Server 2003 x64 Edition) → **Printers and Faxes**.
- 2 Click **Add a printer** (**Add Printer** for Windows Server 2003/Windows Server 2003 x64 Edition) to launch the **Add Printer Wizard**.
- 3 Click **Next**.
- 4 Select **A network printer, or a printer attached to another computer**, and then click **Next**.
- 5 Click **Browse for a printer**, and then click **Next**.
- 6 Select the printer, and then click **Next**. If the printer is not listed, click **Back** and enter the path to the printer in the text box.



For example: \\<server host name>\<shared printer name>


The server host name is the name of the server computer that identifies it to the network. The shared printer name is the name assigned during the server installation process.

If this is a new printer, you may be prompted to install a print driver. If no system driver is available, specify the location where the driver is available.

- 7 Select **Yes** if you want your printer to be set as the default printer, and then click **Next**.
- 8 Click **Finish**.

For Windows Vista and Windows Vista 64-bit Edition

- 1 Click **Start** → **Control Panel** → **Hardware and Sound** → **Printers**.
- 2 Click **Add a printer** to launch the **Add Printer** wizard.
- 3 Select **Add a network, wireless or Bluetooth printer**. If the printer is listed, select the printer and click **Next**, or select **The printer that I want isn't listed** and enter the path to the printer in the **Select a shared printer by name** text box and click **Next**.



For example: \\<server host name>\<shared printer name>

The server host name is the name of the server computer that identifies it on the network. The shared printer name is the name assigned during the server installation process.

If this is a new printer, you may be prompted to install a print driver. If no system driver is available, specify the location where the driver is available.

- 4 Confirm the printer name, and then select whether to use your printer as the default printer and click **Next**.
- 5 If you want to verify installation, click **Print a test page**.
- 6 Click **Finish**.
When a test page is printed successfully, installation is complete.

For Windows Server 2008 and Windows Server 2008 64-bit Edition

- 1 Click **Start** → **Control Panel** → **Hardware and Sound** → **Printers**.
- 2 Click **Add a printer** to launch the **Add Printer** wizard.
- 3 Select **Add a network, wireless or Bluetooth printer**. If the printer is listed, select the printer and click **Next**, or select **The printer that I want isn't listed** and enter the path to the printer in the **Select a shared printer by name** text box and click **Next**.

For example: \\<server host name>\<shared printer name>

The server host name is the name of the server computer that identifies it on the network. The shared printer name is the name assigned during the server installation process.


If this is a new printer, you may be prompted to install a print driver. If no system driver is available, specify the location where the driver is available.

- 4 Confirm the printer name, and then select whether to use your printer as the default printer and click **Next**.
- 5 Select whether to share your printer or not.
- 6 If you want to verify installation, click **Print a test page**.
- 7 Click **Finish**.

When a test page is printed successfully, installation is complete.

For Windows 7, Windows 7 64-bit Edition, and Windows Server 2008 R2

- 1 Click **Start** → **Devices and Printers**.
- 2 Click **Add a printer** to launch the **Add Printer** wizard.
- 3 Select **Add a network, wireless or Bluetooth printer**. If the printer is listed, select the printer and click **Next**, or select **The printer that I want isn't listed**. Click **Select a shared printer by name** and enter the path to the printer in the text box, and then click **Next**.



For example: \\<server host name>\<shared printer name>

The server host name is the name of the server computer that identifies it to the network. The shared printer name is the name assigned during the server installation process.

If this is a new printer, you may be prompted to install a print driver. If no system driver is available, you need to specify the path to the available drivers.

- 4 Confirm the printer name, and then click **Next**.
- 5 Select whether to use your printer as the default printer.
- 6 If you want to verify installation, click **Print a test page**.
- 7 Click **Finish**.

When a test page is printed successfully, installation is complete.

■ Using the XML Paper Specification Print Driver

To use the XML Paper Specification print driver, you may need to install an additional Microsoft package depending on your operating system.

Windows Vista	VC++2008 Redistribution Package
Windows Server 2008	.Net Framework 3.5 SP1
Windows Server 2008 R2	.Net Framework 3.5.1 (Use the Server Manager interface to manually install it.)

For further information on the XML Paper Specification print driver, visit Microsoft's web site.

Installing Print Drivers on Computers Running Mac OS X

For information on how to install print drivers, refer to the *PostScript Level3 Compatible User Guide*.

This section includes:

- ["Mac OS X Wireless Settings on the Operator Panel \(DocuPrint P255 dw only\)" on page 98](#)

■ Mac OS X Wireless Settings on the Operator Panel (DocuPrint P255 dw only)

You can configure wireless settings on the operator panel.

IMPORTANT:

- The Wireless LAN feature is not available in all locations. Please check with your local Fuji Xerox representative for availability of wireless in your location.
- If you are using a method other than WPS to configure your wireless setting, be sure to get the SSID and security information from a system administrator before starting the setup procedure.
- Ensure that the Ethernet cable has been disconnected from the printer before you configure the wireless settings.

NOTE:

- Before you configure the wireless settings on the operator panel, you need to set up the wireless network settings on your computer. For details, see the *Setup Guide*.
- For information on the specifications of the wireless LAN feature, see the "[Configuring Wireless Network Settings \(DocuPrint P255 dw only\)](#)" on page 62.

You can select a method to configure a wireless setting from the following:

Manual Wi-Fi Setup for	Access Point (Infrastructure) Network
	Computer-to-computer (Ad-hoc) Network
Automatic setup using	WPS-PIN ^{*1}
	WPS-PBC ^{*2}

*1 WPS-PIN is a method to authenticate and register devices required for wireless configuration, by entering PIN code in the printer and computer. This setting, performed through access point, is available only when the access points of your wireless router supports WPS.

*2 WPS-PBC is a method to authenticate and register devices required for wireless configuration, by pressing the button provided on the access point via wireless routers, and then performing WPS-PBC setting on the operator panel. This setting is available only when the access point supports WPS.

To configure wireless settings, refer to the method you selected.














- "[Manual Wi-Fi Setup](#)" on page 99
- "[Auto Setup With the Access Point](#)" on page 101

Manual Wi-Fi Setup









You can manually configure wireless settings to connect your printer to an access point (infrastructure) network or computer-to-computer (ad-hoc) network.

• Connecting to Access Point Network

To configure the wireless settings through an access point such as a wireless router:

- 1 On the operator panel, press the  (**Menu**) button.
- 2 Select `Admin Menu`, and then press the  button.
- 3 Select `Network`, and then press the  button.
- 4 Select `Wi-Fi Setup`, and then press the  button.
- 5 Select the desired access point, and then press the  button.
If the desired access point does not appear:
 - a Select `Manual Setup`, and then press the  button.
 - b Enter the SSID, and then press the  button.
Use the  or  button to enter the desired value, and press the  or  button to move a cursor.
 - c Select `Infrastructure`, and then press the  button.
 - d Select an encryption type, and then press the  button.

IMPORTANT:






















- Be sure to use one of the supported encryption methods from `Mixed Mode PSK`, `WPA-PSK-TKIP`, `WPA2-PSK-AES` and `WEP` to protect your network traffic.
- 6 Enter the WEP key or pass phrase, and then press the  button.
Use the  or  button to enter the desired value, and press the  or  button to move a cursor.
When the encryption type is WEP, select a transmit key from `Auto`, `WEP Key 1`, `WEP Key 2`, `WEP Key 3`, and `WEP Key 4` after entering the WEP key.
 - 7 Wait a few minutes until the printer restarts to establish the wireless network.
 - 8 Print a System Settings page from the operator panel.
 - a Press the  (**Menu**) button.
 - b Select `Report/List`, and then press the  button.
 - c Select `System Settings`, and then press the  button.
The System Settings page is printed.
 - 9 Confirm that "Link Quality" is shown as "Good", "Acceptable" or "Low" on the report.

NOTE:

- When "Link Quality" is "No Reception", check if the wireless settings are correctly configured.
- If the wireless setting does not work, contact your system administrator or Fuji Xerox Customer Support Center.

• Using Ad Hoc Connection

To configure the wireless settings for an ad-hoc connection where the wireless devices communicate directly with each other without an access point:

- 1 On the operator panel, press the  (**Menu**) button.
 - 2 Select `Admin Menu`, and then press the  button.
 - 3 Select `Network`, and then press the  button.
 - 4 Select `Wi-Fi Setup`, and then press the  button.
 - 5 Select the desired access point, and then press the  button.
If the desired access point does not appear:
 - a Select `Manual Setup`, and then press the  button.
 - b Enter the SSID, and then press the  button.
Use the  or  button to enter the desired value, and press the  or  button to move a cursor.
 - c Select `Ad-hoc`, and then press the  button.
 - d Select an encryption type, and then press the  button.
- IMPORTANT:**
- Be sure to use one of the supported encryption methods to protect your network traffic.
- 6 Enter the WEP key, and then press the  button.
Use the  or  button to enter the desired value, and press the  or  button to move a cursor.
 - 7 Select a transmit key from `WEP Key 1`, `WEP Key 2`, `WEP Key 3`, and `WEP Key 4`.
 - 8 Wait a few minutes until the printer restarts to establish the wireless network.
 - 9 Print a System Settings page from the operator panel.
 - a Press the  (**Menu**) button.
 - b Select `Report/List`, and then press the  button.
 - c Select `System Settings`, and then press the  button.
The System Settings page is printed.
 - 10 Confirm that "Link Quality" is shown as "Good", "Acceptable" or "Low" on the report.

NOTE:

- When "Link Quality" is "No Reception", check if the wireless settings are correctly configured.
- If the wireless setting does not work, contact your system administrator or Fuji Xerox Customer Support Center.










Auto Setup With the Access Point

If the access point such as a wireless router supports the WPS, security settings can be made automatically.

• WPS-PBC

NOTE:

- WPS-PBC is a method to authenticate and register devices required for wireless configuration, by pressing the button provided on the access point via wireless routers, and then performing WPS-PBC setting on the operator panel. This setting is available only when the access point supports WPS.

- 1 On the operator panel, press the  (**Menu**) button.
- 2 Select `Admin Menu`, and then press the  button.
- 3 Select `Network`, and then press the  button.
- 4 Select `WPS Setup`, and then press the  button.
- 5 Select `Push Button Control`, and then press the  button.
- 6 Select `Start`, and then press the  button.
- 7 Press and hold the WPS button on the access point.
- 8 Wait a few minutes until the printer restarts to establish the wireless network.
- 9 Print a System Settings page from the operator panel.
 - a Press the  (**Menu**) button.
 - b Select `Report/List`, and then press the  button.
 - c Select `System Settings`, and then press the  button.
The System Settings page is printed.
- 10 Confirm that "Link Quality" is shown as "Good", "Acceptable" or "Low" on the report.











NOTE:

- When "Link Quality" is "No Reception", check if the wireless settings are correctly configured.
- If the wireless setting does not work, contact your system administrator or Fuji Xerox Customer Support Center.

• WPS-PIN

NOTE:

- WPS-PIN is a method to authenticate and register devices required for wireless configuration, by entering PIN code to a printer and computer. This setting, performed through access point, is available only when the access points of your wireless router supports WPS.
- Before WPS-PIN starts, you will need to enter your PIN code at the web page of the wireless access point. See the access point manual for the details.

- 1 On the operator panel, press the  (**Menu**) button.
- 2 Select `Admin Menu`, and then press the  button.
- 3 Select `Network`, and then press the  button.
- 4 Select `WPS Setup`, and then press the  button.
- 5 Select `PIN Code`, and then press the  button.
- 6 Take a note of PIN code displayed on the operator panel.
- 7 Select `Start Configuration`, and then press the  button.
- 8 If SSID selection screen appears, select the SSID, and then press the  button.
- 9 Enter the PIN code of the printer at the web page of the wireless access point.
- 10 Wait a few minutes until the printer restarts to establish the wireless network.
- 11 Print a System Settings page from the operator panel.
 - a Press the  (**Menu**) button.
 - b Select `Report/List`, and then press the  button.
 - c Select `System Settings`, and then press the  button.
The System Settings page is printed.
- 12 Confirm that “Link Quality” is shown as “Good”, “Acceptable” or “Low” on the report.

NOTE:

- When “Link Quality” is “No Reception”, check if the wireless settings are correctly configured.
- If the wireless setting does not work, contact your system administrator or Fuji Xerox Customer Support Center.

Installing Print Drivers on Computers Running Linux (CUPS)

This section provides information on installing and setting up print drivers with CUPS (Common UNIX Printing System) on Red Hat® Enterprise Linux® 6 Desktop (x86), SUSE® Linux Enterprise Desktop 11 (x86), and Ubuntu 10 (x86). For the information on the previous versions of the Linux operating systems, visit respective web sites.

This section includes:

- ["Installing Print Drivers" on page 104](#)
- ["Specifying the Queue" on page 105](#)
- ["Specifying the Default Queue" on page 108](#)
- ["Specifying Printing Options" on page 109](#)
- ["Setting the Password for Authority as the Printer Administrator" on page 111](#)
- ["Uninstalling Print Drivers" on page 112](#)

■ Installing Print Drivers

NOTE:

- The print driver **fx-docuprint-p255-xx-xnoar.rpm** or **fx-docuprint-p255_X-X_all.deb** is included in the **linux** folder on the *Software Pack CD-ROM*.

• For Red Hat Enterprise Linux 6 Desktop (x86)

- 1 Double-click **fx-docuprint-p255-xx-xnoar.rpm** on the *Software Pack CD-ROM*.
- 2 Click **Install**.
- 3 Enter the administrator's password, and then click **Authenticate**.
Installation starts. When the installation is complete, the window automatically closes.

• For SUSE Linux Enterprise Desktop 11 (x86)

- 1 Double-click **fx-docuprint-p255-xx-xnoar.rpm** on the *Software Pack CD-ROM*.
- 2 Click **Install**.
- 3 Enter the administrator's password, and then click **Authenticate**.
Installation starts. When the installation is complete, the window automatically closes.

• For Ubuntu 10 (x86)

- 1 Double-click **fx-docuprint-p255_X-X_all.deb** on the *Software Pack CD-ROM*.
- 2 Click **Install Package**.
- 3 Enter the user password, and click **OK**.
- 4 Click **Close**.
- 5 Click the **X** button at the top-right of the dialog box to close the **Package Installer** dialog box.

■ Specifying the Queue

To perform printing, you must set up the print queue on your workstation.

NOTE:

- When you have finished specifying the queue, you can then sent print jobs from applications. Start a print job from an application, and specify the queue in the print dialog box. Depending on the application (Mozilla, for example), however, you may have to use the default queue for printing. In such a case, you must specify a queue you want to use as the default queue. For details on specifying the default queue, see "[Specifying the Default Queue](#)" on page 108.

• For Red Hat Enterprise Linux 6 Desktop (x86)

- 1 Open the URL "http://localhost:631" using a web browser.
- 2 Click **Administration**.
- 3 Click **Add Printer**.
- 4 Enter **root** as the user name, and then enter the administrator password.
- 5 Click **OK**.
- 6 Select either of the following according to the type of your printer connection.
For a network printer:
 - a Select **LPD/LPR Host or Printer** from the **Other Network Printers** menu, and then click **Continue**.
 - b Enter the IP address of the printer in **Connection**.
Format: **lpd://xxx.xxx.xxx.xxx** (the IP address of the printer)
 - c Click **Continue**.
 - d Enter the name of the printer in **Name** in the **Add Printer** dialog box, and then click **Continue**.
You can optionally specify the location and description of the printer as additional information.
If you want to share the printer, select the **Share This Printer** check box.
For a USB printer connected to a computer running the Red Hat Enterprise Linux 6 Desktop (x86):
 - a Select **FUJI XEROX DocuPrint P255 X (FUJI XEROX DocuPrint P255 X)** from the **Local Printers** menu, and then click **Continue**.
 - b Enter the name of the printer in **Name** in the **Add Printer** dialog box, and then click **Continue**.
You can optionally specify the location and description of the printer as additional information.
If you want to share the printer, select the **Share This Printer** check box.
- 7 Select **FX** from the **Make** menu, and then click **Continue**.

- 8 Select **FX DocuPrint P255 xxx** from the **Model** menu, and then click **Add Printer**.
The setup is complete.
You can optionally specify the default options settings of the printer.

• For SUSE Linux Enterprise Desktop 11 (x86)

- 1 Select **Computer** → **More Applications...**, and then select **YaST** on the **Application Browser**.
- 2 Enter the administrator password.
YaST Control Center is activated.
- 3 Select **Hardware** on **YaST Control Center**, and then select **Printer**.
The **Printer Configurations** dialog box appears.
- 4 Select either of the following according to the type of your printer connection.
For a network printer:
 - a Click **Add**.
The **Add New Printer Configuration** dialog box appears.
 - b Click **Connection Wizard**.
The **Connection Wizard** dialog box appears.
 - c Select **Line Printer Daemon (LPD) Protocol** from **Access Network Printer or Printserver Box via**.
 - d Enter the IP address of the printer in **IP Address or Host Name:**.
 - e Select **Fuji Xerox** in **Select the printer manufacturer:**.
 - f Click **OK**.
The **Add New Printer Configuration** dialog box appears.
 - g Select **FX DocuPrint P255 x vx.x [FujiXerox/FX-DocuPrint-P255-x.ppd.gz]** from the **Assign Driver** list.

NOTE:

- You can specify the printer name in **Set Name:**.

For a USB printer connected to a computer running the SUSE Linux Enterprise Desktop 11:

- a Click **Add**.
The **Add New Printer Configuration** dialog box appears.
The printer name is displayed in the **Determine Connection** list.
- b Select **FX DocuPrint P255 x vx.x [FujiXerox/FX-DocuPrint-P255-x.ppd.gz]** from the **Assign Driver** list.

NOTE:

- You can specify the printer name in **Set Name:**.

- 5 Confirm the settings, and then click **OK**.

• For Ubuntu 10 (x86)

- 1 Open the URL "http://localhost:631" using a web browser.
- 2 Click **Administration**.
- 3 Click **Add Printer**.
- 4 Enter the **User Name** and the **Password**, and then click **OK**.
- 5 Select either of the following according to the type of your printer connection.
For a network printer:
 - a Select **FUJI XEROX DocuPrint P255 X(XX:XX:XX) (Fuji Xerox FUJI XEROX DocuPrint P255 X)** from **Discovered Network Printer**.
 - b Click **Continue**.
 - c Enter the name of the printer in **Name** in the **Add Printer** dialog box, and then click **Continue**.
You can optionally specify the location and description of the printer as additional information.
If you want to share the printer, select the **Share This Printer** check box.For a USB printer connected to a computer running the Ubuntu 10 (x86):
 - a Select **FUJI XEROX DocuPrint P255 X (FUJI XEROX DocuPrint P255 X)** from the **Local Printers** menu, and then click **Continue**.
 - b Enter the name of the printer in **Name** in the **Add Printer** dialog box, and then click **Continue**.
You can optionally specify the location and description of the printer as additional information.
If you want to share the printer, select the **Share This Printer** check box.
- 6 Select **FX** from the **Make** menu, and then click **Continue**.
- 7 Select **FX DocuPrint P255 XXX** from the **Model** menu, and then click **Add Printer**.
The setup is complete.
You can optionally specify the default options settings of the printer.

■ Specifying the Default Queue

• For Red Hat Enterprise Linux 6 Desktop (x86)

- 1 Select **Applications** → **System Tools** → **Terminal**.
- 2 Enter the following command in the terminal window.

```
su
(Enter the administrator password)
lpadmin -d (Enter the queue name)
```

• For SUSE Linux Enterprise Desktop 11 (x86)

- 1 Select **Computer** → **More Applications...**, and then select **YaST** on the **Application Browser**.
- 2 Enter the administrator password.
YaST Control Center is activated.
- 3 Select **Printer** from **Hardware**.
The **Printer Configurations** dialog box appears.
- 4 Click **Edit**.
A dialog box to modify the specified queue appears.
- 5 Confirm that the printer you want to specify as the default queue is selected in the **Connection** list.
- 6 Select the **Default Printer** check box.
- 7 Confirm the settings, and then click **OK**.

• For Ubuntu 10 (x86)

- 1 Select **System** → **Administration** → **Printing**.
- 2 Select the printer you want to specify as the default queue.
- 3 Select the **Printer** menu.
- 4 Select **Set As Default**.
- 5 Select whether to set this printer as the system-wide default printer, and then click **OK**.

■ Specifying Printing Options

You can specify printing options such as the duplex (2-sided) printing.

• For Red Hat Enterprise Linux 6 Desktop (x86)

- 1 Open the URL "http://localhost:631" using a web browser.
- 2 Click **Administration**.
- 3 Click **Manage Printers**.
- 4 Click the queue name for which you want to specify printing options.
- 5 Click the **Administration** drop down box, and then select **Modify Printer**.
- 6 Specify necessary printing options, and then click **Continue** or **Modify Printer**.
The message **Printer FUJI_XEROX_DocuPrint_P255_X has been modified successfully** appears.
The setting is complete.

• For SUSE Linux Enterprise Desktop 11 (x86)

- 1 Open a web browser.
- 2 Enter "http://localhost:631/admin" in the address bar, and then press the **Enter** key.
The **CUPS** window appears.

NOTE:

- Set the password for authority as the printer administrator before setting the printer queue. If you have not set it, see "[Setting the Password for Authority as the Printer Administrator](#)" on page 111.
- 3 Click **Manage Printers**.
 - 4 Click **Modify Printer** on the printer.
 - 5 Specify necessary printing options, and then click **Continue**.
 - 6 Enter **root** as the user name, enter the administrator password, and then click **OK**.
The message **Printer FUJI_XEROX_DocuPrint_P255_X has been modified successfully** appears.
The setting is complete.

• For Ubuntu 10 (x86)

- 1 Open the URL "http://localhost:631" using a web browser.
- 2 Click **Administration**.
- 3 Click **Manage Printers**.
- 4 Click the queue name for which you want to specify printing options.
- 5 Click the **Administration** drop down box, and then select **Modify Printer**.
- 6 Enter the **User Name** and the **Password**, and then click **OK**.
- 7 Select the printer you want to modify.
- 8 Specify necessary printing options, and then click **Continue** or **Modify Printer**.
The message **Printer FUJI_XEROX_DocuPrint_P255_X has been modified successfully** appears.
The setting is complete.

■ Setting the Password for Authority as the Printer Administrator

For SUSE Linux Enterprise Desktop 10 and 11, you must set the password for authority as the printer administrator to do operations as the printer administrator.

• For SUSE Linux Enterprise Desktop 11 (x86)

- 1 Select **Computer** → **More Applications...** and select **GNOME Terminal** on the **Application Browser**.
- 2 Enter the following command in the terminal window.

```
su
lppasswd -g sys -a root
(Enter the password for authority as the printer
administrator after the Enter password prompt.)
(Reenter the password for authority as the
printer administrator after the Enter password
again prompt.)
```

■ Uninstalling Print Drivers

• For Red Hat Enterprise Linux 6 Desktop (x86)

- 1 Select **Applications** → **System Tools** → **Terminal**.
- 2 Enter the following command in the terminal window to delete the print queue.

```
su
(Enter the administrator password)
lpadmin -x (Enter the print queue name)
```

- 3 Repeat the command above for all queues for the same model.
- 4 Enter the following command in the terminal window.

```
rpm -e FX-DocuPrint-P255
```

The print driver is uninstalled.

• For SUSE Linux Enterprise Desktop 11 (x86)

- 1 Select **Computer** → **More Applications...** and select **GNOME Terminal** on the **Application Browser**.
- 2 Enter the following command in the terminal window to delete the print queue.

```
su
lpadmin -x (Enter the print queue name)
```

- 3 Repeat the command above for all queues for the same model.
- 4 Enter the following command in the terminal window.

```
rpm -e FX-DocuPrint-P255
```

The print driver is uninstalled.

• For Ubuntu 10 (x86)

- 1 Select **Applications** → **Accessories** → **Terminal**.
- 2 Enter the following command in the terminal window to delete the print queue.

```
sudo lpadmin -x (Enter the print queue name)
(Enter the user password)
```

- 3 Repeat the command above for all queues for the same model.
- 4 Enter the following command in the terminal window.

```
sudo dpkg -r fx-docuprint-p255
(Enter the user password if required)
```

The print driver is uninstalled.

Printing Basics

This chapter includes:

- ["About Print Media" on page 116](#)
- ["Supported Print Media" on page 118](#)
- ["Loading Print Media" on page 125](#)
- ["Setting Paper Sizes and Types" on page 140](#)
- ["Printing" on page 141](#)
- ["Printing with the Web Services on Devices" on page 159](#)

About Print Media

Using paper that is not appropriate for the printer can cause paper jams, image quality problems, or printer failures. To achieve the best performance from your printer, we recommend you use only the paper described in this section.

When using paper other than that recommended, contact our local representative office or authorized dealer.

This section includes:

- ["Print Media Usage Guidelines" on page 116](#)
- ["Print Media That Can Damage Your Printer" on page 117](#)
- ["Print Media Storage Guidelines" on page 117](#)

■ Print Media Usage Guidelines

The paper tray accommodates various sizes and types of paper and other specialty media. Follow these guidelines when loading paper and media:

- Before buying large quantities of any print media, it is recommended that you try a sample first.
- For 60 to 135 gsm (16 to 36 lb bond) paper, grain long, where the paper fibers run along the length of the paper, is recommended. For paper heavier than 135 gsm (36 lb bond), grain short, where the paper fibers run along the width of the paper, is preferred.
- Envelopes can be printed from the paper tray and the Priority Sheet Inserter (PSI).
- Fan paper or other specialty media before loading in the paper tray.
- Do not print on label stock once a label has been removed from a sheet.
- Use only paper envelopes. Do not use envelopes with windows, metal clasps, or adhesives with release strips.
- Print all envelopes single-sided only.
- Some wrinkling and embossing may occur when printing envelopes.
- When loading print media in the paper tray, do not load it above the fill line on the paper width guides of the paper tray.
- Slide the paper width guides to adjust to the paper size.
- If excessive jams or wrinkles occur, use paper or other media from a new package.



WARNING:

- **Do not use conductive paper such as origami paper, carbonic paper or conductively-coated paper. When paper jam occurs, it may cause short-circuit and eventually a fire accident.**

See also:

- ["Loading Print Media in the Paper Tray" on page 126](#)
- ["Loading Print Media in the Priority Sheet Inserter \(PSI\)" on page 134](#)
- ["Loading Envelopes in the Paper Tray" on page 130](#)
- ["Loading Envelopes in the Priority Sheet Inserter \(PSI\)" on page 137](#)
- ["Printing on Custom Size Paper" on page 154](#)

■ Print Media That Can Damage Your Printer

Your printer is designed to use a variety of media types for print jobs. However, some media can cause poor output quality, excessive paper jams, or damage to your printer.

Unacceptable media includes:

- Rough or porous media
- Plastic media
- Paper that has been folded or wrinkled
- Paper with staples
- Envelopes with windows or metal clasps
- Padded envelopes
- Non-laser glossy or coated paper
- Perforated media



WARNING:

- **Do not use conductive paper such as origami paper, carbonic paper or conductively-coated paper. When paper jam occurs, it may cause short-circuit and eventually a fire accident.**

■ Print Media Storage Guidelines

Providing good storage conditions for your paper and other media contributes to optimum print quality.

- Store print media in dark, cool, relatively dry locations. Most paper items are susceptible to damage from ultraviolet (UV) and visible light. UV radiation, which is emitted by the sun and fluorescent bulbs, is particularly damaging to paper items. The intensity and length of exposure to visible light on paper items should be reduced as much as possible.
- Maintain constant temperatures and relative humidity.
- Avoid attics, kitchens, garages, and basements for storing print media.
- Store print media flat. Print media should be stored on pallets, cartons, shelves, or in cabinets.
- Avoid having food or drinks in the area where print media is stored or handled.
- Do not open sealed packages of paper until you are ready to load them into the printer. Leave paper in the original packaging. For most commercial cut-size grades, the ream wrapper contains an inner lining that protects the paper from moisture loss or gain.
- Leave the media inside the bag until you are ready to use it; reinsert unused media in the bag and reseal it for protection. Some specialty media is packaged inside resealable plastic bags.

Supported Print Media

Using unsuitable print media may lead to paper jams, poor print quality, breakdown and damage to your printer. To use the features of your printer effectively, use the suggested print media that is recommended here.

IMPORTANT:

- The toner may come off the print media, if it gets wet by water, rain, steam and so on. For more information, contact our local representative office or authorized dealer.

■ Usable Print Media

The types of print media that can be used on your printer are as follows:

Paper Tray

Paper Size	A4 SEF (210 × 297 mm) B5 SEF (182 × 257 mm) A5 SEF (148 × 210 mm) Letter SEF (8.5 × 11 inches) Executive SEF (7.25 × 10.5 inches) Legal 13 (Folio) SEF (8.5 × 13 inches) Legal 14 SEF (8.5 × 14 inches) Statement SEF (139.7 × 215.9 mm) Com-10 Envelope SEF (4.125 × 9.5 inches) Monarch Envelope SEF (3.875 × 7.5 inches) Monarch Envelope LEF (7.5 × 3.875 inches)* DL Envelope SEF (110 × 220 mm) DL Envelope LEF (220 × 110 mm)* C5 Envelope SEF (162 × 229 mm) Postcard (100 × 148 mm) Postcard (148 × 200 mm) Yougata 2 Envelope SEF (114 × 162 mm) Yougata 2 Envelope LEF (162 × 114 mm)* Yougata 3 Envelope SEF (98 × 148 mm) Yougata 3 Envelope LEF (148 × 98 mm)* Yougata 4 Envelope (105 × 235 mm) Yougata 6 Envelope (98 × 190 mm) Younaga 3 Envelope (120 × 235 mm) Nagagata 3 Envelope (120 × 235 mm) Nagagata 4 Envelope (90 × 205 mm) Kakugata 3 Envelope (216 × 277 mm) Custom size: Width: 76.2 - 215.9 mm (3 - 8.5 inches) Length: 127 - 355.6 mm (5 - 14 inches)
Paper Type	Plain (60 - 105 gsm) Lightweight Cardstock (106 - 163 gsm) Labels Envelope Recycled Postcard JPN
Loading Capacity	250 sheets of standard paper

* You can load Monarch, DL, Yougata 2, and Yougata 3 envelopes in the LEF orientation into the paper tray with the flap unfolded.

Priority Sheet Inserter (PSI)

Paper Size	A4 SEF (210 × 297 mm) B5 SEF (182 × 257 mm) A5 SEF (148 × 210 mm) Letter SEF (8.5 × 11 inches) Executive SEF (7.25 × 10.5 inches) Legal 13 (Folio) SEF (8.5 × 13 inches) Legal 14 SEF (8.5 × 14 inches) Statement SEF (139.7 × 215.9 mm) Com-10 Envelope SEF (4.125 × 9.5 inches) DL Envelope SEF (110 × 220 mm) C5 Envelope SEF (162 × 229 mm) Yougata 4 Envelope (105 × 235 mm) Younaga 3 Envelope (120 × 235 mm) Nagagata 3 Envelope (120 × 235 mm) Kakugata 3 Envelope (216 × 277 mm) Custom size: Width: 76.2 - 215.9 mm (3.0 - 8.5 inches) Length: 210 - 355.6 mm (8.2 - 14 inches)
Paper Type	Plain (60 - 105 gsm) Lightweight Cardstock (106 - 163 gsm) Labels Envelope Recycled Postcard JPN
Loading Capacity	10 sheets for plain paper or one sheet for other paper

NOTE:

- SEF and LEF indicate the paper feed orientation; SEF stands for short-edge feed. LEF stands for long-edge feed.
- Use only laser print media. Do not use ink jet paper on your printer.

See also:

- ["Loading Print Media in the Paper Tray" on page 126](#)
- ["Loading Print Media in the Priority Sheet Inserter \(PSI\)" on page 134](#)
- ["Loading Envelopes in the Paper Tray" on page 130](#)
- ["Loading Envelopes in the Priority Sheet Inserter \(PSI\)" on page 137](#)

Printing on print media that differs from the paper size or paper type selected on the print driver may lead to paper jams. To ensure that printing is correctly done, select the correct paper size and paper type.

■ Standard Paper and Tested Paper

The following paper and media are standard or usable for the printer.

When you print a generally used paper (which called general paper), please use a paper that suits the standard. To print clearly, we recommend the standard paper shown in the following table. For information about the other paper and media, contact Fuji Xerox Customer Support Center.

	Paper Name	Size	Weight	Paper Type	Notes	
Standard Paper	FX P	A4	64 gsm	Recycled	Medium-thickness paper for in-house documents and general office use.	
	XC Premier 80	A4	80 gsm	Plain		
	Colotech +90	A4	90 gsm	Plain		
	Business 4200	Letter	20 lb	Plain		
Supported Paper	Business 4200	Legal	20 lb	Plain	Medium-thickness paper for in-house documents and general office use.	
	Cascade X-9000	Folio		Plain		
	Cascade X-9000	Letter		Plain		
	Hammermill Tidal MP	Letter		Plain		
	Hammermill Fore MP	Legal	24 lb	Plain		
	Business 4200	Letter		Plain		
	Hammermill Laser Print	Letter	Plain			
	Color Xpressions Select	Letter	Plain			
	GP Laser1000	Executive	Plain			
	Color Xpressions Elite	Letter	28 lb	Plain		
	Business 4200	Letter		Plain		
	FX P	B5	64 gsm	Recycled		Medium-thickness paper for in-house documents and general office use.
	FX P	A5		Recycled		
	FX FR	A4		Recycled		
	V-Paper	A4	Recycled			
	Oji-Recycle 100	B5	66 gsm	Recycled		
	Oji-Recycle 100	A4		Recycled		
	V-paper MG	A4	67 gsm	Recycled		Recycled copy/printer paper compounded 70% of recycled pulp.
	FX G70	A4		Recycled		
FX G100	A4	Recycled				

	Paper Name	Size	Weight	Paper Type	Notes
Supported Paper (Cont'd)	FX C2	A5	70 gsm	Recycled	Paper for general office use with minimum see-through.
	FX C2R	A4		Recycled	70% recycled pulp paper.
	XC Premier 80	A5	80 gsm	Plain	
	XC Business 80	A4		Plain	
	Data Copy	A4		Plain	
	Steinbeis Recycling Copy	A4		Plain	
	Yes Bronze	A4		Plain	
	Berga Focus	A4		Plain	
	XC Premier 90	A4	90 gsm	Plain	
	Conqueror Laid laser Paper	A4		Plain	
	FX JD	B5	98 gsm	Plain	Double-sided paper suitable for a variety of uses, including brochures and booklet.
	FX JD	A4		Plain	
		Multicopy Nymolla	A4	100 gsm	Plain
Special Paper	FX Label (No Cut)	A4	Label	Labels	
	FX Label (20 Cut)	A4		Labels	
	Xerox Label (No Cut)	A4		Labels	
	Xerox Label (24 Cut)	A4		Labels	
	Avery Labels 5165 (No Cut)	Letter		Labels	
	Avery Labels 5160 (30 Cut)	Letter		Labels	
	Columbia CO125	Com-10	Envelope	Envelope	
	Print Master	Monarch		Envelope	
	River Series	DL		Envelope	
	Autofill 90 gsm	DL		Envelope	
	River Series	C5		Envelope	
	Autofill 90 gsm	C5		Envelope	
	Heart Hatsushiba	Yougata 2		Envelope	
	Heart Hatsushiba	Yougata 3		Envelope	
	Heart Hatsushiba	Yougata 4		Envelope	
Heart Hatsushiba	Yougata 6		Envelope		
Heart Tokushiro 80	Nagagata 3		Envelope		
Heart Tokushiro 81	Nagagata 4		Envelope		
Heart Tokushiro 82	Kakugata 3		Envelope		

	Paper Name	Size	Weight	Paper Type	Notes
Special Paper (Cont'd)	Official Postcard	Japanese Postcard	Postcard 190 gsm	Postcard JPN	IMPORTANT: • Do not use a special ink jet printer postcard. It can cause the printer failure.
	Official Postcard	Reply-paid Postcard		Postcard JPN	
	Esselte Oxford Index Card	3 x 5 inches	-	Lightweight Cardstock	
	Xerox Color Xpressions Elite	Letter	120 gsm	Lightweight Cardstock	
	OK Prince 127	A4	128 gsm	Lightweight Cardstock	
	Shiraai	A4	156 gsm	Lightweight Cardstock	
	OK Prince 157	A4	157 gsm	Lightweight Cardstock	
	Premier TCF 160	A4	160 gsm	Lightweight Cardstock	
IBG Paper	PFX V704	A4	70 gsm	Plain	
	FXCL Xplore	A4		Plain	
	FXCL Xcellence 70	A4		Plain	
	FXCL Xceed 70	A4		Plain	
	Topgun	A4		Plain	
	OAHING PAPER	A4		Plain	
	UPM Office Multifunction	A4		Plain	
	AG Docupaper	Folio	Plain		
	FXK A704	A4	75 gsm	Plain	
	FXK K704A	A4		Plain	

	Paper Name	Size	Weight	Paper Type	Notes
IBG Paper (Cont'd)	PFX Red & White Packaging	A4	80 gsm	Plain	
	FXA Professional	A4		Plain	
	FXCL Xcite	A4		Plain	
	FXCL Xcellence 80	A4		Plain	
	FXCL Xceed 80	A4		Plain	
	Double A Laser Paper	A4		Plain	
	KX H-Paper	A4		Plain	
	Green Member	A4		Plain	
	BIO TOP 3 Extra	A4		Plain	
	AG Red Label	Folio		Plain	
	THFX Paper-Q Advance Argo	A4		Plain	
	FXM Diplomat	A4		Plain	
	FXM Excel	A4		Plain	
	FXM Xerox One	A4		Plain	
	FXA Colotech Idol 80 gsm	A4		Plain	
	FXA Colotech Idol 100 gsm	A4	100 gsm	Plain	
	Colotech Plus 120 gsm	A4	120 gsm	Lightweight Cardstock	
	FXM Label 16up	A4	140 gsm	Labels	
	FXM Label 8up	A4		Labels	

Loading Print Media

Loading print media properly helps prevent jams and ensures trouble-free printing.

Before loading print media, identify the recommended print side of the print media. This information is usually on the print media package.

NOTE:

- After loading paper in the paper tray or the Priority Sheet Inserter (PSI), specify the same paper type on the operator panel.

■ Capacity

The paper tray can accommodate:

- 250 sheets of standard paper
- 27.5 mm (1.08 inches) of thick paper
- 27.5 mm (1.08 inches) of postcards
- 10 envelopes
- 20 labels

The Priority Sheet Inserter (PSI) can accommodate:

- 10 sheets for plain paper or one sheet for other paper

■ Print Media Dimensions

The paper tray can accommodate print media within the following dimensions:

- Width: 76.2 - 215.9 mm (3.00 - 8.50 inches)
- Length: 127.0 - 355.6 mm (5.00 - 14.00 inches)


The Priority Sheet Inserter (PSI) can accommodate print media within the following dimensions:

- Width: 76.2 - 215.9 mm (3.00 - 8.50 inches)
- Length: 210.0 - 355.6 mm (8.20 - 14.00 inches)


■ Loading Print Media in the Paper Tray

NOTE:


- When you are printing on any print media that is smaller than the A5 size paper, be sure to load it in the paper tray.
- To avoid paper jams, do not remove the paper tray while printing is in progress.
- Use only laser print media. Do not use ink jet paper on your printer.
- For manually loading print media for duplex (2-sided) printing, see "[Manual Duplex Printing \(PCL Print Driver Only\)](#)" on page 144.
- Do not wipe the pink-tinted grease off as doing so may cause paper to misfeed.



- 1 Pull the paper tray out of the printer about 200 mm. Hold the tray with both hands, remove it from the printer, and then remove the paper tray cover from the paper tray.




- 2 Hold the paper tray end with one hand, push and hold the paper tray extension lever with the other hand, and then extend the tray to your desired length.




NOTE:


- The paper tray can accommodate a stack of A5 paper by default, and is designed to extend in two lengths. To load A4 paper media, extend the paper tray to the mid length. To load longer paper media, extend it to the full length.



- 3 Slide the paper width guides and the length guide to the maximum positions.



- 4 Before loading the print media, flex the sheets back and forth, and then fan them. Straighten the edges of the stack on a level surface.




5 Load the print media into the paper tray with the recommended print surface facing up.


NOTE:

- Do not load paper media above the fill line on the paper width guides of the paper tray as it may cause paper jams.


6 Slide the paper width guides and then the length guide inward until they rest lightly against the edges of the print media stack.




7 Replace the paper tray cover onto the paper tray.



8 Hold the paper tray with both hands and push it into the printer until it clicks into place.



9 Open the output tray extension.



10 Select the paper type on the print driver if the loaded print media is not standard plain paper. If a user-specified print media is loaded in the paper tray, you must specify the paper size on the print driver.

NOTE:


- For details on specifying the paper size and type on the print driver, refer to the Help provided for the print driver.

Loading Envelopes in the Paper Tray



Follow the guidelines below to load envelopes in the paper tray.

NOTE:

- When you print on envelopes, be sure to specify the envelope on the print driver. If not specified, the print image will be rotated 180 degrees.
- If you do not load envelopes in the paper tray right after they have been removed from the packaging, they may bulge. To avoid jams, flatten them as shown below before loading them in the paper tray.



- If envelopes are still not fed correctly, add some bending to the flap of the envelopes as shown in the following illustration. The amount of the bending shall be 5 mm (0.20 inches) or less.




IMPORTANT:

- Never use envelopes with a window or coated linings as it causes paper jams that may result in damage to the printer.

• Loading Com-10, Yougata 4/6, or Younaga 3 Envelopes


Load envelopes with the print surface facing up. Ensure that the flapped edge is pointing toward the right of the printer and each flap is folded under the envelope.




• Loading Monarch, DL, or Yougata 2/3 Envelopes

You can load Monarch, DL, and Yougata 2/3 Envelopes in either of the following orientations:

SEF: Load envelopes with the print surface facing up. Ensure that the flapped edge is pointing toward the right of the printer and each flap is folded under the envelope.



LEF: Load envelopes with the print surface facing up. Ensure that the flapped edge is pointing toward the front of the printer and the flaps are left unfolded.




NOTE:

- When you load the envelopes in the LEF orientation, be sure to specify the landscape orientation on the print driver.
- To confirm the correct orientation of each print media such as envelopes, see the instructions on the **Envelope/Paper Setup Navigator** dialog box of the print driver.

• Loading C5, Nagagata 3/4, or Kakugata 3 Envelopes


Load envelopes with the print surface facing up. Ensure that the flapped edge is pointing toward the rear of the printer and each flap is folded under the envelope.



Loading Postcards in the Paper Tray


NOTE:

- When you print on postcards, be sure to specify the postcard on the print driver for the optimum print result.
- Before loading postcards, smooth them out, but bend the leading edge as shown in the following illustration. Bend them about 5 mm (0.20 inches).




• Loading Postcards

Load postcards with the print surface facing up and the top edge first.



• Loading W-Postcards

Load W-postcards with the print surface facing up and the left edge first.



NOTE:


- To confirm the correct orientation of each print media such as postcards, see the instructions on the **Envelope/Paper Setup Navigator** dialog box of the print driver.

■ Loading Print Media in the Priority Sheet Inserter (PSI)


NOTE:

- Before you use the Priority Sheet Inserter (PSI), make sure that the printer has the paper tray inserted.
- Use only laser print media. Do not use ink jet paper on your printer.
- For manually loading print media for duplex (2-sided) printing, see "[Manual Duplex Printing \(PCL Print Driver Only\)](#)" on page 144.


- 1 Open the front cover.




- 2 Slide the paper width guides to the maximum positions.




- 3 Before loading the print media, flex the sheets back and forth, and then fan them. Straighten the edges of the stack on a level surface.




If print media are still not fed correctly, add some bending to the leading edge of the print media as shown in the following illustration. The amount of the bending shall be 5 mm (0.20 inches) or less.




- 4 Load print media in the PSI with the top edge first and the recommended print surface facing up.



- 5 Slide the paper width guides inward until they rest lightly against the edges of the print media stack.



- 6 Open the output tray extension.



- 7 Select the paper type on the print driver if the loaded print media is not plain paper. If a user-specified print media is loaded in the PSI, you must specify the paper size on the print driver.

NOTE:


- For details on specifying the paper size and type on the print driver, refer to the Help provided for the print driver.

Loading Envelopes in the Priority Sheet Inserter (PSI)



Follow the guidelines below to load envelopes in the PSI.

NOTE:

- Be sure to insert envelopes all the way in. Otherwise, print media that is loaded in the paper tray will be fed.
- When you print on envelopes, be sure to specify the envelope on the print driver. If not specified, the print image will be rotated 180 degrees.
- If you do not load envelopes in the PSI right after they have been removed from the packaging, they may bulge. To avoid jams, flatten them as shown below before loading them in the PSI.



- If envelopes are still not fed correctly, add some bending to the flap of the envelopes as shown in the following illustration. The amount of the bending shall be 5 mm (0.20 inches) or less.




IMPORTANT:

- Never use envelopes with a window or coated linings as it causes paper jams that may result in damage to the printer.


• Loading Com-10, DL, Yougata 4, or Younaga 3 Envelopes

Load envelopes with the print surface facing up. Ensure that the flapped edge is pointing toward the right of the printer and each flap is folded under the envelope.



• Loading C5, Nagagata 3, or Kakugata 3 Envelopes


Load envelopes with the print surface facing up. Ensure that the flapped edge is pointing toward the front of the printer and the flaps are left unfolded.



■ Using the Output Tray Extension

The output tray extension is designed to prevent print media from falling from the printer after the print job is complete.

Before printing a long length document, be sure to open the output tray extension.



Setting Paper Sizes and Types

When loading print media, set the paper size and type on the operator panel before printing. This section describes how to set the paper size and type on the operator panel.






See also:

- ["Understanding the Operator Panel Menus" on page 162](#)

This section includes:

- ["Setting Paper Sizes" on page 140](#)
- ["Setting Paper Types" on page 140](#)






■ Setting Paper Sizes

- 1 Press the  (**Menu**) button.
- 2 Select `Tray Settings`, and then press the  button.
- 3 Select `Tray`, and then press the  button.
- 4 Select `Paper Size`, and then press the  button.
- 5 Select the correct paper size for the print media loaded, and then press the  button.

■ Setting Paper Types

IMPORTANT:

- The paper type must match those of the actual print media loaded in the paper tray. Otherwise, print-quality problems can occur.

- 1 Press the  (**Menu**) button.
- 2 Select `Tray Settings`, and then press the  button.
- 3 Select `Tray`, and then press the  button.
- 4 Select `Paper Type`, and then press the  button.
- 5 Select the correct paper type for the print media loaded, and then press the  button.

Printing

This section covers how to print documents from your printer and how to cancel a job.

This section includes:

- ["Printing from the Computer" on page 141](#)
- ["Canceling a Print Job" on page 142](#)
- ["Duplex Printing" on page 143](#)
- ["Selecting Printing Options" on page 148](#)
- ["Printing Custom Size Paper" on page 153](#)
- ["Checking Status of a Print Job" on page 155](#)
- ["Printing a Report Page" on page 156](#)
- ["Printer Settings" on page 157](#)

■ Printing from the Computer

Install the print driver to use all the features of the printer. When you choose **Print** from an application, a window representing the print driver appears. Select the appropriate settings for the file to print. Print settings selected on the print driver have precedence over the default menu settings selected on the operator panel or the Printer Setting Utility.

The following procedure uses Windows 7 WordPad as an example.

Clicking **Preferences** on the initial **Print** dialog box enables you to change the print settings. If you are not familiar with features on the print driver window, open the Help for additional information.

- 1 Open the file you want to print.
- 2 From the file menu, select **Print**.
- 3 Verify that the correct printer is selected in the dialog box. Modify the print settings as needed (such as the pages you want to print or the number of copies).
- 4 To adjust print settings not available from the first screen, such as **Paper Size**, **Paper Type**, or **Feed Orientation**, click **Preferences**.
The **Printing Preferences** dialog box appears.
- 5 Specify the print settings. For more information, click **Help**.
- 6 Click **OK** to close the **Printing Preferences** dialog box.
- 7 Click **Print** to send the job to the selected printer.


■ Canceling a Print Job

There are several methods for canceling a print job.

This section includes:

- ["Canceling a Job From the Operator Panel" on page 142](#)
- ["Canceling a Job From the Computer \(Windows\)" on page 142](#)

Canceling a Job From the Operator Panel

- 1 Press the  (**Cancel Job**) button.

NOTE:

- Printing is canceled only for the current job. All the following jobs will continue to print.

Canceling a Job From the Computer (Windows)

• Canceling a Job From the Taskbar

When you send a print job, a small printer icon appears on the taskbar.

- 1 Double-click the printer icon.
A list of print jobs appears in the printer window.
- 2 Select the job you want to cancel.
- 3 Press the **Delete** key.
- 4 Click **Yes** on the **Printers** dialog box to cancel a print job.

• Canceling a Job From the Desktop

- 1 Minimize all programs to reveal the desktop.
Click **Start** → **Printers and Faxes** (for Windows XP).
Click **Start** → **Printers and Faxes** (for Windows Server 2003).
Click **Start** → **Devices and Printers** (for Windows 7 and Windows Server 2008 R2).
Click **Start** → **Control Panel** → **Hardware and Sound** → **Printers** (for Windows Vista and Windows Server 2008).
A list of available printers appears.
- 2 Double-click the printer you selected when you sent the job.
A list of print jobs appears in the printer window.
- 3 Select the job you want to cancel.
- 4 Press the **Delete** key.
- 5 Click **Yes** on the **Printers** dialog box to cancel a print job.

■ Duplex Printing

Duplex (2-sided) printing allows you to print on either side of a sheet of paper. The paper sizes available for duplex printing are A4, B5, A5, Letter, Executive, Folio, and Legal.

This section includes:

- ["Automatic Duplex Printing" on page 143](#)
- ["Manual Duplex Printing \(PCL Print Driver Only\)" on page 144](#)

Automatic Duplex Printing

The following procedure uses the PCL 6 driver as an example.

- 1 Click **start** → **Printers and Faxes** (for Windows XP).
Click **Start** → **Printers and Faxes** (for Windows Server 2003).
Click **Start** → **Devices and Printers** (for Windows 7 and Windows Server 2008 R2).
Click **Start** → **Control Panel** → **Hardware and Sound** → **Printers** (for Windows Vista).
Click **Start** → **Control Panel** → **Printers** (for Windows Server 2008).
A list of available printers appears.
- 2 Right-click the icon for your printer and select **Printing preferences**.
The **Paper/Output** tab appears.
- 3 From **Duplex**, select **Flip on Long Edge** or **Flip on Short Edge**.
- 4 Click **OK**.

Manual Duplex Printing (PCL Print Driver Only)

When you have a problem with automatic duplex printing, you may want to try manual duplex printing. Starting manual duplex printing displays a window containing the instructions that you can follow. Note that the window cannot be reopened once it is closed. Do not close the window until duplex printing is complete.

NOTE:

- When printing on curled paper, straighten the paper before inserting the paper.


• Operations on Your Computer

The following procedure uses Microsoft Windows 7 WordPad as an example.

NOTE:

- The way to display the **Printer Properties/Printing Preferences** dialog box depends on the application software. Refer to the manual of your application software.

- 1 From the file menu, select **Print**.
- 2 Select the printer from the **Select Printer** list box, and then click **Preferences**.
The **Paper/Output** tab of the **Printing Preferences** dialog box appears.
- 3 From **Duplex**, select either **Flip on Short Edge (Manual)** or **Flip on Long Edge (Manual)** to define the way 2-sided print pages are bound.




- 4 From **Paper Size**, select the size of the document to be printed.
- 5 From **Paper Type**, select the paper type to be used.
- 6 Click **OK** to close the **Printing Preferences** dialog box.
- 7 Click **Print** in the **Print** dialog box to start printing.


• Loading Print Media in the Paper Tray

- 1 First print the even pages (rear sides).

For a six page document, rear sides are printed in the order of page 6, page 4, then page 2.

When printing of the even pages is complete, the  (**Ready**) LED lights and the LCD panel shows the following:

Insert Output
and Press OK



- 2 After the even pages are printed, pull out the paper tray and remove the paper tray cover.

See also:


- ["Loading Print Media in the Paper Tray" on page 145](#)

- 3 Remove the paper stack from the center output tray and load it into the paper tray with the blank surface facing up.

NOTE:

- Warped or curled prints can cause paper jams. Straighten them before setting them.


- 4 Replace the paper tray cover, insert the paper tray into the printer, and then press the **OK** button. Pages are printed in the order of page 1 (rear of page 2), page 3 (rear of page 4), and then page 5 (rear of page 6).




• Loading Print Media in the Priority Sheet Inserter (PSI)

1 First print the even pages (rear sides).

For a six page document, rear sides are printed in the order of page 6, page 4, then page 2.

When printing of the even pages is complete, the  (**Ready**) LED lights and the LCD panel shows the following:

Insert Output
and Press OK




2 After the even pages are printed, remove the paper stack from the center output tray.

NOTE:

- Warped or curled prints can cause paper jams. Straighten them before setting them.

3 Load the paper stack back into the PSI, and then press the button.

Pages are printed in order of page 1 (rear of page 2), page 3 (rear of page 4), and then page 5 (rear of page 6).



■ Selecting Printing Options

This section includes:

- "Selecting Printing Preferences (Windows)" on page 148
- "Selecting Options for an Individual Job (Windows)" on page 148
- "Selecting Options for an Individual Job (Mac OS X)" on page 151

Selecting Printing Preferences (Windows)

Printing preferences control all of your print jobs, unless you override them specifically for a job. For example, if you want to use duplex (2-sided) printing for most jobs, set this option in printing preferences.

- 1 Click **start** → **Printers and Faxes** (for Windows XP).
Click **Start** → **Printers and Faxes** (for Windows Server 2003).
Click **Start** → **Devices and Printers** (for Windows 7 and Windows Server 2008 R2).
Click **Start** → **Control Panel** → **Hardware and Sound** → **Printers** (for Windows Vista and Windows Server 2008).
A list of available printers appears.
- 2 Right-click the icon for your printer, and then select **Printing preferences**.
The printer's **Printing Preferences** dialog box appears.
- 3 Make selections on the driver tabs, and then click **OK** to save your selections.

NOTE:

- For details on Windows print driver options, click **Help** on the print driver tab to view the Help.

Selecting Options for an Individual Job (Windows)

If you want to use special printing options for a particular job, change the driver settings before sending the job to the printer. For example, if you want to use Photo print-quality mode for a particular graphic, select this setting on the print driver before printing that job.

- 1 With the desired document or graphic open in your application, access the **Print** dialog box.
- 2 Select your printer and click **Preferences** to open the print driver.
- 3 Make selections on the driver tabs.

NOTE:

- On Windows, you can save current printing options with a distinctive name and apply them to other print jobs. Make selections on the **Paper/Output**, **Graphics**, **Layout**, **Watermarks/Forms**, or **Advanced** tab, and then click **Save** under **Favorites** on the **Paper/Output** tab. Click **Help** for more information.

- 4 Click **OK** to save your selections.
- 5 Print the job.

See the following table for specific printing options:

Printing Options for Windows

Operating System	Driver Tab	Printing Options
Windows XP, Windows XP x 64bit, Windows Server 2003, Windows Server 2003 x 64bit, Windows Vista, Windows Vista x 64bit, Windows Server 2008, Windows Server 2008 x 64bit,	Paper/Output tab	<ul style="list-style-type: none"> • Favorites • Duplex • Copies • Collated • Paper Summary • Paper Size • Paper Type • Feed Orientation • Envelope/Paper Setup Navigator • Printer Status • Restore Defaults
Windows Server 2008 R2, Windows 7, or Windows 7 x 64bit	Graphics tab	<ul style="list-style-type: none"> • Image Quality • Toner Saving Mode • Image Enhancement • Screen • Image Settings <ul style="list-style-type: none"> – Apply to All Elements – Apply to Selected Element – Brightness – Contrast • Tone Balance • Restore Defaults
	Layout tab	<ul style="list-style-type: none"> • Image Orientation • Multiple Up • Image Order • Image Border • Booklet / Poster / Mixed Document • Output Size • Reduce / Enlarge • Margin Shift/Margin • Restore Defaults

Operating System	Driver Tab	Printing Options
Windows XP, Windows XP x 64bit, Windows Server 2003, Windows Server 2003 x 64bit, Windows Vista, Windows Vista x 64bit, Windows Server 2008, Windows Server 2008 x 64bit, Windows Server 2008 R2,	Watermarks/Forms tab	<ul style="list-style-type: none"> • Watermarks <ul style="list-style-type: none"> – New Text – New Bitmap – Edit – Delete – First Page Only • Forms <ul style="list-style-type: none"> – Off – Create / Register Forms – Image Overlay • Header / Footer Options • Restore Defaults
Windows 7, or Windows 7 x 64bit	Advanced tab	<ul style="list-style-type: none"> • Items <ul style="list-style-type: none"> – Change All Colors to Black – Resolution – Show Paper Size/Type Error • Font Settings • Restore Defaults

Selecting Options for an Individual Job (Mac OS X)

To select print settings for a particular job, change the driver settings before sending the job to the printer.

- 1 With the document open in your application, click **File**, and then click **Print**.
- 2 Select your printer from **Printer**.
- 3 Select the desired printing options from the menus and drop-down lists that are displayed.

NOTE:

- On Mac OS X, click **Save As** on the **Presets** menu screen to save the current printer settings. You can create multiple presets and save each with its own distinctive name and printer settings. To print jobs using specific printer settings, click the applicable saved preset in the **Presets** menu.

- 4 Click **Print** to print the job.

Mac OS X Print Driver Printing Options:

The table shown below uses Mac OS X 10.6 TextEdit as an example.

Printing options for Mac OS X

Item	Printing Options
	<ul style="list-style-type: none">• Copies• Collated• Pages• Paper Size• Orientation
Layout	<ul style="list-style-type: none">• Pages per Sheet• Layout Direction• Border• Two-Sided• Reverse page orientation• Flip horizontally
Color Matching	<ul style="list-style-type: none">• ColorSync• In printer• Profile
Paper Handling	<ul style="list-style-type: none">• Pages to Print• Page Order• Scale to fit paper size• Destination Paper Size• Scale down only
Cover Page	<ul style="list-style-type: none">• Print Cover Page• Cover Page Type• Billing Info
Scheduler	<ul style="list-style-type: none">• Print Document• Priority

Item	Printing Options
Printer Features	<ul style="list-style-type: none">• 1. Detailed Settings<ul style="list-style-type: none">– Resolution– Screen– Toner Saving Mode– Image Enhancement• 2. Paper Handling<ul style="list-style-type: none">– Duplex– Paper Type– Show Paper Size/Type Error
Summary	

■ Printing Custom Size Paper

This section explains how to print on custom size paper using the print driver.

The way to load custom size paper is the same as the one to load standard size paper.

- "Loading Print Media in the Paper Tray" on page 126
- "Loading Print Media in the Priority Sheet Inserter (PSI)" on page 134
- "Setting Paper Sizes and Types" on page 140

Defining a Custom Paper Size

Before printing, define a custom size on the print driver.

NOTE:

- When defining a paper size on the print driver or the operator panel, be sure to specify the same size as the actual print media used. Specifying a wrong size for printing can cause a printer failure. This is especially true if you specify a bigger size when using a narrow width paper.

• Using the Windows Print Driver

On the Windows print driver, define a custom size in the **Custom Paper Size** dialog box. This section explains the procedure using Windows 7 as an example.

On Windows XP or later, only users with administrator rights can use the administrator's password to change the settings. Users without the rights of administrator can only view the contents.

- 1 Click **Start** → **Devices and Printers**.
- 2 Right-click the icon for your printer, and then select **Printer properties**.
- 3 Select the **Configuration** tab.
- 4 Click **Custom Paper Size**.
- 5 Select the custom setup you want to define from **Details**.
- 6 Specify the length of the short edge and long edge under **Change Setting For**. You can specify the values either by entering them directly or using the up arrow and down arrow buttons. The length of the short edge cannot be longer than the long edge, even if it is within the specified range. The length of the long edge cannot be shorter than the short edge, even if it is within the specified range.
- 7 To assign a paper name, select the **Name the Paper Size** check box, and then enter the name in **Paper Name**. Up to 14 characters can be used for the paper name.
- 8 If necessary, repeat steps 5 to 7 to define another custom size.
- 9 Click **OK** twice.

Printing on Custom Size Paper

Use the following procedures to print using either the Windows or Mac OS X print driver.

• Using the Windows Print Driver

This section explains the procedure using Windows 7 WordPad as an example.

NOTE:

- The way to display the **Printer Properties/Printing Preferences** dialog box depends on the application software. Refer to the manual of your application software.

- 1 From the file menu, select **Print**.
- 2 Select your printer and click **Preferences**.
- 3 Select the **Paper/Output** tab.
- 4 Select the size of the document to be printed from **Paper Size**.
- 5 Select the paper type to be used from **Paper Type**.
- 6 Click the **Layout** tab.
- 7 From **Output Size**, select the custom size you defined. If you have selected the custom size from **Paper Size** in step 4, select **Same as Paper Size**.
- 8 Click **OK**.
- 9 Click **Print** in the **Print** dialog box to start printing.

• Using the Mac OS X Print Driver

This section explains the procedure using Mac OS X 10.6 TextEdit as an example.

- 1 From the **File** menu, select **Page Setup**.
- 2 Select your printer from **Format For**.
- 3 From **Paper Size**, select **Manage Custom Sizes**.
- 4 In the **Custom Paper Sizes** window, click **+**.
A newly created setting **Untitled** is displayed in the list.
- 5 Double-click **Untitled** and enter a name for the setting.
- 6 Enter the size of the document to be printed in the **Width** and **Height** boxes of **Paper Size**.
- 7 Specify **Non-Printable Area** if necessary.
- 8 Click **OK**.
- 9 Make sure that the newly created paper size is chosen in **Paper Size**, and then click **OK**.
- 10 From the **File** menu, select **Print**.
- 11 Click **Print** to start printing.

■ Checking Status of a Print Job

This section includes:

- ["Checking Status \(Windows Only\)" on page 155](#)
- ["Checking Status on the CentreWare Internet Services \(Windows & Mac OS X\)" on page 155](#)

Checking Status (Windows Only)

You can check the printer status with the SimpleMonitor. Double-click the SimpleMonitor printer icon on the taskbar at the bottom right of the screen. The **Printer Selection** window appears and displays the printer name, the printer connection port, printer status, and the model name. Check the column **Status** for the current status of your printer.

Settings button: Displays the **Settings** window and allows you to modify the SimpleMonitor settings.

Click the name of the desired printer listed on the **Printer Selection** window. The **Printer Status** window appears. You can check the printer status and print job status.

For details on the SimpleMonitor, see Help. The following procedure uses Windows 7 as an example:

- 1 Click **Start** → **All Programs** → **Fuji Xerox** → **Fuji Xerox Printer Software for Asia-Pacific** → your printer → **SimpleMonitor-Btype for Asia-Pacific**.
The **Printer Selection** window appears.
- 2 Click the name of the desired printer from the list.
The **Printer Status** window appears.
- 3 Click **Help**.

See also:

- ["SimpleMonitor \(Windows Only\)" on page 43](#)

Checking Status on the CentreWare Internet Services (Windows & Mac OS X)

You can check the status of the print job sent to the printer on the **Jobs** tab of the CentreWare Internet Services.

See also:

- ["Printer Management Software" on page 39](#)

■ Printing a Report Page

You can print various types of reports and lists. For details on each report and list, see ["Report/List" on page 163](#).

Taking the System Settings page as an example, this section describes two methods of printing a report page.




Printing the System Settings Page

To verify detailed printer settings, print the System Settings page.

• Using the Operator Panel

NOTE:

- The reports and lists are all printed in English.

- 1 Press the  (**Menu**) button.
- 2 Select `Report/List`, and then press the  button.
- 3 Select `System Settings`, and then press the  button.
The System Settings page is printed.

• Using the Printer Setting Utility (Windows Only)

The following procedure uses Windows 7 as an example.

NOTE:

- The reports and lists are all printed in English.

- 1 Click **Start** → **All Programs** → **Fuji Xerox** → **Fuji Xerox Printer Software for Asia-Pacific** → your printer → **Printer Setting Utility**.

NOTE:

- The window to select a printer appears in this step when multiple print drivers are installed on your computer. In this case, click the name of the desired printer listed in **Printer Name**.

The Printer Setting Utility starts.

- 2 Click the **Printer Settings Report** tab.
- 3 Select **Reports** from the list at the left side of the page.
The **Reports** page is displayed.
- 4 Click the **System Settings** button.
The System Settings page is printed.

■ Printer Settings







You can change the printer settings using either the operator panel or the Printer Setting Utility.

Changing the Printer Settings

• Using the Operator Panel

NOTE:

- Factory defaults may vary for different regions.
- Once one value is selected, it will be active until a new value is applied or the default value is restored.
- Driver settings may have precedence over the changes previously made and you may have to change the printer settings.

- 1 Press the  (**Menu**) button.
- 2 Select the desired menu, and then press the  button.
- 3 Select the desired menu or menu item, and then press the  button.
 - If the selection is a menu, the menu opens and the list of menu items appears.
 - If the selection is a menu item, the default menu setting appears.A value can be:
 - A phrase or word to describe a setting
 - A numerical value that can be changed
 - An On or Off setting
- 4 Repeat step 3 until you reach the desired value.
- 5 Press the  button to apply the selected value.
- 6 To continue changing the printer settings, use the  (**Back**) button to ascend the operator panel menus to one of the top menus and follow steps 2 through 5.
To quit changing the printer settings, keep pressing the  (**Back**) button until the LCD panel shows `Ready to Print`.

• Using the Printer Setting Utility (Windows Only)

The following procedure uses Windows 7 as an example.

NOTE:

- Once one value is selected, it will be active until a new value is applied or the default value is restored.
- Driver settings may have precedence over the changes previously made and you may have to change the printer settings.

- 1 Click **Start** → **All Programs** → **Fuji Xerox** → **Fuji Xerox Printer Software for Asia-Pacific** → your printer → **Printer Setting Utility**.

NOTE:

- The window to select a printer appears in this step when multiple print drivers are installed on your computer. In this case, click the name of the desired printer listed in **Printer Name**.

The Printer Setting Utility starts.

- 2 Click the **Printer Maintenance** tab.

- 3 Select the desired menu item.

Each menu item has a list of values. A value can be:

- A phrase or word to describe a setting
- A numerical value that can be changed
- An On or Off setting

- 4 Select the desired value, and then click the **Apply New Settings** or **Restart printer to apply new settings** button.

Printing with the Web Services on Devices

This section provides information for network printing with the Web Services on Devices available on Windows Vista, Windows Server 2008, Windows Server 2008 R2, and Windows 7 protocol of Microsoft.

This section includes:

- ["Adding Roles of Print Services" on page 159](#)
- ["Printer Setup" on page 160](#)

■ Adding Roles of Print Services

When you use Windows Server 2008 or Windows Server 2008 R2, you need to add the roles of print services to the Windows Server 2008 or Windows Server 2008 R2 client.

• For Windows Server 2008:

- 1 Click **Start** → **Administrative Tools** → **Server Manager**.
- 2 From the **Action** menu, select **Add Roles**.
- 3 Select the **Print Services** check box on the **Server Roles** window in the **Add Roles Wizard**, and then click **Next**.
- 4 Click **Next**.
- 5 Select the **Print Server** check box, and then click **Next**.
- 6 Click **Install**.

• For Windows Server 2008 R2:

- 1 Click **Start** → **Administrative Tools** → **Server Manager**.
- 2 From the **Action** menu, select **Add Roles**.
- 3 Select the **Print and Document Services** check box on the **Server Roles** window in the **Add Roles Wizard**, and then click **Next**.
- 4 Click **Next**.
- 5 Select the **Print Server** check box, and then click **Next**.
- 6 Click **Install**.

■ Printer Setup

You can install your new printer on the network using the *Software Pack CD-ROM* that shipped with your printer, or using **Add Printer Wizard**.

Installing a Print Driver Using the Add Printer Wizard

- 1 Click **Start** → **Control Panel** → **Hardware and Sound** → **Printers (Start** → **Devices and Printers** for Windows Server 2008 R2 and Windows 7).
- 2 Click **Add a printer** to launch the **Add Printer Wizard**.
- 3 Select **Add a network, wireless or Bluetooth printer**.
- 4 In the list of available printers, select the one you want to use, and then click **Next**.

NOTE:

- In the list of available printers, the Web Services on Devices printer is displayed in the form of "**http://IP address/ws**".
 - If no Web Services on Devices printer is displayed in the list, enter the printer's IP address manually to create a Web Services on Devices printer. To enter the printer's IP address manually, follow the instructions below. For Windows Server 2008 R2, to create a Web Services on Devices printer, you must be a member of Administrators group.
 - 1 Click **The printer that I want isn't listed**.
 - 2 Select **Add a printer using a TCP/IP address or hostname** and click **Next**.
 - 3 Select **Web Services Device** from **Device type**.
 - 4 Enter the printer's IP address in the **Hostname or IP address** text box and click **Next**.
 - Before installing the driver using the **Add Printer** wizard on Windows Server 2008 R2 or Windows 7, perform one of the followings:
 - Establish the Internet connection so that Windows Update can scan your computer.
 - Add the print driver to your computer in advance.
- 5 If prompted, install the print driver on your computer. If you are prompted for an administrator password or confirmation, type the password or provide confirmation.
 - 6 Complete the additional steps in the wizard, and then click **Finish**.
 - 7 Print a test page to verify print installation.
 - a Click **Start** → **Control Panel** → **Hardware and Sound** → **Printers (Start** → **Devices and Printers** for Windows Server 2008 R2 and Windows 7).
 - b Right-click the printer you just created, and then click **Properties (Printer properties** for Windows Server 2008 R2 and Windows 7).
 - c On the **General** tab, click **Print Test Page**. When a test page is printed successfully, installation is complete.

Using the Operator Panel Menus

This chapter includes:

- ["Understanding the Operator Panel Menus" on page 162](#)
- ["Panel Lock Feature" on page 185](#)
- ["Changing the Power Saver Mode Settings" on page 187](#)
- ["Resetting to Factory Defaults" on page 188](#)


Understanding the Operator Panel Menus

When your printer is connected to a network and available to a number of users, access to the `Admin Menu` may be restricted. This prevents unauthorized users from using the operator panel to inadvertently change the default menu settings that have been set by the administrator. However, you can change settings for individual print jobs using the print driver. Print settings selected on the print driver have precedence over the default menu settings on the operator panel.

■ Report/List

Use `Report/List` to print various types of reports and lists.

NOTE:

- A password is required to use the `Report/List` menu when `Panel Lock Set` is set to `Enable`. In this case, enter the password you specified, and press the  button.
- The reports and lists are all printed in English.

System Settings

Purpose:

To print a list of information such as the printer name, the serial number, print volume, and network settings.

Panel Settings

Purpose:

To print a detailed list of all the settings on the operator panel menus.

Job History

Purpose:

To print a detailed list of the jobs that have been processed. This list contains the last 50 jobs.

Error History

Purpose:

To print a detailed list of paper jams and fatal errors.

Demo Page

Purpose:

To print a test page.

PCL Fonts List

Purpose:

To print a sample of available PCL fonts.

PS Fonts List

Purpose:

To print a sample of available PostScript Level3 Compatible and PDF fonts.


■ Meter Readings

Use `Meter Readings` to check the total number of printed pages.

■ Admin Menu

Use the `Admin Menu` to configure a variety of printer features.

NOTE:

- A password is required to use the `Admin Menu` when `Panel Lock Set` is set to `Enable`. In this case, enter the password you specified, and press the  button.

Network

Use the `Network` option to change the printer settings affecting jobs sent to the printer through the network.

• Ethernet

Purpose:

To specify the communication speed and the duplex settings of Ethernet. To make any changes effective, turn off the printer and then turn it back on.

Values:

Auto*	Detects the Ethernet settings automatically.
10BASE-T Half	Uses 10base-T half-duplex.
10BASE-T Full	Uses 10base-T full-duplex.
100BASE-TX Half	Uses 100base-TX half-duplex.
100BASE-TX Full	Uses 100base-TX full-duplex.

* Factory default menu setting

NOTE:

- This menu item appears only when the printer is connected to a wired network.

• Wi-Fi Status (DocuPrint P255 dw only)

Purpose:

To display the information on the wireless signal strength. No changes can be made on the operator panel to improve the status of the wireless connection.

Values:

Good	Indicates good signal strength.
Acceptable	Indicates marginal signal strength.
Low	Indicates insufficient signal strength.
No Reception	Indicates that no signal is received.

NOTE:

- This menu item appears only when the printer is connected to a wireless network.

• Wi-Fi Setup (DocuPrint P255 dw only)

Purpose:

To configure wireless network settings.

Values:

Manual Setup	Enter Network (SSID)	Enter a name of up to 32 alphanumeric characters to identify the wireless network. As the factory default menu setting, <code>wireless_device</code> is specified in advance.
	Infrastructure	Configures a wireless network with access points.
	No Security*	Configures a wireless network without security encryption.
	Mixed Mode PSK	Configures a wireless network with the WPA-PSK-TKIP, WPA-PSK-AES and WPA2-PSK-AES encryptions.
	PassPhrase Entry	Enter a passphrase of 8 to 63 alphanumeric characters.
	WPA-PSK-TKIP	Configures a wireless network with the WPA-PSK-TKIP encryption.
	PassPhrase Entry	Enter a passphrase of 8 to 63 alphanumeric characters.
	WPA2-PSK-AES	Configures a wireless network with the WPA2-PSK-AES encryption.
	PassPhrase Entry	Enter a passphrase of 8 to 63 alphanumeric characters.
	WEP	Configures a wireless network with the WEP encryption and specify a WEP key of 5 or 13 ASCII characters; 10 or 26 hexadecimal characters.
	Transmit Key	Select the transmit key from Auto, WEP Key 1, WEP Key 2, WEP Key 3, and WEP Key 4.
	Ad-hoc	Configures a wireless network without access points.
	No Security*	Configures a wireless network without security encryption.
WEP	Configures a wireless network with the WEP encryption and specify a WEP key of 5 or 13 ASCII characters; 10 or 26 hexadecimal characters.	
Transmit Key	Select the transmit key from WEP Key 1, WEP Key 2, WEP Key 3, and WEP Key 4.	

* Factory default menu setting

NOTE:

- This menu item appears only when the printer is connected to a wireless network.

• WPS Setup (DocuPrint P255 dw only)

Push Button Control	PBC Start	Cancel*	Disables the PBC method for the WPS encryption.
		Start	Enables the PBC method for the WPS encryption.
PIN Code	Start Configuration	Starts configuring wireless network settings using the PIN code assigned automatically by the printer.	
	Print PIN Code	Prints the PIN code to be entered on the computer for the WPS encryption setup.	

* Factory default menu setting

NOTE:

- This menu item appears only when the printer is connected to a wireless network.

• Reset Wi-Fi (DocuPrint P255 dw only)

Purpose:

To initialize wireless network settings. Enabling this feature and rebooting the printer will reset all the wireless settings to their factory default settings.

Values:

No*	Does not reset the wireless setting.
Yes	Resets the wireless setting.

* Factory default menu setting

NOTE:

- This menu item appears only when the printer is connected to a wireless network.

• TCP/IP

Purpose:

To configure TCP/IP settings. To make any changes effective, turn off the printer and then turn it back on.

Values:

IP Mode	Dual Stack*	Uses both IPv4 and IPv6 to set the IP address.	
	IPv4	Uses IPv4 to set the IP address.	
IPv4	Get IP Address	DHCP/AutoIP*	Automatically sets the IP address.
		BOOTP	Uses BOOTP to set the IP address.
		RARP	Uses RARP to set the IP address.
		DHCP	Uses DHCP to set the IP address.
		Panel	Enter the IP address on the operator panel.
		IP Address	Enter the IP address allocated to the printer.
	Subnet Mask	Enter the subnet mask.	
	Gateway Address	Enter the gateway address.	

* Factory default menu setting

NOTE:

- To configure the IPv6 settings, use the CentreWare Internet Services.

• Protocol

Purpose:

To enable or disable each protocol. To make any changes effective, turn off the printer and then turn it back on.

Values:

LPD	Disable	Disables the Line Printer Daemon (LPD) port.
	Enable*	Enables the LPD port.
Port 9100	Disable	Disables the Port 9100 port.
	Enable*	Enables the Port 9100 port.
WSD**	Disable	Disables the Web Services on Devices port.
	Enable*	Enables the Web Services on Devices port.
SNMP	Disable	Disables the Simple Network Management Protocol (SNMP) UDP port.
	Enable*	Enables the SNMP UDP port.
Status Messenger	Disable	Disables the Status Messenger feature.
	Enable*	Enables the Status Messenger feature.
CentreWare IS	Disable	Disables an access to the CentreWare Internet Services embedded in the printer.
	Enable*	Enables an access to the CentreWare Internet Services embedded in the printer.
Bonjour (mDNS)	Disable	Disables the Bonjour (mDNS).
	Enable*	Enables the Bonjour (mDNS).

* Factory default menu setting

** WSD stands for Web Services on Devices.

• IP Filter

NOTE:

- The IP Filter feature is available only when `Protocol` is set to `LPD` or `Port 9100`.

Purpose:

To block data received from certain IP addresses through the network. You can set up to five IP addresses. To make any changes effective, turn off the printer and then turn it back on.

Values:

No.n/Address (n is 1 - 5.)		Sets the IP address for Filter <i>n</i> .
No.n/Mask (n is 1 - 5.)		Sets the address mask for Filter <i>n</i> .
No.n/Mode (n is 1 - 5.)	Off*	Disables the IP Filter feature for Filter <i>n</i> .
	Reject	Rejects an access from the specified IP address.
	Accept	Accepts an access from the specified IP address.

* Factory default menu setting

• Initialize NVM

Purpose:

To initialize wired network data stored in Non-Volatile Memory (NVM). Enabling this feature and rebooting the printer will reset all the wired network settings to their factory default values.

Values:

Yes	Initializes the wired network data stored in NVM.
No*	Does not initialize the wired network data stored in NVM.

* Factory default menu setting

• PS Data Format

Purpose:

To set the PS data communications protocol. To make any changes effective, turn off the printer and then turn it back on.

Values:

Auto*	Sets the PS data communications protocol automatically.
Standard	Sets the PS data communications protocol to Standard.
BCP	Sets the PS data communications protocol to BCP.
TBCP	Sets the PS data communications protocol to TBCP.

* Factory default menu setting

System Settings

Use the `System Settings` menu to configure a variety of printer features.

• Power Saving Timer

Purpose:


To specify a time period before the printer enter each power saver mode.

Values:

Low Power Timer	1min* 1min - 30min	By default, the printer enters Low Power mode in one minute of inactivity after completion of the last job. You can change the <code>Low Power Timer</code> setting within a range from 1 to 30 minutes.
Sleep Timer	6min* 6min - 11min	By default, the printer enters Sleep mode in six minutes of inactivity starting from the moment it entered Low Power mode. You can change the <code>Sleep Timer</code> setting within a range from 6 to 11 minutes.

* Factory default menu setting

Select `1min` (default) for `Low Power Timer` if your printer shares an electrical circuit with your room lights and you notice them flickering. Otherwise, select a high value to keep your printer available for frequent use with the minimum warm-up time.

The printer automatically exits a power saver mode when it receives a print job from a computer. Alternatively, you can manually bring it back to the ready-to-print state by pressing the  (**Energy Saver**) button. Whether the printer is in Low Power or Sleep mode, it will take about 25 seconds for the printer to resume the ready-to-print state.

• Auto Reset

Purpose:

To specify a time period before the printer restores the default setting for the current menu item and resumes the ready-to-print state when an attempt to change the setting is left unfinished.

Values:

45sec*
1min
2min
3min
4min

* Factory default menu setting

• Fault Timeout

Purpose:

To specify a time period before the printer cancels a job that has halted abnormally. Any job will be cancelled when it times out.

Values:

Off		Disables the fault time-out feature.
On	60sec* 3sec - 300sec	By default, the printer cancels a job in 60 seconds after the job halts abnormally. You can change the setting within a range from 3 to 300 seconds.

* Factory default menu setting

• Job Timeout

Purpose:

To specify a time period that the printer waits to receive data from a computer. Any print job will be cancelled when it times out.

Values:

Off		Disables the job time-out feature.
On	30sec* 5sec - 300sec	By default, the printer waits to receive data from a computer for 30 seconds. You can change the setting within a range from 5 to 300 seconds.

* Factory default menu setting

• mm / inch

Purpose:

To specify the measurement unit after the numeric value displayed on the operator panel.

Values:

Millimeters (mm)*
Inches (")

* Factory default menu setting

• Low Toner Alert Msg

Purpose:

To specify whether to show the alert message when the toner is low.

Values:

Off	Does not show the alert message when the toner is low.
On*	Shows the alert message when the toner is low.

* Factory default menu setting

Maintenance

Use the Maintenance menu to adjust print settings for each paper type, initialize the Non-Volatile Memory (NVM), and change the toner cartridge settings.

• F/W Version

Purpose:

To display the version of the controller.

• Adjust BTR

Purpose:

To specify a voltage of the transfer roller (BTR) for optimum printing of each paper type. To lower the voltage, specify a negative value. To increase, specify a positive value.

The default settings may not yield the best output on all paper types. If you see mottles on the print output, try increasing the voltage. If you see white spots on the print output, try decreasing the voltage.

NOTE:

- The print quality depends on the values you select for this menu item.

Values:

Plain	0*
	-3 - 3
Light Card	0*
	-3 - 3
Labels	0*
	-3 - 3
Envelope	0*
	-3 - 3
Recycled	0*
	-3 - 3
Postcard	0*
	-3 - 3

* Factory default menu setting

• Adjust Fusing Unit

Purpose:

To specify a temperature of the fusing unit for optimum printing of each paper type. To lower the temperature, specify a negative value. To increase, specify a positive value.

The default settings may not yield the best output on all paper types. When the printed paper has curled, try lowering the temperature. When the toner does not fuse on the paper properly, try increasing the temperature.

NOTE:

- The print quality depends on the values you select for this menu item.

Values:

Plain	0*
	-3 - 3
Light Card	0*
	-3 - 3
Labels	0*
	-3 - 3
Envelope	0*
	-3 - 3
Recycled	0*
	-3 - 3
Postcard	0*
	-3 - 3

* Factory default menu setting

• Density Adjustment

Purpose:

To adjust the print density level within the range of -3 to 3. The factory default menu setting is 0.

• Clean Developer

Purpose:

To rotate the developer motor and stir the toner in the toner cartridge.

Values:

Yes	Stirs the toner in a new toner cartridge.
No*	Does not stir the toner in a new toner cartridge.

* Factory default menu setting

• Toner Refresh

Purpose:

To use up a toner cartridge when you need to replace it before the end of its life, or to stir the toner in a new toner cartridge.

Values:

Black	Yes	Cleans the toner in the toner cartridge.
	No*	Does not clean the toner in the toner cartridge.

* Factory default menu setting

• Initialize NVM

Purpose:

To initialize the NVM for the printer settings. Enabling this feature and rebooting the printer will reset all the printer settings to their factory default values.

See also:

- ["Resetting to Factory Defaults" on page 188](#)

Values:

System Section	Yes	Initializes the printer settings.
	No*	Does not initialize the printer settings.

* Factory default menu setting

• Non-Genuine Mode

Purpose:

To use a toner cartridge of another manufacturer.

NOTE:

- Using a non-genuine toner cartridge may make some printer features unusable, reduce print quality and decrease the reliability of your printer. We recommend you use only new Fuji Xerox brand toner cartridges for your printer. We do not provide warranty coverage for problems caused by using non-genuine consumables.
- Before you use a toner cartridge of another manufacturer, be sure to restart the printer.

Values:

Toner	Off*	Does not use a toner cartridge of another manufacturer.
	On	Uses a toner cartridge of another manufacturer.

* Factory default menu setting

• Adjust Altitude

Purpose:

To specify the altitude of the location where the printer is installed.

The discharge phenomenon for charging the photo conductor varies with barometric pressure. You can specify the altitude of the printer location for adjustment.

NOTE:

- An incorrect altitude adjustment leads to poor printing quality and an incorrect indication of remaining toner.

Values:

0m*	Select the altitude of the location where the printer is installed.
1000m	
2000m	
3000m	

* Factory default menu setting

• Machine Life

Purpose:

To specify whether to continue print operations when the printer comes to the end of its service life.

Values:

Stop Printing*	Stops print operations at the end of service life.
Keep Printing	Continues print operations after the end of service life.

* Factory default menu setting

NOTE:

- When the printer no longer operates showing the error code 191-310 on the LCD panel, press the **↩ (Back)** button and the **▼** button at the same time and change the `Machine Life` setting to `Keep Printing`. Then, you can keep using the printer.
- Although you can keep using the printer after the end of its service life by changing the setting to `Keep Printing`, the printing quality is not guaranteed.

Secure Settings

Use the `Secure Settings` menu to set a password to limit access to the operator panel menus. This prevents the printer settings from being changed accidentally.

• Panel Lock

Purpose:

To restrict access to `Admin Menu` and `Report/List` with a password.

See also:

- ["Panel Lock Feature" on page 185](#)

Values:

<code>Panel Lock Set</code>	<code>Disable*</code>	Does not restrict access to <code>Admin Menu</code> and <code>Report/List</code> with a password.
	<code>Enable</code>	Restricts access to <code>Admin Menu</code> and <code>Report/List</code> with a password.
<code>Change Password**</code>	<code>0000*-9999</code>	Sets or changes the password required to access <code>Admin Menu</code> and <code>Report/List</code> .

* Factory default menu setting

** Not displayed when `Panel Lock Set` is set to `Disable`.

• Software Download

Purpose:

To install or discard the software data downloaded and sent by the connected computer.

Values:

<code>Disable</code>	Discards the downloaded software data to maximize data security.
<code>Enable*</code>	Installs the downloaded software data.

* Factory default menu setting

USB Settings

Use the `USB Settings` menu to change printer settings affecting a USB port.

• Port Status

Purpose:

To enable or disable the USB interface.

Values:

<code>Disable</code>	Disables the USB interface.
<code>Enable*</code>	Enables the USB interface.

* Factory default menu setting

• PS Data Format

Purpose:

To set the PS data communications protocol. To make any changes effective, turn off the printer and then turn it back on.

Values:

Auto*	Sets the PS data communications protocol automatically.
Standard	Sets the PS data communications protocol to Standard.
BCP	Sets the PS data communications protocol to BCP.
TBCP	Sets the PS data communications protocol to TBCP.

* Factory default menu setting

PCL Settings

Use the PCL Settings menu to change printer settings that only affect jobs using the PCL emulation printer language.

• Paper Size

Purpose:

To specify the default paper size.

Values:

A4 - 210x297*
A5 - 148x210
B5 - 182x257
Letter - 8.5x11
Folio - 8.5x13
Legal - 8.5x14
Executive
Statement
#10Env - 4.125x9.5
Monarch Env.
Monarch Env.L
DL Env - 110x220
DL Env L
C5 Env - 162x229
148 x 100mm
148 x 200mm
Env Yougata2
Env Yougata2L
Env Yougata3
Env Yougata3L
Env Yougata4
Env Yougata6

Env Younaga3			
Env Nagagata3			
Env Nagagata4			
Env Kakugata3			
New Custom Size	Portrait (Y)	297mm*/11.7inch h*	Specifies the length of the custom size paper. Which factory default menu setting displays depends on the value selected for mm / inch under the System Settings menu. See " mm / inch " on page 169 for more information.
		127mm - 355mm/5.0inch - 14.0inch	
	Landscape (X)	210mm*/8.3inch *	Specifies the width of the custom size paper. Which factory default menu setting displays depends on the value selected for mm / inch under the System Settings menu. See " mm / inch " on page 169 for more information.
		77mm - 215mm/3.0inch - 8.5inch	
* Factory default menu setting.			

• Image Orientation

Purpose:

To specify how text and graphics are oriented on the page.

Values:

Portrait*	Prints text and graphics parallel to the short edge of the paper.
Landscape	Prints text and graphics parallel to the long edge of the paper.
* Factory default menu setting	

• 2 Sided Options

Purpose:

To specify whether to print on either side of paper.

Values:

2 Sided Print	Off*	Does not print on either side of paper.
	On	Prints on either side of paper.
Binding Edge	Flip Long Edge*	Prints on either side of paper to be bound on the long edge.
	Flip Short Edge	Prints on either side of paper to be bound on the short edge.
* Factory default menu setting		

• Font

Purpose:

To select the default font from the fonts installed on the printer.

Values:

Courier*	AlbertusMd	ITCBookmanDb
CGTimes	AlbertusXb	ITCBookmanLtIt
CGTimesBd	Arial	ITCBookmanDbIt
CGTimesIt	ArialBd	NwCentSchlbkRmn
CGTimesBdIt	ArialIt	NwCentSchlbkBd
CGOmega	ArialBdIt	NwCentSchlbkIt
CGOmegaBd	TimesNew	NwCentSchlbkBdIt
CGOmegaIt	TimesNewBd	Times
CGOmegaBdIt	TimesNewIt	TimesBd
Coronet	TimesNewBdIt	TimesIt
ClarendonCd	Helvetica	TimesBdIt
UniversMd	HelveticaBd	ZapfChanceryMdIt
UniversBd	HelveticaOb	Symbol
UniversMdIt	HelveticaBdOb	SymbolPS
UniversBdIt	HelveticaNr	Wingdings
UniversMdCd	HelveticaNrBd	ZapfDingbats
UniversBdCd	HelveticaNrOb	CourierBd
UniversMdCdIt	HelveticaNrBdOb	CourierIt
UniversBdCdIt	PalatinoRmn	CourierBdIt
AntiqueOlv	PalatinoBd	LetterGothic
AntiqueOlvBd	PalatinoIt	LetterGothicBd
AntiqueOlvIt	PalatinoBdIt	LetterGothicIt
GarmondAntiqua	ITCAvantGardBk	CourierPS
GarmondHlb	ITCAvantGardDb	CourierPSBd
GarmondKrsv	ITCAvantGardBkOb	CourierPSOb
GarmondKrsvHlb	ITCAvantGardDbOb	CourierPSBdOb
Marigold	ITCBookmanLt	

* Factory default menu setting

• Symbol Set

Purpose:

To specify a symbol set for the specified font.

Values:

PC-8*	PS MATH	WINGDINGS
PC-8 DN	PI FONT	DNGBTSMS
PC-850	LEGAL	ISO-L6
PC-852	ISO-4	PC-1004
PC-8 TK	ISO-6	PC-775
WIN L1	ISO-11	WINBALT
WIN L2	ISO-15	UCS-2
WIN L5	ISO-17	ROMAN-8
DESKTOP	ISO-21	ROMANEXT
MC TEXT	ISO-60	ISO-L1
PS TEXT	ISO-69	ISO-L2
MS PUB	WIN 3.0	ISO-L5
MATH-8	SYMBOL	

* Factory default menu setting

• Font Size

Purpose:

To specify the font size for scalable typographic fonts, within a range from 4.00 to 50.00. The default is 12.00.

Font size refers to the height of the characters in the font. One point equals approximately 1/72 of an inch.

NOTE:

- The `Font Size` menu item only appears for typographic fonts.

• Font Pitch

Purpose:

To specify the font pitch for scalable mono spaced fonts, within a range from 6.00 to 24.00. The default is 10.00.

Font pitch refers to the number of fixed-space characters in a horizontal inch of type. For nonscheduled mono spaced fonts, the pitch is displayed, but cannot be changed.

NOTE:

- The `Font Pitch` menu item only appears for fixed or mono spaced font.

• Form Line

Purpose:

To set the number of lines in a page.

Values:

64*	Select the value in increments of 1.
5-128	
* Factory default menu setting	

NOTE:

- The printer sets the amount of space between each line (vertical line spacing) based on the `Form Line` and `Image Orientation` settings. Make sure that the `Form Line` and `Image Orientation` settings are correct before changing the `Form Line` setting.

• Quantity

Purpose:

To set the default print quantity, within a range from 1 to 999. The default is 1. (Set the number of copies required for a specific job on the print driver. Values selected on the print driver always override values selected on the operator panel.)

• Image Enhancement

Purpose:

To specify whether to enable the Image Enhancement feature which makes the boundary line between black and white smoother to decrease jagged edges and enhance the visual appearance.

Values:

Off*	Disables the Image Enhancement feature.
On	Enables the Image Enhancement feature.
* Factory default menu setting	

• Draft Mode

Purpose:

To save toner by printing in the draft mode. The print quality is reduced when you print in the draft mode.

Values:

Disable*	Does not print in the draft mode.
Enable	Prints in the draft mode.
* Factory default menu setting	

• Line Termination

Purpose:

To add the line termination commands.

Values:

Off*	The line termination command is not added. CR=CR, LF=LF, FF=FF
Carriage Return	The CR command is added. CR=CR, LF=CR-LF, FF=CR-FF
Line Feed	The LF command is added. CR=CR-LF, LF=LF, FF=FF
CR + LF	The CR and LF commands are added. CR=CR-LF, LF=CR-LF, FF=CR-FF

* Factory default menu setting

PS Settings

Use the `PS Settings` menu to change printer settings that only affect jobs using the PostScript Level3 Compatible printer language.

• PS Error Report

Purpose:

To specify whether to print the description of errors concerning the PostScript Level3 Compatible printer language.

Values:

Off	Does not print the PS error report.
On*	Prints the PS error report.

* Factory default menu setting

• PS Job Timeout

Purpose:

To specify the runtime of a single job using the PostScript Level3 Compatible printer language.

Values:

Off*	Does not set the runtime of a PS job.
On	Sets the runtime of a PS job. 1min 1min - 900min

* Factory default menu setting

PDF Settings

Use the PDF Settings menu to change printer settings that only affect the PDF jobs.

• Quantity

Purpose:

To specify the number of copies to print.

Values:

1*	Select a value in increments of 1.
1 - 999	

* Factory default menu setting

• 2 Sided Options

Purpose:

To specify whether to print on either side of paper.

Values:

2 Sided Print	Off*	Does not print on either side of paper.
	On	Prints on either side of paper.
Binding Edge	Flip Long Edge*	Prints on either side of paper to be bound on the long edge.
	Flip Short Edge	Prints on either side of paper to be bound on the short edge.

* Factory default menu setting

• Print Mode

Purpose:

To specify the print mode.

Values:

Normal*	For documents with normal sized characters.
High Quality	For documents with small characters or thin lines, or documents printed using a dot-matrix printer.

* Factory default menu setting

• PDF Password

Purpose:

To specify a password for printing secure PDF files.

Values:

XXXXXX	Enter a password of up to 32 alphanumeric characters for printing secure PDF files.
--------	---

• Output Size

Purpose:

To specify the output paper size for PDF files.

Values:

A4 - 210x297*

Auto

Letter - 8.5x11

* Factory default menu setting

• Layout

Purpose:

To specify the output layout.

Values:

Auto %*

4 Pages Up

2 Pages Up

100% (No Zoom)

* Factory default menu setting

■ Tray Settings

Use the `Tray Settings` option to set the paper size and type of paper loaded in the paper tray.

Tray

Purpose:

To specify the paper loaded in the paper tray.

Values:

Paper Size	A4 - 210x297*		
	A5 - 148x210		
	B5 - 182x257		
	Letter - 8.5x11		
	Folio - 8.5x13		
	Legal - 8.5x14		
	Executive		
	Statement		
	#10Env - 4.125x9.5		
	Monarch Env.		
	Monarch Env.L		
	DL Env - 110x220		
	DL Env L		
	C5 Env - 162x229		
	148 x 100mm		
	148 x 200mm		
	Env Yougata2		
	Env Yougata2L		
	Env Yougata3		
	Env Yougata3L		
	Env Yougata4		
	Env Yougata6		
	Env Younaga3		
	Env Nagagata3		
	Env Nagagata4		
	Env Kakugata3		
New	Portrait (Y)	297mm*/11.7inch*	Specifies the length of the custom size paper. Which factory default menu setting displays depends on the value selected for mm / inch under the System Settings menu. See "mm / inch" on page 169 for more information.
Custom		127mm -	
Size		355mm/5.0inch - 14.0inch	
	Landscape (X)	210mm*/8.3inch*	Specifies the width of the custom size paper. Which factory default menu setting displays depends on the value selected for mm / inch under the System Settings menu. See "mm / inch" on page 169 for more information.
		77mm -	
		215mm/3.0inch - 8.5inch	

Paper Type	Plain*
	Light Card
	Labels
	Envelope
	Recycled
	Postcard
* Factory default menu setting	

NOTE:

- For details on the supported paper sizes, see ["Usable Print Media" on page 119](#).









Panel Lock Feature

This feature prevents unauthorized users from changing the settings on the operator panel made by the administrator. However, you can modify the settings for individual print jobs using the print driver.

This section includes:

- ["Enabling the Panel Lock Feature" on page 185](#)
- ["Disabling the Panel Lock Feature" on page 186](#)






■ Enabling the Panel Lock Feature

- 1 Press the  (**Menu**) button.
- 2 Select `Admin Menu`, and then press the  button.
- 3 Select `Secure Settings`, and then press the  button.
- 4 Select `Panel Lock`, and then press the  button.
- 5 Select `Panel Lock Set`, and then press the  button.
- 6 Select `Enable`, and then press the  button.
- 7 If necessary, select `Change Password`, and then press the  button.
- 8 Enter a new password, and then press the  button.








NOTE:

- The factory-default panel password is 0000.

NOTE:

- If you forget your password, turn off the printer. Then, while holding the  (**Menu**) button, turn on the printer. Continue to hold the  (**Menu**) button until the LCD panel shows `Ready to Print`.
- If you want to change the password while `Panel Lock Set` is `Enable`, perform steps 1 and 2. Enter the current password, and then press the  button. Perform steps 3 and 4. Select `Change Password`, and then press the  button. Enter a new password, and then press the  button. This will change the password.

■ Disabling the Panel Lock Feature









- 1 Press the  (**Menu**) button.
- 2 Select `Admin Menu`, and then press the  button.
- 3 Enter the password, and then press the  button.
- 4 Select `Secure Settings`, and then press the  button.
- 5 Select `Panel Lock`, and then press the  button.
- 6 Select `Panel Lock Set`, and then press the  button.
- 7 Select `Disable`, and then press the  button.

NOTE:

- The password is reset to 0000 when the setting for `Panel Lock Set` is changed from `Enable` to `Disable`.







Changing the Power Saver Mode Settings

The printer enters a power saver mode after the specified time period of inactivity. You can set `Power Saving Timer` to place the printer in either of the power saver modes.

- 1 Press the  (**Menu**) button.
- 2 Select `Admin Menu`, and then press the  button.
- 3 Select `System Settings`, and then press the  button.
- 4 Select `Power Saving Timer`, and then press the  button.
- 5 Select `Low Power Timer` or `Sleep Timer`, and then press the  button.
- 6 Press the  or  button to select the desired value, and then press the  button.
You can select from 1 - 30 minutes for `Low Power Timer` or 6 - 11 minutes for `Sleep Timer`.

Resetting to Factory Defaults

Enabling the Initialize NVM feature and rebooting the printer will reset all the printer settings to their factory default menu settings.

- 1 Press the  (**Menu**) button.
- 2 Select `Admin Menu`, and then press the  button.
- 3 Select `Maintenance`, and then press the  button.
- 4 Select `Initialize NVM`, and then press the  button.
- 5 Select `System Section` to initialize the printer settings, and then press the  button.
- 6 Select `Yes`, and then press the  button.

The printer restarts automatically with the factory default menu settings.

Troubleshooting

This chapter includes:

- ["Clearing Jams" on page 190](#)
- ["Basic Printer Problems" on page 203](#)
- ["Display Problems" on page 204](#)
- ["Printing Problems" on page 205](#)
- ["Print Quality Problems" on page 207](#)
- ["Other Problems" on page 217](#)
- ["Understanding Printer Messages" on page 218](#)
- ["Contacting Service" on page 221](#)
- ["Getting Help" on page 222](#)
- ["Enabling Non-Genuine Mode" on page 224](#)

Clearing Jams

Careful selection of appropriate print media and proper loading allow you to avoid most jams.

 **WARNING:**

- **If you cannot remove the paper jam by doing the procedures in the manual, do not try to forcibly remove the jam. Doing so may cause injuries. Contact your local Fuji Xerox representative.**

See also:

- ["About Print Media" on page 116](#)
- ["Supported Print Media" on page 118](#)

NOTE:

- Before buying large quantities of any print media, it is recommended that you try a sample first.

This section includes:

- ["Avoiding Jams" on page 191](#)
- ["Identifying the Location of Paper Jams" on page 192](#)
- ["Clearing Paper Jams From the Front of the Printer" on page 193](#)
- ["Clearing Paper Jams From the Rear of the Printer" on page 198](#)
- ["Clearing Paper Jams From the Center Output Tray" on page 200](#)
- ["Jam Problems" on page 202](#)

■ Avoiding Jams

- Use only recommended print media.
- See ["Loading Print Media in the Paper Tray" on page 126](#) and ["Loading Print Media in the Priority Sheet Inserter \(PSI\)" on page 134](#) to load print media properly.
- Do not load print media before turning on the printer.
- Do not overload the print media sources.
- Do not load wrinkled, creased, damp, or curled print media.
- Flex, fan, and straighten print media before you load it. If a jam occurs with print media, try feeding one sheet at a time through the paper tray or the Priority Sheet Inserter (PSI).
- Do not use print media that you have cut or trimmed.
- Do not mix print media sizes, weights, or types in the same print media source.
- Ensure that the recommended print surface is face up when you load print media in the paper tray or the Priority Sheet Inserter (PSI).
- Keep print media stored in an acceptable environment.
- Do not remove the paper tray cover while printing is in progress.
- Ensure that all cables that connect to the printer are correctly attached.
- Overtightening the guides may cause jams.

See also:

- ["About Print Media" on page 116](#)
- ["Supported Print Media" on page 118](#)
- ["Print Media Storage Guidelines" on page 117](#)


■ Identifying the Location of Paper Jams

CAUTION:

- Do not attempt to remove a paper deeply jammed inside the product, particularly a paper wrapped around the fusing unit or the heat roller. Otherwise, it may cause injuries or burns. Switch off the product immediately and contact your local Fuji Xerox representative.

IMPORTANT:

- Do not attempt to clear any jams using tools or instruments. This may permanently damage the printer.
- The following illustration shows where paper jams may occur along the print media path.



- | | |
|---|-------------------------------|
| 1 | Center Output Tray |
| 2 | OPC Drum |
| 3 | Levers |
| 4 | Rear Cover |
| 5 | Front Cover |
| 6 | Paper Tray |
| 7 | Priority Sheet Inserter (PSI) |

■ Clearing Paper Jams From the Front of the Printer

This section includes:

- "Clearing Paper Jams From the Paper Tray" on page 193
- "Clearing Paper Jams From the Priority Sheet Inserter (PSI)" on page 196

Clearing Paper Jams From the Paper Tray


IMPORTANT:

- To prevent electric shock, always turn off the printer and disconnect the power cord from the grounded outlet before performing maintenance.
- To avoid burns, do not clear paper jams immediately after printing. The fusing unit becomes extremely hot during use.


NOTE:

- To resolve the error displayed on the LCD panel, you must clear all print media from the print media path.


- 1 Push the rear cover handle and open the rear cover.




- 2 Lift up the levers.




- 3** Pull the paper tray out of the printer carefully. Hold the tray with both hands, lift the front slightly, and remove it from the printer.




- 4** Remove all the jammed and/or creased paper from the tray.




- 5** Pull the jammed paper out carefully to avoid tearing it.




- 6** Lower the levers to the original position.



7 Close the rear cover.



8 Insert the paper tray into the printer, and push until it clicks into place.



Clearing Paper Jams From the Priority Sheet Inserter (PSI)


IMPORTANT:

- Do not put excessive force on the front cover when removing the jammed paper. Doing so could damage the cover.
- To prevent electric shock, always turn off the printer and disconnect the power cord from the grounded outlet before performing maintenance.
- To avoid burns, do not clear paper jams immediately after printing. The fusing unit becomes extremely hot during use.


NOTE:

- To resolve the error displayed on the LCD panel, you must clear all print media from the print media path.


- 1 Push the rear cover handle and open the rear cover.




- 2 Lift up the levers.




- 3 Pull the jammed paper out carefully to avoid tearing it.



4 Lower the levers to the original position.



5 Close the rear cover.



■ Clearing Paper Jams From the Rear of the Printer


IMPORTANT:

- To prevent electric shock, always turn off the printer and disconnect the power cord from the grounded outlet before performing maintenance.
- To avoid burns, do not clear paper jams immediately after printing. The fusing unit becomes extremely hot during use.
- Protect the OPC drum against bright light. If the rear cover is left open for more than three minutes, print quality may deteriorate.


NOTE:

- To resolve the error displayed on the LCD panel, you must clear all print media from the print media path.


- 1 Push the rear cover handle and open the rear cover.




- 2 Lift up the levers.




- 3 Remove the jammed paper from the rear of the printer.




- 4 Lower the levers to the original position.



- 5 Close the rear cover.



If the error is not resolved, there may be a piece of paper remaining inside the printer. Use the following procedure to clear the jam.

- 6 Load a print media on the Paper Tray or PSI if there is no print media.
- 7 Press and hold  (**Cancel Job**) button for more than three seconds.

■ Clearing Paper Jams From the Center Output Tray


IMPORTANT:

- To prevent electric shock, always turn off the printer and disconnect the power cord from the grounded outlet before performing maintenance.
- To avoid burns, do not clear paper jams immediately after printing. The fusing unit becomes extremely hot during use.
- Protect the OPC drum against bright light. If the rear cover is left open for more than three minutes, print quality may deteriorate.


NOTE:

- To resolve the error displayed on the LCD panel, you must clear all print media from the print media path.


- 1 Push the rear cover handle and open the rear cover.




- 2 Lift up the levers.




- 3 Remove the jammed paper from the rear of the printer. If no paper is found in the paper path, then remove it from the center output tray.




- 4 Lower the levers to the original position.



- 5 Close the rear cover.



If the error is not resolved, there may be a piece of paper remaining inside the printer. Use the following procedure to clear the jam.

- 6 Load a print media on the Paper Tray or PSI if there is no print media.
- 7 Press and hold  (**Cancel Job**) button for more than three seconds.

■ Jam Problems

This section includes:

- ["Misfeed Jam" on page 202](#)
- ["Multi-feed Jam" on page 202](#)

Misfeed Jam

Problem	Action
Print media misfeeds occur.	<p>Remove the paper from the Priority Sheet Inserter (PSI), and then ensure that the paper is properly inserted in the paper tray.</p> <hr/> <p>Depending on the print media you use, take any of the following actions:</p> <ul style="list-style-type: none">• For thick paper, use the one that is 163 gsm or less.• For postcard, the one up to 190 gsm is available.• For thin paper, use the one that is 60 gsm or more.• For the envelope, ensure that it is properly loaded in the paper tray as instructed in "Loading Envelopes in the Paper Tray" on page 130. <hr/> <p>If the envelope is deformed, correct it or use another envelope.</p> <hr/> <p>If performing manual duplex (2-sided) printing, ensure that the print media is not curled.</p> <hr/> <p>Fan the print media.</p> <hr/> <p>If the print media is damp, turn over the print media.</p> <hr/> <p>If the problem continues, use print media that is not damp.</p>

NOTE:

- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.

Multi-feed Jam

Problem	Action
Print media multiple feeds occur.	<p>Remove the paper from the Priority Sheet Inserter (PSI), and then ensure that the paper is properly loaded in the paper tray.</p> <hr/> <p>If the print media is damp, use print media that is not damp.</p> <hr/> <p>Fan the print media.</p>

NOTE:

- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.


Basic Printer Problems

Some printer problems can be easy to resolve. If a problem occurs with your printer, check each of the following:


- The power cord is connected to the printer, and to a properly grounded electrical outlet.
- The printer is turned on.
- The electrical outlet is not turned off at any switch or breaker.
- Other electrical equipment plugged into the outlet is working.
- When the DocuPrint P255 dw model is connected to a wireless network, an Ethernet cable should be unplugged from the printer.

If you have checked all of the above and still have a problem, turn off the printer, wait for 10 seconds, and then turn on the printer. This often fixes the problem.

Display Problems

Problem	Action
After the printer is turned on, the  (Ready) LED is not lit.	Turn off the printer, wait for 10 seconds, and turn on the printer.
Menu settings changed from the operator panel have no effect.	Settings in the software program, the print driver, or the printer utilities have precedence over the settings made on the operator panel. Change the menu settings from the print driver, the printer utilities, or the software program instead of the operator panel.

Printing Problems

Problem	Action
Job did not print or incorrect characters printed.	<p>Ensure that the  (Ready) LED is lit.</p> <p>Ensure that print media is loaded in the printer.</p> <p>Verify that you are using the correct print driver.</p> <p>Ensure that you are using the correct Ethernet or USB cable and that it is securely connected to the printer.</p> <p>Verify that the correct print media size is selected.</p> <p>If you are using a print spooler, verify that the spooler has not stalled.</p> <p>Check the interface of your printer from Admin Menu.</p> <p>Determine the host interface you are using. Print the System Settings page to verify that the current interface settings are correct. Refer to "Printing the System Settings Page" on page 156 for details on how to print the System Settings page.</p>
Print media misfeeds or multiple feeds occur.	<p>Ensure that the print media you are using meets the specifications for your printer.</p> <p>See also:</p> <ul style="list-style-type: none">• "Usable Print Media" on page 119 <p>Fan the print media before loading it.</p> <p>Ensure that the print media is loaded correctly.</p> <p>Ensure that the paper width guides and length guide are adjusted correctly.</p> <p>Do not overfill the print media sources.</p> <p>Do not force print media into the Priority Sheet Inserter (PSI) or the paper tray when you load it. Otherwise, it may skew or buckle.</p> <p>Ensure that the print media is not curled.</p> <p>Load print media with the recommended print surface facing in the correct direction.</p> <p>See also:</p> <ul style="list-style-type: none">• "Loading Print Media" on page 125 <p>Turn the print media over or around and try printing again to see if feeding improves.</p> <p>Do not mix print media types.</p> <p>Do not mix print media sizes.</p> <p>Remove the top and bottom curled sheets of a ream before loading the print media.</p> <p>Load a print media source only when it is empty.</p>
The envelope is creased after printing.	<p>Ensure that the envelope is loaded in the paper tray as instructed in "Loading Envelopes in the Paper Tray" on page 130.</p>
Page breaks in unexpected places.	<p>Increase the value for Job Time-Out in the System Settings menu, that is on the Printer Maintenance tab in the Printer Setting Utility.</p> <p>Increase the time-out value in the Protocol Settings menu on the CentreWare Internet Services.</p>

Problem	Action
Print media does not stack neatly in the center output tray.	Turn the print media stack over in the Priority Sheet Inserter (PSI) and the paper tray.
Printer does not duplex pages.	Select Flip on Short Edge or Flip on Long Edge from the Duplex menu on the Paper/Output tab of the print driver.

Print Quality Problems

This section includes:

- ["The Output Is Too Light" on page 208](#)
- ["Toner Smears or Print Comes Off/Stain on Back Side" on page 209](#)
- ["Random Spots/Blurred Images" on page 210](#)
- ["The Entire Output Is Blank" on page 210](#)
- ["Streaks Appear on the Output" on page 211](#)
- ["Mottle" on page 211](#)
- ["Ghosting" on page 212](#)
- ["Fog" on page 213](#)
- ["Bead-Carry-Out \(BCO\)" on page 213](#)
- ["Auger Mark" on page 214](#)
- ["Wrinkled/Stained Paper" on page 215](#)
- ["The Top Margin Is Incorrect" on page 216](#)
- ["Protrudent/Bumpy Paper" on page 216](#)


NOTE:

- In this section, some procedures use the Printer Setting Utility or the SimpleMonitor. Some procedures that use the Printer Setting Utility can also be performed using the operator panel.

See also:

- ["Understanding the Operator Panel Menus" on page 162](#)
- ["Printer Setting Utility \(Windows Only\)" on page 42](#)
- ["SimpleMonitor \(Windows Only\)" on page 43](#)

■ The Output Is Too Light




Problem	Action
The output is too light.	<p>The toner cartridge may be low or need to be replaced. Confirm the amount of toner in the toner cartridge.</p> <ol style="list-style-type: none"><li data-bbox="552 587 1225 639">1 Check the toner level on the Consumables tab of the Printer Status window of the SimpleMonitor.<li data-bbox="552 649 982 674">2 Replace the toner cartridge as needed. <hr/> <p>Verify that the print media is dry and the correct print media is used. If not, use the print media recommended for the printer.</p> <p>See also:</p> <ul style="list-style-type: none"><li data-bbox="552 819 934 844">• "Usable Print Media" on page 119 <hr/> <p>Try changing the Paper Type setting on the print driver.</p> <ol style="list-style-type: none"><li data-bbox="552 890 1238 942">1 On the Paper/Output tab for Printing Preferences of the print driver, change the Paper Type setting. <hr/> <p>Disable Toner Saving Mode on the print driver.</p> <ol style="list-style-type: none"><li data-bbox="552 989 1252 1041">1 On the Graphics tab in Printing Preferences of the print driver, ensure that the Toner Saving Mode check box is not selected.

NOTE:

- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.

■ Toner Smears or Print Comes Off/Stain on Back Side




Problem	Action
Toner smears or print comes off. The output has stain on the back side.	<p>The print media surface may be uneven. Try changing the Paper Type setting in the print driver. For example, change Plain to Lightweight Cardstock.</p> <ol style="list-style-type: none">1 On the Paper/Output tab for Printing Preferences of the print driver, change the Paper Type setting. <hr/> <p>Verify that the correct print media is being used. If not, use the print media recommended for the printer.</p> <p>See also:</p> <ul style="list-style-type: none">• "Usable Print Media" on page 119 <hr/> <p>Adjust the temperature of the fusing unit.</p> <ol style="list-style-type: none">1 Launch the Printer Setting Utility, and click Adjust Fusing Unit on the Printer Maintenance tab.2 Adjust the fixing temperature by turning up the value for your printing media.3 Click the Apply New Settings button.

NOTE:

- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.

■ Random Spots/Blurred Images




Problem	Action
The printed result has random spots or is blurred.	Ensure that the toner cartridge is installed correctly. See also: <ul style="list-style-type: none">• "Installing a Toner Cartridge" on page 232
	If you use a non-genuine brand toner cartridge, install a genuine brand toner cartridge.
	Clean up the fusing unit. <ol style="list-style-type: none">1 Load one sheet of paper in the paper tray, and then print a solid image all over paper.2 Load the printed sheet with the print surface facing down, and then print a blank sheet of paper.

NOTE:


- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.

■ The Entire Output Is Blank



If this trouble happens, contact our local representative office or authorized dealer.

■ Streaks Appear on the Output



If this trouble happens, contact our local representative office or authorized dealer.


■ Mottle

Problem	Action
The printed result has mottled appearance.	Adjust the transfer bias. <ol style="list-style-type: none">1 Launch the Printer Setting Utility, click Adjust BTR on the Printer Maintenance tab.2 Adjust the setting for the type of print media being used.3 Click the Apply New Settings button.
	If you use non-recommended print media, use the print media recommended for the printer.

NOTE:

- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.

■ Ghosting



Problem	Action
The printed result has ghosting.	<p>The print media surface may be uneven. Try changing the Paper Type setting in the print driver. For example, change Plain to Lightweight Cardstock.</p> <ol style="list-style-type: none">1 On the Paper/Output tab for Printing Preferences of the print driver, change the Paper Type setting. <hr/> <p>Adjust the transfer bias.</p> <ol style="list-style-type: none">1 Launch the Printer Setting Utility, click Adjust BTR on the Printer Maintenance tab.2 Adjust the setting for the type of print media being used.3 Click the Apply New Settings button. <hr/> <p>Adjust the temperature of the fusing unit.</p> <ol style="list-style-type: none">1 Launch the Printer Setting Utility, and click Adjust Fusing Unit on the Printer Maintenance tab.2 Adjust the fixing temperature by turning up the value for your printing media.3 Click the Apply New Settings button. <hr/> <p>If you use non-recommended print media, use the print media recommended for the printer.</p>

NOTE:

- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.

■ Fog



Problem	Action
The printed result is foggy.	When the whole is printed light, contact our local representative office or authorized dealer. When the printed page is partly light, start Clean Developer . <ol style="list-style-type: none">1 Launch the Printer Setting Utility, and click Clean Developer on the Diagnosis tab.2 Click the Start button.

NOTE:

- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.

■ Bead-Carry-Out (BCO)




Problem	Action
Bead-Carry-Out (BCO) is happening.	If the printer is installed in a high altitude location, set the altitude of the location. <ol style="list-style-type: none">1 Launch the Printer Setting Utility, and click Adjust Altitude on the Printer Maintenance tab.2 Select the value close to the altitude of the location where the printer is installed.3 Click the Apply New Settings button.

NOTE:

- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.

■ Auger Mark




Problem	Action
The printed result has auger mark.	<p>The toner cartridge may be low or need to be replaced. Confirm the amount of toner in the toner cartridge.</p> <ol style="list-style-type: none"><li data-bbox="552 581 1225 639">1 Check the toner level on the Consumables tab of the Printer Status window of the SimpleMonitor.<li data-bbox="552 645 985 670">2 Replace the toner cartridge as needed. <hr/> <p>Start Clean Developer.</p> <ol style="list-style-type: none"><li data-bbox="552 722 1249 780">1 Launch the Printer Setting Utility, and click Clean Developer on the Diagnosis tab.<li data-bbox="552 786 803 811">2 Click the Start button.

NOTE:

- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.

■ Wrinkled/Stained Paper




Problem	Action
The output is wrinkled. The output is stained.	<p data-bbox="543 517 1048 542">Verify that the correct print media is being used.</p> <p data-bbox="543 556 1126 581">If not, use the print media recommended for the printer.</p> <p data-bbox="543 595 1229 653">If excessive wrinkles occur, use paper or other media from a new package.</p> <p data-bbox="543 678 659 703">See also:</p> <ul data-bbox="550 716 934 778" style="list-style-type: none"><li data-bbox="550 716 934 741">• "Usable Print Media" on page 119<li data-bbox="550 749 924 774">• "About Print Media" on page 116 <hr/> <p data-bbox="543 794 1254 852">If you use the envelope, check whether the crease is within 30 mm of the four edges of the envelope.</p> <p data-bbox="543 865 1254 923">If the crease is within 30 mm of the four edges of the envelope, this is considered normal. Your printer is not at fault.</p> <p data-bbox="543 937 1270 1068">If not, check if the printer supports your envelope type, and then check if you loaded the envelope in the correct orientation. For more information, see "Loading Print Media in the Paper Tray" on page 126 or "Loading Print Media in the Priority Sheet Inserter (PSI)" on page 134.</p>

NOTE:

- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.

■ The Top Margin Is Incorrect




Problem	Action
The top margin is incorrect.	Ensure that the margins are set correctly on the application being used.

NOTE:

- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.

■ Protrudent/Bumpy Paper



Problem	Action
Printed surface got protrudent/bumpy.	Clean up the fusing unit. <ol style="list-style-type: none">1 Load one sheet of paper in the paper tray, and then print a solid image all over paper.2 Load the printed sheet with the print surface facing down, and then print a blank sheet of paper.

NOTE:

- If the problem continues even though you have taken suggested actions described above, contact our local representative office or authorized dealer.

Other Problems



Problem	Action
Condensation has occurred inside the printer.	This usually occurs within several hours after you heat the room in winter. This also occurs when the printer is operating in a location where relative humidity reaches 85% or more. Adjust the humidity or relocate the printer to an appropriate environment.




Understanding Printer Messages

The printer's LCD panel displays a message describing the current state of the printer or indicates a possible printer problem you must resolve. This section describes error codes included in the messages, their meanings, and how to clear the messages.

IMPORTANT:


- When an error message is displayed, the print data remaining on the printer and the information accumulated in the memory of the printer are not secured.

Error Code	What You Can Do
010-397	Turn off the printer, and then on. If this does not solve the problem, contact our local representative office or authorized dealer.
016-501	
016-502	See also: <ul style="list-style-type: none">• "Online Services" on page 247
016-719	Press the  button to cancel the current job. Retry when the printer does not process any job.
016-744	Press the  button to clear the message. If this does not solve the problem, contact our local representative office or authorized dealer.
016-745	
	See also: <ul style="list-style-type: none">• "Online Services" on page 247
016-753	Press the  button to cancel the current job. Retry when the printer does not process any job.
016-755	
016-920	Press the  button to clear the message. Check the wireless settings for the access point and the printer.
018-338	Turn off the printer, and then on. If this does not solve the problem, contact our local representative office or authorized dealer.
024-340	
024-360	See also: <ul style="list-style-type: none">• "Online Services" on page 247
024-371	
024-963	Load the specified paper and press the  button to clear the message. Follow the on-screen instruction if one appears.
	See also: <ul style="list-style-type: none">• "Loading Print Media in the Paper Tray" on page 126• "Loading Print Media in the Priority Sheet Inserter (PSI)" on page 134
041-340	Turn off the printer, and then on. If this does not solve the problem, contact our local representative office or authorized dealer.
042-358	
061-370	See also: <ul style="list-style-type: none">• "Online Services" on page 247
091-402	The service life of your printer is coming to an end and the printer will soon stop running. If you want to keep using the printer, change the <code>Machine Life</code> setting to <code>Keep Printing</code> . However, continuous use of the printer will degrade the print quality.
	See also: <ul style="list-style-type: none">• "Machine Life" on page 173

Error Code	What You Can Do
091-441	The printer has exceeded its service life or the settings have been changed to continue using it. The quality of printouts will degrade if the printer continues to be used. See also: • "Machine Life" on page 173
092-651 092-661	Turn off the printer, and then on. If this does not solve the problem, contact our local representative office or authorized dealer. See also: • "Online Services" on page 247
116-314 116-355	Turn off the printer, and then on. If this does not solve the problem, contact our local representative office or authorized dealer. See also: • "Online Services" on page 247
116-720	Press the  button to cancel the current job. Retry when the printer does not process any job.
124-333	Turn off the printer, and then on. If this does not solve the problem, contact our local representative office or authorized dealer. See also: • "Online Services" on page 247
191-310	Although the service life of your printer has been over and the printer stopped running, you can still use the printer by pressing the  (Back) button and the  button at the same time. However, continuous use of the printer will degrade the print quality. See also: • "Machine Life" on page 173
191-311	The life of your printer has been over and you can no longer use the printer.

NOTE:

- As for the following message, which does not include an error code, refer to the table below for the solution.

Error Message	What You Can Do
Load Paper Press OK AAAA BBBB AAAAA: Paper size BBBBB: Paper Type	Check and clear the paper path, load the paper, and then press the  button to clear the message. See also: • "Clearing Paper Jams From the Front of the Printer" on page 193

Error Message	What You Can Do
Load Paper then Press OK AAAA BBBB AAAAA: Paper size BBBBB: Paper Type	Load the specified paper and press the  button to clear the message. See also: <ul style="list-style-type: none"> • "Loading Print Media in the Paper Tray" on page 126 • "Loading Print Media in the Priority Sheet Inserter (PSI)" on page 134
<hr/> Wrong PaperSize: Reload>Press OK AAAA BBBB AAAAA: Paper size BBBBB: Paper Type	
<hr/> Paper Jam: Open Rear Cover >Clear Jam	Open the rear cover and remove the jammed paper. See also: <ul style="list-style-type: none"> • "Clearing Paper Jams From the Rear of the Printer" on page 198
<hr/> Jam at Exit Open Rear Door and Remove Paper	
<hr/> Paper Jam: Open Rear Cover>Push Up Green Lever> Clear Jam	
<hr/> Rear Cover Open Close Rear Cover	Close the rear cover.
<hr/> Toner Low Replace Soon	Replace the toner cartridge soon. See also: <ul style="list-style-type: none"> • "Replacing the Toner Cartridge" on page 228
<hr/> Invalid Toner	Replace the toner cartridge with a supported one. See also: <ul style="list-style-type: none"> • "Replacing the Toner Cartridge" on page 228
<hr/> Replace Toner Cartridge	Replace the toner cartridge with a new one. If you do not replace the toner cartridge, print quality problems may occur. See also: <ul style="list-style-type: none"> • "Replacing the Toner Cartridge" on page 228
<hr/> Insert Toner Cartridge	Turn off the printer, check if the toner cartridge is installed correctly, and then turn on the printer. If this does not solve the problem, contact our local representative office or authorized dealer. See also: <ul style="list-style-type: none"> • "Online Services" on page 247

Contacting Service

When you call for printer service, be prepared to describe the problem you are experiencing or the error message on the LCD panel.

You need to know the model of your printer and serial number. See the label on the rear cover of your printer.

Getting Help

This section includes:

- ["LCD Panel Messages" on page 222](#)
- ["SimpleMonitor Alerts" on page 222](#)
- ["Obtaining the Product Information" on page 223](#)

We provide several automatic diagnostic tools to help you produce and maintain print quality.

■ LCD Panel Messages

The LCD panel provides you with information and troubleshooting help. When an error or warning condition occurs, the LCD panel displays a message informing you of the problem.

See also:

- ["Understanding Printer Messages" on page 218](#)

■ SimpleMonitor Alerts

The SimpleMonitor is a tool that is included on the *Software Pack CD-ROM*. It automatically checks the printer status when you send a print job. If the printer is unable to print your job, the SimpleMonitor automatically displays an alert on your computer screen to let you know that the printer needs attention.

■ Obtaining the Product Information

Obtaining the Latest Print Driver

The latest print driver can be obtained by downloading it from our web site.

NOTE:

- The communication fee shall be borne by users.
- 1** On your print driver's **Properties** dialog box, click the **Configuration** tab and then click **About**.
 - 2** Click **Fuji Xerox Web Site**.
Your web browser starts and our web site is displayed.
 - 3** Follow the instructions on the web site and download an appropriate print driver.

NOTE:

- The URL of the driver download service page is as follows: <http://www.fujixeroxprinters.com/>.
- For the latest information about the print driver features, refer to the Help provided for the print driver.

Updating the Printer's Firmware

Our web site also provides a tool that allows you to update the printer's firmware (software embedded within the printer) from your computer.

The latest firmware and updating tool can be downloaded from the following URL.

Follow the instructions on the web site and download the correct firmware update.

<http://www.fujixeroxprinters.com/>

NOTE:

- The communication fee shall be borne by users.

Enabling Non-Genuine Mode

When toner within the toner cartridge is empty, the `Replace Toner Cartridge` message appears. When you want to use the printer in Non-Genuine Mode, enable Non-Genuine Mode and replace the toner cartridge.

IMPORTANT:

- If you use the printer in Non-Genuine Mode, the performance of the printer may not be at its optimum. And any problems that may arise from the use of Non-Genuine Mode are not covered by our quality guarantee. The continuous use of Non-Genuine Mode can also cause the printer to break down, and any repair charges for such break down will be incurred by users.

NOTE:

- To disable Non-Genuine Mode, select `Off for Toner of Non-Genuine Mode` on the operator panel or clear the check box next to **On** on the **Non-Genuine Mode** page of the **Printer Maintenance** tab of the **Printer Setting Utility**.








This section includes:

- ["Using the Operator Panel" on page 224](#)
- ["Using the Printer Setting Utility \(Windows Only\)" on page 225](#)

■ Using the Operator Panel

NOTE:

- Before starting the operation described below, confirm that the LCD panel shows `Ready to print`.

- 1 Press the  (**Menu**) button.
- 2 Select `Admin Menu` and then press the  button.
- 3 Select `Maintenance` and then press the  button.
- 4 Select `Non-Genuine Mode` and then press the  button.
- 5 Select `Toner` and then press the  button.
- 6 Select `On` and then press the  button.
- 7 Press the  button until the top page is displayed.
The printer switches to Non-Genuine Mode.

■ Using the Printer Setting Utility (Windows Only)

The following procedure uses Windows 7 as an example.

- 1 Click **Start** → **All Programs** → **Fuji Xerox** → **Fuji Xerox Printer Software for Asia-Pacific** → your printer → **Printer Setting Utility**.

NOTE:

- The window to select a printer appears in this step when multiple print drivers are installed on your computer. In this case, click the name of the desired printer listed in **Printer Name**.

The Printer Setting Utility starts.

- 2 Click the **Printer Maintenance** tab.
- 3 Select **Non-Genuine Mode** from the list at the left side of the page.
The **Non-Genuine Mode** page is displayed.
- 4 Select the check box next to **On**, and then click the **Apply New Settings** button.

Maintenance

This chapter includes:

- ["Replacing the Toner Cartridge" on page 228](#)
- ["Ordering Supplies" on page 234](#)
- ["Storing Consumables" on page 236](#)
- ["Managing the Printer" on page 237](#)
- ["Conserving Supplies" on page 240](#)
- ["Checking Page Counts" on page 241](#)
- ["Moving the Printer" on page 242](#)

Replacing the Toner Cartridge

Genuine toner cartridges are available only through Fuji Xerox.

It is recommended that you use a genuine toner cartridge for your printer. Fuji Xerox does not provide warranty coverage for problems caused by using non-genuine consumables.

WARNING:

- Use a broom or a wet cloth to wipe off spilled toner. Never use a vacuum cleaner for the spills. It may catch fire by electric sparks inside the vacuum cleaner and cause explosion. If you spill a large volume of toner, contact your local Fuji Xerox representative.
- Never throw a toner cartridge into an open flame. Remaining toner in the cartridge may catch fire and cause burn injuries or explosion. If you have a used toner cartridge no longer needed, contact your local Fuji Xerox representative for its disposal.

CAUTION:

- Keep drum cartridges (or drum if not a cartridge type) and toner cartridges out of the reach of children. If a child accidentally swallows toner, spit it out, rinse mouth with water, drink water and consult a physician immediately.
- When replacing drum cartridges (or drum if not a cartridge type) and toner cartridges, be careful not to spill the toner. In case of any toner spills, avoid contact with clothes, skin, eyes and mouth as well as inhalation.
- If toner spills onto your skin or clothing, wash it off with soap and water. If you get toner particles in your eyes, wash it out with plenty of water for at least 15 minutes until irritation is gone. Consult a physician if necessary. If you inhale toner particles, move to a fresh air location and rinse your mouth with water. If you swallow toner, spit it out, rinse your mouth with water, drink plenty of water and consult a physician immediately.

IMPORTANT:

- Do not shake the used toner cartridge to avoid spilling of the toner.

This section includes:

- ["When to Replace the Toner Cartridge" on page 229](#)
- ["Removing the Toner Cartridge" on page 230](#)
- ["Installing a Toner Cartridge" on page 232](#)

■ When to Replace the Toner Cartridge

The printer has one toner cartridge: black (K).

When a toner cartridge reaches its usable life-span, the following messages appear on the LCD panel.

Message	Remaining Page Yield	Printer Status and Action
Toner Low Replace Soon*	Approx. 500 pages	The toner cartridge has become low. Prepare a new one.
Replace Toner Cartridge	—	The toner cartridge has become empty. Replace the old toner cartridge with a new one.


* This warning appears only when a genuine toner cartridge is used (i.e. Non-Genuine Mode is disabled).

IMPORTANT:


- When placing a used toner cartridge on the floor or on a table, place a few sheets of paper under the toner cartridge to catch any toner that may spill.
- Do not reuse old toner cartridges that you remove from the printer. Doing so can impair print quality.
- Do not shake or pound used toner cartridges. The remaining toner may spill.
- We recommend you use up a toner cartridge within one year after you remove it from the packaging.

■ Removing the Toner Cartridge


- 1 Turn off the printer.
- 2 Open the front cover.



- 3 Open the toner access cover.




- 4 Spread a few sheets of paper on the floor or table where you want to place the removed toner cartridge.
- 5 Turn the toner cartridge counterclockwise to unlock.



6 Pull the toner cartridge out.

IMPORTANT:


- Do not touch the shutter of the used toner cartridge.
- Always pull the toner cartridge out slowly so you do not spill any toner.



7 Place the toner cartridge slowly on the sheets of paper you spread in step **4**.

■ Installing a Toner Cartridge


- 1 Unpack a new toner cartridge and shake it five times to distribute the toner evenly.



NOTE:

- Handle the toner cartridge carefully to avoid spilling of the toner.


- 2 Insert the toner cartridge into the cartridge holder, and then turn it clockwise to align to the lock mark.




IMPORTANT:

- Be sure to secure the toner cartridge firmly before printing. Otherwise, it may cause some defects.

- 3 Close the toner access cover. Make sure that the cover clicks into place.



- 4 Close the front cover.



- 5 Pack the removed toner cartridge in the box in which the installed toner cartridge was packed up.
- 6 Taking care not to touch any spilled toner, dispose of the sheets of paper you used for toner cartridge replacement.

Ordering Supplies

The toner cartridge needs to be ordered occasionally. The toner cartridge includes installation instructions on the box.

This section includes:

- ["Consumables" on page 234](#)
- ["When to Order a Toner Cartridge" on page 234](#)
- ["Recycling Supplies" on page 235](#)

■ Consumables

IMPORTANT:

- Use only consumables we recommend. Use of any consumables other than recommended can impair machine quality and performance.

Product Name	Product Code	Description
Toner Cartridge	CT201918	Available for DocuPrint P255 dw and capable of printing approximately 2,500 pages.
Toner Cartridge	CT201919	2-in-1 package of CT201918
Toner Cartridge	CT201920	Available for DocuPrint P255 d and capable of printing approximately 2,500 pages.
Toner Cartridge	CT201921	2-in-1 package of CT201920

IMPORTANT:

- The number of printable pages are applicable when A4 plain paper SEF (☐) is used and printing is done continuously in the print ratio of 5% in image density. Also, it satisfies the public values on the basis of JIS X6931 (ISO/IEC 19752). These values are estimates and vary depending on conditions such as the content being printed, paper size, paper type, the printer's operating environment, initializing process done when you turn on or off the printer, and adjustments to maintain print quality.

NOTE:

- The printable number of pages for the starter toner cartridge shipped with the printer is approximately 1,000 pages on DocuPrint P255 dw and 2,500 pages on DocuPrint P255 d.
- Each toner cartridge includes installation instructions on the box.

■ When to Order a Toner Cartridge

The LCD panel displays a warning when the toner cartridge nears its replacement time. Verify that you have a replacement at hand. It is important to order a toner cartridge when the message first appears to avoid interruptions to your printing. The LCD panel displays an error message when the toner cartridge must be replaced.

To order a toner cartridge, contact our local representative office or authorized dealer.

IMPORTANT:

- This printer is designed to provide the most stable performance and print quality when used with the recommended toner cartridge. Not using the toner cartridge recommended for this printer degrades the performance and printing quality of the printer. You could also incur charges if the printer breaks down. To receive customer support and achieve the optimum performance of the printer, be sure to use the recommended toner cartridge.

■ Recycling Supplies

- For environmental protection and efficient use of resources, Fuji Xerox reuses returned toner cartridges and drums (photoreceptors) to make recycle parts, recycle materials or energy recovery.
- Proper disposal is required for toner cartridges no longer needed. Do not open toner cartridges. Return them to your local Fuji Xerox representative.

Storing Consumables

Store consumables in their original packaging until you need to use them. Do not store consumables in:

- Temperatures greater than 40 °C (140 °F).
- An environment with extreme changes in humidity or temperature.
- Direct sunlight.
- Dusty places.
- A car for a long period of time.
- An environment where corrosive gases are present.
- An environment with salty air.

Managing the Printer

This section includes:

- ["Checking or Managing the Printer with the CentreWare Internet Services" on page 237](#)
- ["Checking Printer Status with the SimpleMonitor \(Windows Only\)" on page 238](#)
- ["Checking Printer Status Through E-mail" on page 239](#)

■ Checking or Managing the Printer with the CentreWare Internet Services

When the printer is installed in a TCP/IP environment, you can check printer status and configure settings using a web browser on a network computer. You can also use the CentreWare Internet Services to check the remaining volume of consumables and the paper loaded in this printer.

NOTE:

- When using the printer as a local printer, you cannot use the CentreWare Internet Services. For details on checking the status of a local printer, refer to ["Checking Printer Status with the SimpleMonitor \(Windows Only\)" on page 238](#).

Starting the CentreWare Internet Services

Use the following procedure to start the CentreWare Internet Services.

- 1 Launch your web browser.
- 2 Enter the IP address of the printer in the address bar, and then press the **Enter** key.
The CentreWare Internet Services appears on your browser.

• Using Online Help

For details regarding the items that you can set on the CentreWare Internet Services, click the **Help** button to display the online Help.

■ Checking Printer Status with the SimpleMonitor (Windows Only)

The SimpleMonitor is a tool that is installed along with your print driver. It automatically checks the printer status when you send a print job. The SimpleMonitor can also check the status of the paper tray and remaining amount of toner in the toner cartridge.

Starting the SimpleMonitor

Double-click the SimpleMonitor icon on the taskbar or right-click the icon and select **Printer Selection**.

If the SimpleMonitor icon is not displayed on the taskbar, open the SimpleMonitor from the **Start** menu.

The following procedure uses Microsoft Windows 7 as an example.

- 1 Click **Start** → **All Programs** → **Fuji Xerox** → **Fuji Xerox Printer Software for Asia-Pacific** → your printer → **SimpleMonitor-Btype for Asia-Pacific**.
The **Printer Selection** window appears.
- 2 Click the name of the desired printer from the list.
The **Printer Status** window appears.

For details on the functions of the SimpleMonitor, refer to the Help of the SimpleMonitor.

See also:

- ["SimpleMonitor \(Windows Only\)" on page 43](#)

■ Checking Printer Status Through E-mail

When connected in a network environment where e-mail exchange is available, the printer can send an e-mail report to specified e-mail addresses containing the following information:

- The network settings and the printer status
- The error status which has occurred on the printer

Setting the E-mail Environment

Access the CentreWare Internet Services. On the **Properties** tab, configure the following settings according to your e-mail environment. After configuring the settings on each window, always click **Apply** and then turn off/on the printer to reboot. For details on each item, refer to the Help on the CentreWare Internet Services.

Item	Item to be configured	Description
General Setup > StatusMessenger	Recipient's E-mail Address	Specify up to two e-mail addresses to which notices about changes in printer status or errors are sent.
	Notification Items	Set the content of the notices to send via e-mail.
Port Status	StatusMessenger	Select Enabled .
Protocol Settings > E-mail	SMTP Server Settings	Select appropriate settings for sending and receiving e-mails.
	• Machine's E-mail Address	
	• SMTP Server Address	
	• SMTP Server Port Number	
	Send Authentication	
	• E-Mail Send Authentication	
	• Login Name	
	• Password	
	• Re-enter Password	
	POP3 Server Settings	
• POP3 Server Address		
• POP3 Server Port Number		
• Login Name		
• Password		
• Re-enter Password		

Conserving Supplies

You can change several settings of your print driver to conserve toner and paper.

Supply	Setting	Function
Toner cartridge	Toner Saving Mode in the Graphics tab of the print driver	This check box allows the users to select a print mode that uses less toner. When this feature is used, the image quality will be lower than when it is not used.
Print media	Multiple Up in the Layout tab of the print driver	The printer prints two or more pages on one side of a sheet. The available numbers that each print driver can print on one sheet of paper are as follows: <ul style="list-style-type: none">• Microsoft Windows Print Driver: 2, 4, 8, or 16 pages• Mac OS X Print Driver: 2, 4, 6, 9, or 16 pages Combined with the Duplex (2-sided) print setting, Multiple Up allows you to print up to 32 pages on one sheet of paper. (16 images on the front and 16 on the back)

Checking Page Counts

You can print the System Settings page to check the total number of printed pages. The total number of printed pages is shown in the Print Volume section, classified by paper sizes.

Single side print (including Multiple Up print) is counted as one job, and 2-sided print (including Multiple Up print) is counted as two. During duplex (2-sided) printing, if an error occurs after one side is printed properly, it is counted as one.

During duplex (2-sided) printing, a blank page may be inserted automatically depending on the settings of the application. In this case, the blank page is counted as one page. If a blank page is inserted during duplex (2-sided) printing for odd-number pages and the rear of the last odd-number page is left blank, however, this page is excluded from page counting.





NOTE:

- Refer to "[Printing the System Settings Page](#)" on page 156 for details on how to print the System Settings page.


Moving the Printer

IMPORTANT:


- Printer must be moved or stored top-side up after usage or it may break down.




- 1 Turn off the printer.




- 2 Disconnect the power cord, interface cable, and any other cables.



- 3 Remove all paper from the center output tray and close the output tray extension, if open.



- 4 Remove the paper tray from the printer.




- 5 Lift the printer and move it gently.

NOTE:

- If you move the printer over a long distance, be sure to remove the toner cartridge and pack the printer inside a box to avoid spilling of the toner.



- 6 Place the printer at a new location and replace the paper tray.



Contacting Fuji Xerox

This chapter includes:

- ["Technical Support" on page 246](#)
- ["Online Services" on page 247](#)

Technical Support

Fuji Xerox recommends the Customer first utilize support materials shipped with the product, product diagnostics, information contained on the Web, and e-mail support. If unsuccessful, to obtain services under product warranty, the Customer must notify Fuji Xerox Telephone Support or its authorized service representative of the defect before the expiration of the warranty period. Customer will provide appropriate assistance to Telephone Support personnel to resolve issues, such as restoration of the operating system, software program and drivers to their default configuration and settings, verification of functionality of our products, replacement of customer replaceable units, clearing paper misfeeds and cleaning the unit and other prescribed routine and preventative maintenance.

If the Customer's product contains features that enable Fuji Xerox or its authorized service representative to diagnose and repair problems with the product remotely, we may request that the Customer allow such remote access to the product.

Online Services

You can find detail Product and Consumable warranty information and activate your warranty by registering your details on our web site at <http://www.fujixerox.com/support/docuprint/>.

Fuji Xerox Online Support Assistant provides instructions and troubleshooting guides to resolve your printer problems. It is an easy-to-use, searchable online Help. To find out more, please visit our online support at <http://www.fujixerox.com/support/docuprint/>.

Index

Numerics

2 Sided Options 176, 181

A

Adjust Altitude 173
Adjust BTR 170
Adjust Fusing Unit 171
Admin Menu 164
Auto Reset 169
Automatic duplex printing 143
Avoiding jams 191

B

Back button 34
Basic printer problems 203

C

Cancel Job button 34
Canceling a print job 142
 From computer 142
 From operator panel 142
Center output tray 32, 192, 200
CentreWare Internet Services 41, 167
 Managing printer 237
 Online help for 237
 Starting 237
Clean Developer 171
Clearing jams 190
Clearing paper jams
 From center output tray 200
 From front of printer 193
 From paper tray 193
 From Priority Sheet Inserter (PSI) 196
 From rear of printer 198
Connecting printer 49
Connection specifications 49
Connection type 49
Conserving supplies 240
Consumables 234
Contacting service 221
Continuous print speed 27
CPU 28
Custom paper 153
 With Mac OS X driver 154
 With Windows print driver 154

D

Demo Page 163

Density Adjustment 171
Dimensions 29
Display problems 204
Draft Mode 179
Duplex printing 25, 143

E

Electrical safety 14
Energy Saver button/LED 34
Envelope 170, 171
Error and warning messages 222
Error History 163
Error LED 34
Ethernet 164
Ethernet port 33, 49

F

F/W Version 170
Fault Timeout 169
First print output time 27
Font 177
Font Pitch 178
Font Size 178
Form Line 179
Front cover 32, 192
Fusing system 27

G

Getting help 222
 SimpleMonitor alerts 222

I

Image Enhancement 179
Image Orientation 176
Initialize NVM 168, 172
Installing print driver
 Linux 103
 Mac OS X 97
 Windows 58
Interface 29
IP Filter 167

J

Job History 163
Job Timeout 169

L

- Labels 170, 171
- Launcher 44
- Layout 182
- LCD 34
- LCD panel 34
- LCD panel messages 222
- Levers 33
- License 9
- Light Card 170, 171
- Line Termination 180
- Liquid Crystal Display 34
- Loading envelopes
 - Paper tray 130
 - Priority Sheet Inserter (PSI) 137
- Loading print media 125
 - Paper tray 126
 - Priority Sheet Inserter (PSI) 134
- Low Toner Alert Msg 170
- LPD 167

M

- Machine installation 16
- Machine Life 173
- Main components 32
- Maintenance 170
- Manual duplex printing 144
- Manuals 10
- Memory capacity 29
- Menu button 34
- Meter Readings 164
- mm / inch 169
- Mottle 211
- Multiple Up 25, 240

N

- Network 164
- Network connection setup 61
- Non-Genuine Mode 172, 224

O

- OK button 34
- OPC drum 33, 192
- Operating noise 29
- Operational safety 18
- Operator panel 32
- Ordering supplies 234
- Output Size 182
- Output tray capacity 28
- Output tray extension 32, 139

P

- Page description language 29
- Panel Lock 174, 185
- Panel Settings 163
- Panel Settings Page 36
- Paper capacity 28
- Paper chute 33
- Paper jam location 192
 - Center output tray 192
 - Front cover 192
 - Levers 192
 - OPC drum 192
 - Paper tray 192
 - Priority Sheet Inserter (PSI) 192
 - Rear cover 192
- Paper jams 193, 198, 200, 202
 - Paper tray 193
 - Priority Sheet Inserter (PSI) 196
- Paper Size 175
- Paper size 28
- Paper Tray 119
- Paper tray 28, 32, 192
- Paper tray cover 32
- Paper type 28
- Paper weight 28
- Paper width guides 32, 128
- Parts name 32
- PCL Fonts List 163
- PCL print driver 58
- PCL Settings 175
- PDF Password 181
- PDF Settings 181
- Peer-to-peer 92
- Plain 170, 171
- Point and Print 89
- Port 9100 167
- Port Status 174
- Postcard 170, 171
- PostScript Level3 Compatible print driver 58
- Power 29
 - Power connector 33
 - Power consumption 29
 - Power saver mode 187
 - Power Saving Timer 168
 - Power switch 32
- Print driver
 - Linux 103
 - Mac OS X 97
 - PCL 58
 - PostScript Level3 Compatible 58
 - Windows 58
 - XML Paper Specification 58, 96
- Print driver pre-install status 59

- Print media 240
 - Dimensions 125
- Print Mode 181
- Print quality problems 207
- Printer
 - Managing 237
 - Messages 218
 - Moving 242
 - Status 239
- Printer messages 218
- Printer Setting Utility 42
- Printer software 39
- Printer status 239
- Printing 141
 - Basics 115
 - Custom paper 153
 - From computer 141
 - method 27
 - Problems 205
 - With Web Services on Devices 159
- Printing method 27
- Printing problems 205
- Printing with Web Services on Devices 159
- Priority Sheet Inserter (PSI) 25, 28, 32, 120, 192, 196
- Product code 27
- Product features 25
- Product information 223
- Protocol 167
- PS Data Format 168, 175
- PS Error Report 180
- PS Fonts List 163
- PS Job Timeout 180
- PS Settings 180

Q

- Quantity 179, 181

R

- Ready LED 34
- Rear cover 33, 192
- Rear cover handle 33
- Recycled 170, 171
- Recycling supplies 235
- Registration roller 33
- Report Page 156
- Reset Wi-Fi 166
- Resetting to factory defaults 188
- Resolution 27

S

- Safety
 - Electrical 14
 - Operational 18
- Secure Settings 174
- SimpleMonitor alerts 222
- SNMP 167
- Software Download 174
- Software installation 47
- Specifications 27
- Standard Paper and Tested Paper 121
- StatusMessenger 167, 239
 - Configuring 239
- Storing consumables 236
- Supplies
 - Recycling 235
 - When to order 234
- Supported OS 29
- Symbol Set 178
- System Settings 163, 168

T

- TCP/IP 166
- Tone 27
- Toner access cover 32
- Toner cartridge 32, 229
 - Conserving 240
 - Install 232
 - Remove 230
 - When to order 234
 - When to replace 229
- Toner Refresh 172
- Total page counts 241
- Transfer roller 33
- Tray 182
- Tray Settings 182

U

- Usage environment 30
- USB port 33, 49
- USB Settings 174
- User Setup Disk Creating Tool 45

W

- Warm-up time 27
- Weight 30
- Wi-Fi Setup 165
- Wi-Fi Status 164
- Wireless network settings (Mac OS X) 98
- Wireless network settings (Windows) 62
- WPS Setup 166

X

XML Paper Specification print driver 58, 96